# MANUAL

# **PC Software Manual**

for the Servo Amplifier DS, DPC and the Battery Drives BAMO-D, BAMOBIL-D, BAMOCAR-D

# NDrive.3



Stegmaier-Haupt GmbH
Industrieelektronik-Servoantriebstechnik
Untere Röte 5
D-69231 Rauenberg
Tel.: 06222-61021
Fax: 06222-64988
Email: info@stegmaier-haupt.de
Http://www.stegmaier-haupt.de

Edition /	Ver	sion
2017	V	1

1 (	Lontents
2 B	asic information
2.1	History 4
2.2	Further manuals for digital units:4
2.3	General5
2.4	Safety advice:
2.5	Operating system
2.6	Software installation
2.7	Communication RS232 (COMx)6
3 S	tart screen7
3.1	Description7
3.2	Operation9
3.3	Entry and selection 10
4 H	lelp 11
4.1	Direct help
5 S	torage12
5.1	Storage in the controller 12
5.2	Storage to the pc
6 S	election of the communication interface13
6.1	Display of a saved file (*.urf) in the NDrive13
6.2	Firmware update14
7 N	Лeasured values 15
7.1	Table of measured values    15
7.2	Table / measured value   16
8 C	Conversion
8.1	Conversion of the measurement units 17
9 E	rrors
9.1	Error list
9.2	Warnings
9.3	States
9.4	Display of inputs and outputs 22
10	Enable
10.	1 Hardware - Enable FRG/RUN 23
10.	2 Safety 25
10.3	3 Settings
10.4	4 Motor setting
10.	5 Setting window for the feedback encoder 30
10.	6 Setting window for the feedback encoder

# Basic information

10.7	Setting X8 as second counter input	. 32
10.8	Brake setting	. 33
10.9	Ballast circuit setting	35
10.10	Motor temperature setting	. 36
10.11	Setting of the power connection/bus circuit	39
10.12	Output stage temperature	. 40
10.13	Setting field for rated servo data	41
10.14	Setting field for rated servo data	42
10.15	Command value setting	. 43
10.16	BTB / RDY setting	. 47
11	CAN-BUS settings	48
11.1	Settings CAN-BUS	48
11.2	Aufbau serielles Protokoll	49
11.3	Interface RS232	50
12	Parameter	. 51
12.1	Current controller parameters	. 51
12.2	Current reduction parameters	. 54
12.3	Current reduction functions	. 55
12.4	Current controller parameters	. 56
12.5	Speed controller parameters	59
12.6	Speed controller parameters	62
12.7	Speed controller optimization	. 65
13	Field weakening at synchronous motors	67
13.1	Field weakening mode	67
14 .	Forque control	69
14.1	Torque control	. 69
15	Position controller parameters	. 70
15.1	Setting of the position controller	. 70
15.2	Reference run	. 74
15.3	Position controller optimization	. 76
15.4	Position scaling	. 77
16	Frequency converter parameters	. 78
16.1	Frequency converter parameters	. 79
17	Logic	80
17.1	Logic setting window	. 80
17.2	Digital inputs	. 81
17.3	Digital outputs	. 82
17.4	Logic links	84

# Basic information

18	Diagnosis	85
18.	1 Diagnosis window	85
18.2	2 Manual read/write	
18.3	3 Track display field	86
18.4	4 Information	87
19	Monitor	88
19.:	1 Measured values	88
20	Options	89
20.3	1 Recuperation for vehicles (Brake Car)	89
21	Automatic setting functions	90
21.3	1 Setting window Auto	
21.2	2 Tuning still (0x85-1)	
21.3	3 Tuning rotating (0x85-2)	92
21.4	4 Phasing still (0x85-3)	92
21.	5 Measuring the encoder offset (phase angle)	
21.0	6 Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)	94
21.0 21.7	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> </ul>	94 95
21.0 21.7 21.8	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> </ul>	94 
21.0 21.7 21.8 21.9	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> </ul>	
21.0 21.7 21.8 21.9 <b>21</b> .9	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> </ul>	
21.0 21.7 21.8 21.9 <b>21.</b> 7 <b>22</b>	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> </ul>	
21.0 21.7 21.8 21.9 <b>21.</b> 7 <b>21</b> .7 <b>22</b> 22.7	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Overview</li> </ul>	
21.0 21.7 21.8 21.9 21.9 21.7 22 22.7 22.7	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Oscilloscope settings</li> </ul>	
21.0 21.7 21.8 21.9 21.9 21.7 22 22.7 22.7 22.7	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Overview</li> <li>Oscilloscope settings</li> <li>Arrow key for the channel selection</li> </ul>	
21.0 21.7 21.8 21.9 21.9 21.9 22.7 22.7 22.7 22.7 22.4	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Overview</li> <li>Oscilloscope settings</li> <li>Arrow key for the channel selection</li> <li>Trigger settings</li> </ul>	
21.0 21.7 21.8 21.9 21.9 21.9 22.7 22.7 22.7 22.7 22.9 22.9	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Overview</li> <li>Oscilloscope settings</li> <li>Arrow key for the channel selection</li> <li>Display of measured values</li> </ul>	
21.0 21.7 21.8 21.9 21.7 21.7 22.7 22.7 22.7 22.7 22.4 22.4 22.4 22	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Overview</li> <li>Oscilloscope settings</li> <li>Arrow key for the channel selection</li> <li>Trigger settings</li> <li>Display of measured values</li> <li>Parameters on the oscilloscope page</li> </ul>	
21.0 21.7 21.8 21.9 21.9 21.9 22.7 22.7 22.7 22.4 22.4 22.4 22.4 22.4	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Overview</li> <li>Oscilloscope settings</li> <li>Arrow key for the channel selection</li> <li>Trigger settings</li> <li>Display of measured values</li> <li>Parameters on the oscilloscope page</li> <li>Test operation</li> </ul>	
21.0 21.7 21.8 21.9 21.7 21.7 22.7 22.7 22.7 22.7 22.7 22.7	<ul> <li>Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)</li> <li>Analog offset (0x85 -6)</li> <li>Tacho offset (0x85 -7)</li> <li>Calc from Motorplate (0x85-8)</li> <li>Calc from Motorplate (0x85-8)</li> <li>VdcBus Adjustment</li> <li>Oscilloscope</li> <li>Overview</li> <li>Oscilloscope settings</li> <li>Arrow key for the channel selection</li> <li>Trigger settings</li> <li>Display of measured values</li> <li>Parameters on the oscilloscope page</li> </ul>	

# 2 Basic information

### 2.1 History

Version	Modifications	Date
2016 / V1.1	Fax-Number / page 68 (lq – complete)	02.08.2016
2017 / V1	Error-List / Parameter	14.11.2017

#### Note :

Only use NDrive3xx for units from firmware FW-350 on (from serial no. 70000)

# 2.2 Further manuals for digital units:

1.	MANUAL	DPC 4xx-AC DSxx, BAMO-D3, BAMOBIL-Dx	Hardware description
2.	MANUAL	DSxx, BAMO-D3, BAMOBL-Dx	Commissioning
3.	MANUAL	CAN	BUS system

#### Use all manuals for the planning, the installation, and the commissioning!

Included as CD version in the equipment delivery (DOKU-SOFT).

MANUAL includes warning and safety notes, descriptions to standards and regulations, and mechanical and electrical installation notes.

The MANUAL must be available at any time for all persons dealing with the unit.

#### Short symbols/terms

Servo	Digital motor controller
Unit	Digital motor controller
PC	Personal computer, notebook

### 2.3 General

The software NDrive3 is used to set-up and optimize digital servo amplifiers (DS, DPC) and motor drives (BAMO-D, BAMOBIL-D, BAMOCAR-D).

Basic computer skills and fundamental knowledge of the Windows software are required. The NDrive3 software and the respective manual are available on CD or via the internet.

### 2.4 Safety advice:

The parameters and settings of the controller (servo amplifier) and the motor are preset with the software NDrive3. Operating parameters can be preset and changed during operation. The computer and the PC programs are not

malfunction-proof. The user must ensure that in case of malfunctions neither personnel nor machines are endangered and that the drive is stopped.



Saved data can be changed by third parties. Any imported data record must be checked prior to re-use.

Any adjustments or optimising work on the running drive must only be carried out by trained competent personnel with knowledge of drive and control engineering and computer handling. Further to this, the safety advice for the amplifier and the drive used must be observed. Any operation not conform to the safety guidelines is not permissible.

### 2.5 Operating system

NDrive will operate with WINDOWS 2000 and WINDOWS NT4, WINDOWS XP, Windows Vista

#### Min. required PC equipment

Processor	80486 or superior
Graphics	WINDOWS compatible
Hard drive, available capacity	ЗМВ
Floppy disc drive	3.5"
CD drive	CD ROM
RAM, min.	8MB
Interface	COM1 or COM2 (RS232, USB adapter)
WINDOWS is a registered trademark o	f Microsoft Corp.

### 2.6 Software installation

The user software NDrive3 can be copied. An installation program is not required.

From a CD (Compact Disc Doku-Soft-Vx)

Copy the software file (NDrive-x digital Servo) from the CD to the hard drive (do not install). Open the NDrive-x-Aktuell-Vxx,

start the software file NDrive-x-Vxx.exe with a double click.

### **NDrive ICON**

Right click on the software file NDrive-Vxx.exe. Send to the desktop. The icon is displayed on the desktop as shortcut to NDrive-Vxx. Double click the desktop icon to start NDrive-Vxx

### 2.7 Communication RS232 (COMx)

Software communication between the PC and the servo amplifier is effected via RS232. 115200 baud rate.

The connecting cable is a null modem type cable.

Do not use a null modem link cable! Use an USB-RS232 adapter with PCs with an USB interface.

Use the USB adapter RS323 for PCs with an USB interface.

Plug and unplug the connecting cable only when the interface is disconnected.

The interface is galvanically connected to device ground (AND).

### RS232 PC X10DSxx/BAxx RxD TxD GND GND Schirm am Steckergehäuse Shield at connector housing

Icon\_32x32

DS400-RS232-Verb.



#### 3 Start screen



### 3.1 Description

The program presents a screen consisting of two elements. A constant outer frame (grey) and an interleaved page area (blue). The pages are accessed by a horizontal tab bar running across the top of the frame

Тор	Title bar, menu bar, page tabs
Left	Display of speed, current, inputs and outputs, states, errors, and test functions
Bottom	Setup states

The screen surface switches between pages.

The tab structure allows for easy access of relevant data and fast switching between the pages. The grey frame surface is constantly displayed.

The selected pages are opened across the complete blue area.

It is always possible to switch between the pages without a time delay.

Multi-page parameters are automatically transferred. Settings referring to only one page remain unaffected.

### Title bar NDrive version + parameter set name

#### Drop-down menu for Windows commands

IMD Utility Software V3.03RC20         Datei       Kommunikation         Hife       Laden Register         Alt-X       Speichern Register         Alt-Speichern Register file (*.utd)       Drucke Register file (*.utd)         Drucke Register       Alt-P         Drucke ausgewählte Register       Skript ausführen         Exit       Alt-X	Communication COM-Port Baud rate 115200	Help         Manual       F1         Uber       Uber         Change Language       Tress         About       Select language         (Change Language)       Change Language
File Features		
Load register	NDrive file*.urf	Loading of the parameter file from the pc to the unit
Save register Import register file (*.utd.)	DRIVE file*.utd	Loading of the parameter from the unit to the pc file Loading of an old (utd) parameter file from the pc to the unit
Print register Print selected registers Script execution Exit	NDrive file Selected files (for service only)	Printing of selected parameters (registers) Printing of selected parameters (registers) Load protected parameters to the unit Closing the window
Page - Register		
Einstellun	gen Drehzahl Position Logik	Bus Ozilloskop Monitor Diagnose Auto Extra
Permanently active dis	splay and inut fields Speed	Numeric speed display in rpm. Bar graph 0-100 % speed
Dista Komunikation Heffe - Ordenali 916 0000 10000 10000 10000	Current	Numeric current display in Aeff. Bar graph 0-200% rated current
Drown         NUM           0,18         0.15           1         200%	Inputs / Outputs	Display of the active inputs and outputs
De-Out         Status         Status           Outrit         Origin         Origination           Outrit         Origin         Origin           Outrit         Origin         Origin           Outrit         Outrit         Origin           Origin         Outrit         Outrit	States	Display of the states
Otton Orong Onderstein Otton Orong Onderstein Otton Orong Onderstein Otton Otton Otton Otton Otton	Warning	Display of the warnings
000         0xm         0m4xm           0xm         0m4xm         0m4xm	Faults	Error display
- Fahlar	Test	Only for test operation!!
	Current	Numerical entry for a test current
Test	Speed	Numeric entry of a test speed value
Drive is online (COML, 11520).	Position	Dest: = numeric entry of the position P(preset) = entry as actual position value and command value Calib. = Start of a reference run
Drive is online (COM1, 115200).	Firmware: 452	Bez.Achse: ko

### 3.2 Operation

The PC user interface has a standard WINDOWS format. Only use whole numbers and write decimals with a point. Write positive values without a sign, negative values with a -sign.

#### Offline operation

There is no connection to the control unit (servo amplifier). The message 'Drive is offline' flashes in the bottom line of the frame display.

To download a parameter file click  $\rightarrow$  communication  $\rightarrow$  view file and use the windows browser to select and open a file (\*.urf).

The parameter data are transferred to the input fields.

The data can now be optimised and saved again with  $\rightarrow$  file  $\rightarrow$  save register. The original file may be overwritten or a new file created.

#### **Online operation**

Plug the connecting cable RS232. Switch on the PC and the control unit.

Select the baud rate of 115200.

Select the communication interface with  $\rightarrow$  communication  $\rightarrow$  COM1 to COM8.

When the connection is successful, the message 'Drive is online' appears in the bottom frame line.

The active drive parameter data will be imported from the drive to the PC and can be manipulated via the input fields as required.

Any changed data will be downloaded from the PC to the RAM of the drive by clicking  $\rightarrow$  enter. Tested parameters are permanently saved in the EEPROM by clicking the key field 'memory level0.1'.





### **3.3** Entry and selection

Click the **entry field** (left mouse button), enter a numerical value and click  $\rightarrow$  enter to save the new value into the PC RAM and the Drive RAM.

Nnom	3000	RPM
Fnom	500,0	Hz

Up-Down value change Click an input field (left mouse button). The value can be changed via the up and down buttons. The values are immediately updated in both device RAMs

#### Drop-down menu



Click the arrow button of the list box. The menu shows the available options. Scroll up or down by means of the arrow button and select an option. Selecting an option updates the variable and closes the option menu

Richtung	CW	ccw
Bremse	ON	OFF

#### **Option buttons**

Click button. The green button displays the selected function. A tick in the button shows the selected option.

# Help

#### Help 4

### 4.1 Direct help

Shift the cursor to the parameter entry field or setup field and an explanation field opens. An explanation field opens.

Richtung	CW	ccw	Ballast	INT
Bremse	ON	OFF	Ballast-P	25
Bremse verzug	250	ms	Ballast-R	80
freier Auslauf	ON	o 0xf1	rzäcon mar. Zoit	dar Promos
M-Temp	700	2 Zeitbere	eich 0 bis 1000ms	uer breinse
		_	Taktfree	
		Hilfe-to	oltip	

Manual

Über...

Change Language...

F1

IMD Utility Software V3.03RC20

0 k

N

Г

Datei Kommunikation Hilfe

Drehzahl-

RPM

### Help menu

#### Click Help.

Click Manual.

A pdf version of the manual *Manual NDrive* is opened. Clicking the topic in the bookmark opens the requested page.



Select language Click Help Click ChangeLanguage A list box opens Select the language Restart NDrive

Help	
Manual Über	F1
Charge Language	
Change Language	

### 5 Storage

### 5.1 Storage in the controller

#### Download of parameter data from a PC to the controller (servo) RAM (volatile)



When there is an active communication the parameters displayed on the screen are those currently active in the drive RAM. When a value is changed, the value is directly updated in the drive RAM when the return key is pressed.

Attention: If the +24 V auxiliary voltage is switched off, the RAM data will be lost.



EEPROM (non-volatile)

Click  $\rightarrow$  write0 (1) on the setting page. The data are written into the drive EEPROM (level 0, 1). The EEPROM level 0 contains the current parameter record which is downloaded to the drive RAM each time when the 24 V auxiliary voltage is switched on.

Note:

The data EEPROM level 2 is code protected and not visible. It is only visible with the release code. The data of *Write2* are write-protected and contain the factory-set parameter set.

#### Transfer of parameter data from the drive (servo) to the PC



Click  $\rightarrow$  *read0 (1, 2)* on the setting page. The parameter data are transferred from the drive EEPROM to the drive RAM and from the drive RAM to the PC RAM

read / load

### 5.2 Storage to the pc

IMD Utility Software V	3.03RC2
Datei Kommunikation Hilfe	2
Laden Register	Alt-L
Speichern Register	Alt-S
Import register file (*.utd)	)
Drucke Register	Alt-P
Drucke ausgewählte Regis	ster
Skript ausführen	
Exit	Alt-X



read / load



Saving the parameter data of the PC RAM to PC disks (hard drive, CD, floppy disk, etc.)

#### Saving parameter data in the PC (\*.urf)

#### - via the menu bar

Click  $\rightarrow$  *file* in the menu bar.

Click  $\rightarrow$  *save registers* and the window is opened. Select the required folder and save with the same or a different file name.

#### Through the button save

Click  $\rightarrow$  *save* on the setting page.

The window *save register file* is opened. Select the required folder and save with the same or a different file name

# Transfer of parameter data from PC discs (hard drive, CD, floppy disk, etc.) to the PC RAM

Click  $\rightarrow$  *download* on the setting page and the window *download register file* is opened.

Select the requested folder and click  $\rightarrow$  **open** to download the data to the NDrive

The parameters are in the RAM. In order to store them permanently, click  $\rightarrow$  *write 0* or *write 1* (EEPROM).

### 6 Selection of the communication interface

### - for online operation

Click the menu  $\rightarrow$  **communication** to drop down the options. Click the requested **COMx** interface (Com1 to Com8) to select it. The checked interface is selected and the connection to the control unit (servo) is established.

The message *Drive is Online (COMx)* is displayed in the bottom screen frame.

#### Note:

If the data scroll in the warning or error display, the COM connection is faulty.

#### Stop communication

Open drop down menu Kommunikation. Click  $\rightarrow Offline$  .

The connection is cut off and the message Drive is offline is displayed in the bottom screen frame.

### 6.1 Display of a saved file (\*.urf) in the NDrive

Click 'view file'.

The window 'load register file' opens. Select folder.

File is loaded to the NDrive.

The parameter fields are overwritten. The parameter data can be changed. Save the modified and checked values with the same or a new name (\*.urf) in the pc via 'save file register'.



uer Ordner		
Name ^	Änderungsdatum	Тур
BAMOCAR-400-IN-ATS-Motor.urf	21.10.2013 12:37	URF-Datei
BAMOCAR-400-RS-ATS-Motor.urf	21.10.2013 15:15	URF-Datei
1		
BAMOBIL-D3-62-250-RS-FORI-FU-FW440.urf		

MD Utility Software V3.03RC20

Alt-O

Alt-1

Alt-2

Alt-3

Alt-4

Alt-5

Alt-6

Alt-7

Alt-8

•

Datei Kommunikation Hilfe

Offline

✔ COM1

COM2

COM3

COM4

COM5

COM6

COM7

COM8

Baudrate

Zeige Datei

Serial Boot

Drehz

RPM

Strom

A rms

In-O

O LM

LM

O IN2

OIN1

### 6.2 Firmware update

Please use the manual <u>"Firmware update-2017-SD-Flash EN.pdf.</u> Then you will have an update version. The latest manual can either

#### Manual:

be found on the CD

#### CD-DOKU-SOFT

Folder "SOFTWARE\NDrive2-Software\Firmware update inst"

# 7 Measured values

# 7.1 Table of measured values

Measured values			-
Selected values	Function	Range	ID address
OFF	No measured value		REGID
N cmd	Speed command value before ramp	+/- 32767	0x31
N cmd Ramp	Speed command value after ramp	+/- 32767	0x32
N actual	Speed actual value	+/- 32767	0x30
N actual-filter	Filtered speed actual value for display	+/- 32767	0xa8
N error	Speed command/actual value error	+/- 32767	0x33
l cmd	Current command value	see table	0x26
I cmd Ramp	Current command value after ramp	see table	0x22
I actual	Actual current(I)	see table	0x20
I actual-Filter	Filtered current actual value for display	see table	0x5f
Leistung	Motor power		0xf6
Pos dest	Position target	+/- 2147483647	0x6e
Pos cmd	Position command value	+/- 2147483647	0x91
Pos actual	Actual position	+/- 2147483647	0x6d
Pos error	Position command/actual value error	+/- 32767	0x70
Zero capture			0x74
I_Limit1	Digital input END1	0/1	0xe4
I_Limit2	Digital input END2	0/1	0xe5
I_Din1	Digital input 1	0/1	0xe6
I_Din2	Digital input 2	0/1	0xe7
I_Run (Frg)	Digital input control unit enable	0/1	0xe8
O_Dout1	Digital output 1	0/1	0xe0
O_Dout2	Digital output 2	0/1	0xe1
O_Dout3	Digital output 3	0/1	0xe1
O_Dout4	Digital output 4	0/1	0xe1
O_Rdy (BTB)	Drive ready message	0/1	0xe2
I_Fault	Intern. error message from the power section	0/1	0xe9
I_Regen (Ballast)	Ballast circuitry state	0/1	Oxea
I_o'/u' voltage	Over-voltage condition	0/1	0xeb
I_LossOfSignal	Resolver signal missing or faulty	0/1	0xec
0_Go	Internal enable	0/10/1	0xe3
O_Brake	Active brake	0/1	0xf2
O_lcns	Limited to continuous current	0/1	0xf3
O_Less_NO	Speed inferior to 0.1%	0/1	0xf5
O_Toler	Within position tolerance range	0/1	0xf4
Rotor	Rotor position signals (RST)	1 to 6 (0 or 7 = error	0x5c
Var1	Comparison reference value 1	+/-32767	0xd1
Var2	Comparison reference value 2	+/-32767	0xd2
Var3	Comparison reference value 3	+/-32767	0xd3
Var4	Comparison reference value 4	+/-32767	0xd4
MPOS_mech	Mechanical rotor position		0x42
MPOS_elec	Electrical motor position	100000	0x43
Ain1	Analog input Ain1	+/-32/6/	UX05
Ain2	Analog Input AIn2	+/-32/6/	UXDb
13_adc	Current actual value sensor 3	2048 +/- 2000	0xa9
	Current actual value sensor 2	2048 +/- 2000	
11_actual	Current actual value Ph1	see table	0x54
IZ_actual	Current actual value Ph2	see table	0x55
is_actual	Current actual value Ph3		0x27
Ind_actual		0.600	0x27
	Current actual value	0.600	0x28
iq_error	Current actual value - command/actual val. error	0.600	0x38
	Current actual value - command/actual val. error	0-600	0x59
Idmin			0x02
			0x05
	Pus veltage	0.22767	UX48 Oveh
DC-R02	bus voltage	0-32707	0xeb
Va	Voltage		0x2a
vq	Voltage		0x29
vout	Output voltage		Ux8a

# 7.2 Table / measured value

Measured values			
Selected values	Function	Range	ID address
Vred	Voltage limitation		0x8b
pwm1 (5/6)	Pulse width modulation phase 1	750 +/-750	Охас
pwm2 (3/4)	Pulse width modulation phase 2	750 +/-750	Oxad
pwm3 (1/2)	Pulse width modulation phase 3	750 +/-750	0xae
T_Motor	Motor temperature	0-32767	0x49
T_IGBT	Output stage temperature	0-32767	0x4a
T_air	Air temperature (unit interior)	0-32767	0x4b
Ballast Count	Ballast power monitoring		0xa1
Temp-Debug	For service only		0x9a
Logic (Hz)	I/O processing frequency	0-32767	0xab
Time_1us	Time pulse 1us	1/0	0x98
*PTR1			0xb8
*PTR2			0xba
Unknown			

# 8 Conversion

### 8.1 Conversion of the measurement units

For position, speed, current, and command value

Some of the measured values are not converted in all formats. Numeric values (num) are indicated and processed. It must be differentiated between the values and their numeric representation when processing data such as in case of data transfers (CAN-BUS, RS232) or track and oscilloscope displays.

#### Position

Actual position range	Resolver	Incremental encoder
Pulses/rpm	65536	65536
Max. value +/-2147483647		
(31 Bit-1)		
Resolution (lowest value)	16 (65536/4096 (12Bit))	65536/Ink x4
Example	Travel 1000mm = 200 rpm	Incremental encoder 2048 pulses/rpm
Feed Drive	200 rpm = 13107200	Travel 1000mm = 200rpm
Factor 5mm/rpm	Resolution = 65536/4096 = 16	200 rpm = 1638400
		Resolution 65536/8192 = 8

### Speed

Actual speed range	Max. speed (Nmax) calibration	Limitation
Max. value +/- 32767 (15Bit-1)	Nmax value in the parameter field Motor and speed = 32767	Speed limiting via the parameter field 'speed limit'
Example	N max = 2000 Speed of 2000 rpm corresponds to 32767	The max. speed is limited to 1500 rpm. Limit = 32767/2000*1500 = 24575 num Die maximale Drehzahl ist auf 1500 Upm begrenzt

#### Current

	I 100 %	Rated current (I) calibration I-device			Peak cur DC disal	rent (I) bled	Limitation
Max. value +/- 9bit	mV	Num	Aeff	A=	Num	A=	
DS 205/405	550	440	5	7	640	10	
DS412	800	640	12	17	920	24	
DS420	700	560	20	28	800	40	
DS450	416	328	50	70	480	100	
DS475 / BAMO-D3	416	328	75	105	480	150	Limit set in the
BAMOBIL-D3-50/250	870	700	25/125	35/175	1020	50/250	parameter fields <i>Motor</i> and <i>Current</i>
BAMOBIL-D3-80	560	450	40	56	650	80	The smallest value is
BAMOBIL-D3-100	700	560	50	60	800	100	valid.
BAMOBIL-D3-120	840	670	60	84	970	120	
BAMOBIL-D3-350	610	490	175	245	710	350	
BAMOBIL-D3-450	785	630	225	315	910	450	
BAMOCAR-D3-250	625	700	125	176	1020	250	
BAMOCAR-D3-400	500	560	200	282	810	400	

#### **Command values**

Position command value range	Speed command value range	Current command	d value range	
Max. value +/-31Bit	Max. value +/-15 Bit	Max. value +/- 9	Bit	
+/- 2147483647 Num	+/- 32767 Num	DS 205/405	rated: 440	max: 640
		DS 412	rated: 640	max: 920
		DS 420	rated: 560	max: 800
		DS 450	rated: 328	max: 480
		DS 475/BAMO	rated: 328	max: 480

## 9 Errors

The error messages are displayed in the window 'Error'.

### 9.1 Error list

Display on the	Error message	Description
servo	on the NDrive	
	NOREPLY-NORS	RS232 failure.
		Incorrectly connected or missing connecting cable
0	BADPARAS	Defective parameter
1	POWER FAULT	Output stage fault
2	RFE FAULT	Faulty safety circuit (only active for RUN)
3	<b>BUS TIMEOUT</b>	Transfer fault BUS
4	FEEDBACK	Faulty encoder signal
5	POWERVOLTAGE	No power supply voltage
6	MOTORTEMP	Motor temperature too high
7	DEVICETEMP	Device temperature too high
8	OVERVOLTAGE	Overvoltage >1.8 x UN
9	I_PEAK	Over-current 300 %
А	RACEAWAY	Racing (no command value, incorrect polarity)
В	USER	User – error selection
С	I <sup>2</sup> R	Bleeder resistor
D	HW_FAIL	Firmware not compatible with hardware
E	ADC-INT	Current measuring fault
F (device dependent)	BALLAST	Ballast circuit overload
Flashing decimal po	pint	Active processor
Dark decimal point		No auxiliary voltage or unit-internal hardware fault

### LED displays on the servo

In case of an error the red LED 'fault' lights up and the error no. is indicated.

The BTB (ready) contact is opened.

The software ,BTB message' switches from 1 to 0. The state message ,RDY' extinguishes.

When the enable is switched off, the error message is still displayed.

The error message deleted:

When the enable is switched on, the function 'cancel errors' is activated via a digital input or a CAN BUS.

#### Note:

When applying the 24V auxiliary voltage with the enable closed (FRG/RUN X1:7 aktiv) the red LED signals an error. There is no fault signal displayed in the 7-segment display.





### 9.2 Warnings

Display of the warning messages. The warning messages are displayed in the window 'warnings'.

Display on the servo	Error message on the NDrive	Description	ID address
			REGID 0x8f
0	WARNING_0	Inconsistent device identification	Bit 16
1	ILLEGAL STATUS	Faulty RUN signal, EMI	Bit 17
2	WARNING_2	Inactive RFE signal (without RUN)	Bit 18
3			Bit 19
4			Bit 20
5	POWERVOLTAGE	Power voltage missing or too low	Bit 21
6	MOTORTEMP	Motor temperature > 87 %	Bit 22
7	DEVICETEMP	Device temperature > 87 %	Bit 23
8	OVERVOLTAGE	Overvoltage >1.5 x UN	Bit 24
9	I_PEAK	Over-current 200 %	Bit 25
А			Bit 26
В			Bit 27
С	I2R	Overload > 87 %	Bit 28
D			Bit 29
E			Bit 30
F	BALLAST (device dependent)	Ballast circuit overload > 87 %	Bit 31

### LED desplays on the servo

In case of warning state the red LED changes (lowfrequency) and the seven-segment display shows alternately the warning no. (red LED) and the operating state (LED dark).





### LED display on the servo

The operating state **"normal"** is signalled by a bright green seven-segment display + decimal point (display of the state).

The state **"fault"** is signalled by a bright red fault LED and the seven-segment display indicates the error no.

In case of a "warning" state the red LED changes and the segment display shows alternately the warning no. and the state.

Display	Point/segment	State	State of NDrive					
	flashing	Processor active						
□.	dark	Auxiliary voltage missing or inhere	nt hardware failure					
	flashing	Starting state after reset (aux. volta stops the flashing display.	Starting state after reset (aux. voltage 24V off-on). The first enable stops the flashing display.					
	bright	Drive enabled		OK = 1, ENA = 1 OK = 1, ENA = 0				
	dark	Drive disabled (not enabled)						
	bright	Speed zero (standstill signal)	NO = 1					
	bright	Drive revolves clockwise, N current	NO = 0					
	bright	Drive revolves anti-clockwise, N cu	NO = 0					
	flashing	Motor current reduced to continue						
	bright	Motor current at max. current limi	lcns = 1 lcns = 0 lcns = 0					
	dark	Normal operation; Motor current v	-					
	bright for 0.1s	Left segment:						
		Right segment:	Digital input changed.					

### Display of the servo-drive state

#### Example: Motor revolving clockwise

Point flashes	=	Processor active	
Bottom segment	=	Drive enabled	
Right segment	=	Motor revolves clockwise	

#### Ballast circuit

switching:

The direction segment (at the right or left bottom) is switched off when the ballast circuit is switched on.

### 9.3 States

State display

The operating states are displayed in the window 'state'.

### List of states

Display of the	Function	address
state		
		REGID 0x40
Ena	Drive enable (combination hardware RUN and Software)	Bit 0
NcR0	Speed limit to zero (Speed command still active)	Bit 1
Lim+	Limited switch Plus tripped	Bit 2
Lim-	Limited switch Minus tripped	Bit 3
ОК	Drive okay (no uncontrolled control-voltage reset seen)	Bit 4
lcns	Current is limited to the continuous current level	Bit 5
T-Nlim	Speed limited torque mode active	Bit 6
P-N	Position control possible	Bit 7
N-I	Speed control possible	Bit 8
<n0< td=""><td>Actual speed less than 0.1 %</td><td>Bit 9</td></n0<>	Actual speed less than 0.1 %	Bit 9
Rsw	Reference switch tripped	Bit 10
Cal0	Calibration move active	Bit 11
Cal	Calibration move completed (position calibrated)	Bit 12
Tol	Position within tolerance window	Bit 13
Rdy	Drive ready (BTB/RDY contact is closed)	Bit 14
Brk0	De-energized brake with motor active	Bit 15
SignMag	Speed internally inverted	Bit 16
Nclip	General speed limiting (if ≤ 90%) possible	Bit 17
Nclip+	Additional switchable positive speed limiting possible	Bit 18
Nclip-	Additional switchable negative speed limiting possible	Bit 19
Ird-Dig	Current limiting (switchable) reached	Bit 20
luse-rchd	Actual current limit reached	Bit 21
lrd-N	Current limiting (speed)	Bit 22
Ird-TI	Current derating (power-stage temperature) possible	Bit 23
Ird-TIR	Current reduced to continuous current (power-stage temperature)	Bit 24
>10 Hz	Additional current limit if frequency less than 10 Hz	Bit 25
Ird-TM	Current limiting due to motor temperature reached	Bit 26
Ird-ANA	Current derating due to analog input (if ≤90 %) possible	Bit 27
lwcns	Current peak value warning	Bit 28
RFE pulse	Pulsed RFE –input monitoring active	Bit 29
M+D	vacant	Bit 30
HndWhl	Hand-wheel function selected	Bit 31

Status	Status
🔵 Ena	SignMag
NcR0	Nclip
Lim+	Nclip+
🔵 Lim -	🔘 Nclip -
Ок	Ird-Dig
Icns	Iuse-rchd
T-Nlim	Ird-N
P-N	Ird-TI
N-I	Ird-TIR
NO	>10Hz
Rsw	Ird-TM
Calo	🔘 Ird-Ana
Cal	Iwcns
Tol	RFEpulse
Rdy	M+D
Brk0	HndWhl

### 9.4 Display of inputs and outputs

The LEDs are bright when the positive input voltage is superior to >10 V and the output voltage is positive

Short symbol	Function	ID-Ad.	-In-Out-
		REGID 0xd8	
LMT 1	Digital input limit 1 active	Bit 0	
LMT 2	Digital input limit 2 active	Bit 1	
IN 2	Digital input Din 2 active	Bit 2	O IN1
IN 1	Digital input Din 1 active	Bit 3	O PLIN
FRG (RUN)	Hardware enable active	Bit 4	OREE
RFE	Rotating field enable	Bit 5	
		Bit 6	
		Bit 7	OUT1
OUT 1	Digital output Dout 1 on	Bit 8	
OUT2	Digital output Dout 2 on	Bit 9	
BTB (Rdy)	Hardware relay, output BTB (Rdy) on	Bit 10	
GO	Internal enable GO active	Bit 11	
OUT 3	Digital output Dout 3 on	Bit 12	
OUT 4	Digital output Dout 4 on	Bit 13	
G-OFF		Bit 14	
BRK1	Excited brake	Bit 15	U DKKI

### Display of speed and current

Speed in rpm (revolutions per minute) and as numerical value from the parameter 0xa8

Current in Aeff (motor current in ampere effective / rms) and as numerical value from the parameter 0x5f



# 10 Enable

## 10.1 Hardware - Enable FRG/RUN

### Switching on

Voltage across the enable input (X1:7, X1:G FRG/RUN) > 10 V= , <30 V=

The power stage of the drive is immediately enabled when the drive enable is switched on. The software control of the power stage is activated 2ms later. Commands such as command values, reference travel, etc. can be sent 5ms after the drive enable (RUN).

The enable state is indicated in the state field with '*Ena*'.

## Switching off

Voltage across the enable input (X1:7, X1:G FRG/RUN) < 4 V= When the enable function is switched off, the drive is electronically disabled.

### Switching off with emergency stop (free coasting Off)

The drive decelerates to standstill before it is enabled.

When the enable function is switched off, the internal speed command value *N cmd Ramp* is reduced to zero by means of the *ramp limit* which has been adjusted in the parameter field *speed*. The power section is disabled by means of the internal command *GO* 50ms after the axis has come to a standstill or after the ramp time (*ramp limit*) + 50ms has elapsed.



The power stage is disabled after 1.5 s at the latest.

### Switching off without emergency stop (free coasting On)

The power section is immediately disabled when the enable function is switched off. The drive decelerates free of torque.



### Enable and disable function via interfaces (CAN BUS, RS232)

The hardware enable (FRG/RUN) and the safety input must be switched on!

#### Enable

By means of the command '**Not ENABLE OFF'** (MODE-BIT 0x51 Bit2=0) the amplifier is enabled without delay.

#### Disable

By means of the command 'ENABLE OFF' (MODE-BIT 0x51 Bit2=1) the internal speed command value N cmd (ramp) is controlled to zero according to the ramp R-Lim adjusted in the parameter field 'speed'.

Set **R-Lim** in such a way that the drive is braked to a standstill.

50ms after the switch-off ramp time (ramp limit) has elapsed, the power section is disabled. The drive is torque-free.

#### Software enable of the NDrive

The hardware enable (FRG/RUN) must be switched on!

Drehzahl 💌		Dis	
500	+	0	-
Position		1. 1.	10
0	Dest	Ρ.	Calib

Switching field Dis grey = Software enable = ON red = Software enable = OFF



### 10.2 Safety

### Safety input RFE (Rotating field enable) Warning:

If the input of the enable or of the rotating field (FRG/RUN) enable are switched off, the drive is free (RFE) of torque. The drive could move if there is no mechanical brake or block provided.

The motor conductors are **not dead**. Only the rotating field is disabled. Prior to any work or maintenance on the motor or servo-drive, the servo-drive must be completely disconnected from the mains power supply.



#### Operation with an RFE input

Two-channel disable of the enable via a safety switching device. Enable input FRG/RUN + Rotating field enable input RFE.

#### Switching-on

Contacts of the safety device closed, enable FRG/RUN 0.5s after RFE.

#### Safety switch-off

Contacts of the safety device open:

- there is no FRG/RUN signal in the 1<sup>st</sup> disable channel to disable the PWM pulses in the processor
- -there is no RFE signal in the 2<sup>nd</sup> disable channel to disable the PWM pulses at the output of the processor

#### Restart

Release the safety switching device. Contacts of the safety device closed. The motor can only move after a second disable FRG/RUN (after the rotating field enable).





### **Operation without RFE input**

The input RFE must be bridged with the logic voltage.

If the logic voltage corresponds to the supply voltage, the RFE input is bridged with +24 V.

Enable FRG/RUN at least 0.5 s after the RFE signal.

#### Note:

In case of circular and Tyco connectors (BAMOCAR,BAMOBIL) use the plug no. of the device MANUAL.



### 10.3 Settings

#### Parameters and data input

	Einstellungen	Drehzahl	Position	Logik	Bus	Ozilloskop	Monitor	Diagnose	Auto	Extra					
Motor		·	Servo				Param	eter							
Туре	EC-Servo	-	Type	DS	405		- Strom	-		Drehzal	hl —		Position		
Nnom	3000 F	RPM	S-Nr.	12	3456		Кр	40		Кр	10		Кр	100	
Fnom	500,0 H	iz	Achse	ko			Ti	800	μs	Ti	6	ms			
Unom	0	r -	Netz wahl	4	C DC		TiM	85	96	Td	0	ms	Ti	300	ms
cos Phi	0,00		Netz	40	0	v	xKp2	0	96	TiM	20	96	Td	500	ms
I max eff	5,0 A	• •	DC-BUS ma	0 xe		96	Kf	0		Kacc	0	96	TiM	80	96
I nom eff	3,0 4	· ·	DC-BUS mi	n 0		96	Ramp	150	US	Filter	2	Num	Pos-Refe	erence	
M-Pole	6		ZW-monite	or D	IG AN	A	I max pk	100	96	Rcw Acc	25	ms	Speed to	0	RPM
Richtung	CW CCW		Ballast	1	VT EXT		I max pk	10,6	Α	Rcw Dec	10	ms	Speed from	100	RPM
Bremse	ON OFF		Ballast-P	25		W				Rccw Acc	50	ms	Reso Edge	0	Num
Bremse ver	rzug 250 n	ns	Ballast-R	80		Ohm	I con eff	70	96	Rccw Dec	50	ms			
freier Ausla	auf ON OFF		BTB Power	n	nit ohn	e	I con eff	3,5	Α						
M-Temp	7000	lum					T-peak	5	s	R-Lim	5000	ms	Ref-Ramp	DEC LIM	
			Taktfreq.	8	Hz	-							Pos-Para	meter	
						_	I-lim-dig	100	96				Tol-wind	100	
Geber			Analog out	Na	actual	-	I-red-N	100	96	Nmax-100	3000	RPM	Off. Ref.	0	
RES	OLVER	-				_	I-red-TD	32767	Num	N-lim	100	96	ND-Scale	0	
			Comma	and	-		I-red-TE	32767	Num	N-Lim+	0	96			
FB-Pole	2		Mode Dig	ital Spee	ed	-	I-red-TM	5600	Num	N-lim-	0	96			
FB-Offset	-58	Deg				_									
FB-Inkr. (Me	ot) 2048 I	nc/Rev	Cutoff (dig	.)	0		— FU-Sta	rt		- FU-Stop			- Option		
							T-DC	0	ms	T-DC	0	ms			
2. Feedbac	k			Ain 1	Ain	2	U-DC	0,0	96	U-DC	0,0	96			
Off	8	-	Format Cr	nd 🔻	+Cmc	1 <b>v</b>	Umin	0,0	96	Umin	0,0	96			
1		_	·			_	Fmin	0,0	Hz	Fmin	0,0	Hz			
Inc-ext	0	nc/Rev	Offset 0		0		Ueck	0,0	96	U eck	0,0	96			
Faktor-ext	0 1	lum.	Nullzor 1		0		Feck	0,0	Hz	Feck	0,0	Hz			
Inc - Out			Scale -7	,000	1,000	0									
Inc-Out	0	nc/Rev					Current	linear	-	Current I	linear	-			
Faktor	4	-		Paramet	er-Step										
		_	Mode -1	0+ 🔻	-10	+ 🔻									
					,		Display	RAN	//<->PC		RAM	<->EEPRO	M		
														3	-
												Ψ.		<b></b>	Ψ

Input fields for motor data, device data (servo) and parameter data. Buttons for the saving functions.

The adjustments for the motor and the servo amplifier can only be made via the setting window. The parameter data can be entered via this and several other windows. The changed parameter data are immediately updated on all pages.

When a value has been changed, the new value is automatically updated on all windows. See the detailed information for the input fields.

#### Note:

Prior to the first commissioning and any change of the motor type the data displayed in the setting windows must be checked with the type plate or the data sheet of the motor.

Please observe the motor specific connection guidelines!

Any changes of the set value during online operation must only be carried out by competent and qualified personnel.



# 10.4 Motor setting

Setting window for the rated motor data

Motor settin	ng parameters				
Short symbol	Function	Setting range	Unit	Note	ID address
Туре	Select motor type				
Nnom	Rated motor speed	Type plate (600-50000)	rpm		0x59
Fnom	Rated motor frequency	20 bis 1200	Hz		0x05
Unom	Rated motor voltage	Type plate	V		0x06
Uphi	Motor power factor	Type plate	%		0x0e
I max eff	max. motor current(I)	Type plate	А		0x4d
I nom eff	Continuous motor current(I)	Type plate	А		0x4e
M- Pole	No. of motor poles	248	Num		0x4f
Direction	Select rotation direction	Switching field	Selection		0x5a-Bit8
Brake	Select with/without brake	Switching field	Selection		0x5a-Bit18
Brake Delay	Response time motor brake	0500	ms		0xf1
Free coasting	Selection	Switching field			0x5a-Bit3
M-Temp	Switching point motor temperature	0 to 32767	Num		0xa3
Encoder	Selection of encoder system		Selection		
2. Feedback	Selection 2. encoder system		Selection		
Inc-Out	Output counter increment				

Mator	Motor type selection	Motor type
N nom 3000 RPM F nom 500,0 Hz U nom 0 V	EC-Servo	Synchronous servo motor with encoder system (sensor)
U phi 0,00 Num I max eff 5,0 A I nom eff 5,0 A M-Pole 6	FU	Asynchronous motor frequency converter without sensor
	FU-Servo	Asynchronous motor AC servo vector control with speed encoder system (e.g. position encoder A,B channel)
	DC	DC motor without or with DC tacho encoder

Geber	Motor type selection	Feedback	
ROTENC_TTL FE RESOLVER CHABSENC SC Deg	EC-Servo	Feedback selection	
In ROT_TACHO Inc/F ROT	FU	without feedback	
- 2.F DC_TACHO DC_ARM BL ARM	FU-Servo	Feedback selection	
ENC_TTL In ENC_SC Inc/R	DC	without feedback	
Fa DC_ARM_VIR		or	
In SLS_SMO Inc/F Fa SLS_Usens		DC tacho	
Anain1_caic Anain2_caic PANASONIC			

#### Setting window for the rated motor data Check type plate, data sheet, and connection specifications! Motor

Туре	Motor type selection (EC-Servo, FU , FU-Servo, DC)
N nom	Motor speed (type plate)
	Is used as calculation value for FU autotuning
Fnom	Frequency at which the rated motor speed is reached.
	Only for frequency converter mode.
	(Type plate or motor data sheet)
U nom	Voltage for the rated motor speed
	Only for frequency converter mode.
	(Type plate or motor data sheet)
U phi	Motor power factor
	Only for frequency converter mode.
	(Type plate or motor data sheet)
I max eff	Max. permissible motor current
	(Type plate or motor data sheet)
I nom eff	Permissible rated continuous motor current
	(Type plate or motor data sheet)
M-Pole	No. of motor poles (2 x pole pairs)
Direction	Global change of the rotation direction.
	The command value, the actual value, and the counting direction are
	changed.
	CW clockwise rotation, CCW counter-clockwise rotation
Brake	Motor selection with/without (ON/OFF) brake.
	When it is set to 'without' (OFF) the switch-off delay (braking delay) is
	out of function.
Brake delay	Attraction delay time of the electro-mechanical brake
	Deceleration when no brake is connected
Free coasting	Free coasting (UN) or emergency stop braking (UFF) when the enable
M Tomp	(FRG/RON) is switched on
Wi-remp	Therewill be a warning message 6 ( $0x8fBit21$ ) at 87 %
	MOTORTEMP > 87 %
	At 100 % (set value) the drive is switched off.
	Error message 6 (0x8f Bit6) MOTORTEMP
Note:	
The parameters	Imax and Inom are also written into the parameter field ' current'.
The smaller val	ue serves as limit.
Encoder	
Encoder	Encoder system selection
	(TTL incremental encoder, resolver, SIN/COS, DC tacho, etc.)
2nd Feedback	2 <sup>nd</sup> feedback selection
	INC-IN, INC-OUT, HAND, SSI
Inc-Out	Setting of the output incremental signals





# 10.5 Setting window for the feedback encoder

RESOLVER	•	RESOLVER
ROTENC_TTL		
RESOLVER		FB-Pole Z
O ABSENC_SC	Deg	Offset -60 Deg
In ROT_TACHO ROT	Inc/F	Inc-Mot 2048 Inc/R
DC_TACHO		- 2. Feedback
DC_ARM		Litecobuck
BL_ARM ENC_TTL		Off
In ENC_SC	Inc/F	Inc-ext 0 Inc/R
ABS_SC	Num	Existence with a Num
DC_ARM_VIR		Faktor-ext 0
SLS		Inc - Out
In SLS_SMO	Inc/F	Inc-Out 0 Inc/R
FaSLS_Usens		Faktor
Anain1_calc		
Anain2_calc		
PANASONIC		L

RESOLVER- Encoder 10 kHz 2 Vpp			
RESOLVER			
F-Pole	No. of encoder poles 2 to 12		
Offset1	Correction value for the mechanical encoder setting.		
	Polar wheel angle 0 to 360 degree		
	Automatic detection of the offset angle = see page AUTO		

Incremental encoder 5 V TTL			
ROTENC_TTL	Incremental encoder TTL with rotor position tracks		
Offset	Correction value for the mechanical encoder setting		
	Automatic detection of the offset angle = see page AUTO		
Inc. Mot	No. of pulses per revolution		
Note:	The no. of poles of the rotor position encoder must correspond to the no. of		
	motor poles!		
ENC-TTL	Incremental encoder TTL without rotor position tracks		
Inc. Mot	No. of pulses per revolution		
	Only for asynchronous motors or special drives		

SINUS/COSINUS encoder 1 Vss			
ABSENC_SC	1 Vss-Sin/Cos encoder with Sin/Cos-commutation tracks		
Offset	Correction value for the mechanical encoder setting		
Inc. Mot	No. of pulses per revolution		
ENC_SC	1 Vss-Sin/Cos encoder without commutation track		
Inc. Mot	No. of pulses per revolution		
ABS_SC	Sinus-Cosinus signal per motor pole pair (analog Hall sensors)		
M-Pole, FG-	No. of motor poles is equal to the no. of encoder poles		
Pole			

### 10.6 Setting window for the feedback encoder

ROTOR POSITI	ROTOR POSITION ENCODER 5 V, 15 V				
ROT_TACHO	Rotor position encoder with bl-tacho (DC tacho)				
Offset	Correction value for the mechanical encoder setting.				
ROT	Rotor position encoder without bl-tacho, only rotor signals				
Offset	Correction value for the mechanical encoder setting.				
BL-ARM	EC/AC motor without tacho				
Note	The no. of poles of the rotor position encoder must correspond to the no. of				
	motor poles!				

Feedback for DC motors			
DC_TACHO	DC motor with tacho		
Offset	120 = connection M1-M3 (0=M2-M3, -120=M1-M2)		
DC-ARM	DC motor with armature voltage sensor (without tacho)		
Offset	120 = M1-M3 (0=M2-M3, -120=M1-M2)		
DC_ARM_VIR	Sensorless DC motor without tacho, without armature voltage measuring		
Offset	120 = connection M1-M3 (0=M2-M3, -120=M1-M2)		

Sensorless drives		
SLS	Sensorless AC motor without feedback encoder	
	no setting	
SLS_SMO	not yet available	
SLS_Usens	not yet available	

Parameter overview of encoder settings					
Short	Function	Setting Units Notes		ID address	
symbol		range			
FB-Pole	No. of encoder poles	212	num		0xa7
Offset	Phase angle correction	0 +/- 360	degree		0x44
Inc-Mot	Encoder resolution	10248192	pulse/rev.	only binary	0xa6
Voltage	DC tacho voltage		mV/RPM		
Inc-ext	Resolution of 2nd encoder		pulse/rev.		0xcfL
Factor	Multiplicator SIN/COS inc.	416	num		0x7e

In case of changing the feedback parameters it is necessary to reset the parameter.

Write the parameter set into the EEPROM (EEPROM<->RAM ) and re-read it.





read

write

### 10.7 Setting X8 as second counter input

#### Selection fot the 2<sup>nd</sup> counter input (2nd feedback)+

input switched off
connected as input
connected as output
Handwheel input
SSI encoder input

#### INC-IN Setting X8 as input for incremental encoder signals

Incremental encoder TTL 5 V A,B,N +push-pull Bridge between X8:1 and X8:6 (X8 switched as input) Scale (Factor-ext.): Calculate the transmission 1 motor revolution = 65536 num (internal counter) Faktor-ext for the adaption of the 2nd encoder (0x7e) Encoder\_2\_Scale = 65536 / encoder pulses per motor revolution \*4 from the 2<sup>nd</sup> encoder

Input at factor-ext. (0x7e) = Encoder\_2\_Scale \* 16384

#### Example:

1 Motor revolution corresponds to 0.1 encoder revolutions No. of encoder pulses 1000/rpm Pulses per motor revolution 0,1\*1000\*4 = 400

**Input** at encoder\_2\_Scale = 65536 / 400 = **163,840** 

Input factor-ext. (0x7e) = 163,840 \* 16384 = 2684354

#### Setting X8 as output for incremental encoder signals

The encoder signals from the motor (feedback) are output across the D-connector X8 as TTL encoder signals for the CNC control.

Signals: channel A, channel /A, channel B, channel /B, Kanal N, channel /N

The encoder output is floating. The voltage is supplied through the encoder cable of the CNC/PLC control. Voltage supply +5 V  $\pm$ 0.2 V The output signal corresponds to RS485.

**Option:** Internal supply from the servo (LBR1+ LBR2)

#### **Resolution:**

For the -RS and -SC versions the resolution can be programmed. For -IN the output corresponds to the no. of encoder pulses. Factor Multiplication factor for the basic no. of pulses for SinCos (SC)

Inc-Out Setting value for the no. of pulses for resolver

Pulses per revolution	Resolution	Parameter
256	10 Bit	
1024	12 Bit	
4096	14 Bit	







### 10.8 Brake setting



#### Brake setting

The max. braking power of the motor is applied when the power has been switched off.

According to the electrical brake control the **brake delay** (switching on/switching off) corresponds to the respective type. (Brake delay)

A brake up to 24 V, 1 A can directly be switched by the digital output.

For braking processes with higher current or voltage values a relay must be inserted.

The brake output is activated on the page *logic* in the parameter field *output*.

Click the command **O-Break** in the drop-down menu at **Dout 1**, **Dout 2** or **Dout3** to transfer it to the display field.

Tranfer the operand = (equal) or  $\mathbf{I}$  = (not equal) in the dropdown menu by clicking it.

The switching function of the output can be selected by entering **0** or **1** into the parameter field (standard: 0)

Enter the switch-off delay of the motor brake in the parameter field  $\rightarrow$  *brake delay* (0 to 500 ms) of the input field  $\rightarrow$  *motor*.

When the brake is active, the state is displayed **BRK1** in the input field **state**.

**Note:** Connect a recovery diode or a varistor directly to the brake connection at the motor.

Example Digital outputs Dout1	Selection not used	OUTPUT Dout1 Dout2	Off	•	Off Off	•	0	• •
Dout2 Dout3 Dout4	not used The brake is disconnected from the power supply when the enable is switched off. Set the switch-off delay via the brake delay. not used	Dout4 Var1 Var2 Var3 Var4	I Fault I Regen Imax inuse I LossOfSignal O GO O Brake VO Icns O Less NO O Toler Rotor		Ott	0x000 0x000 0x000 0x000	0 000000 00000 00020 01000	<u> </u>

#### Brake output on the logic side

#### **Brake function**

When the drive enable is switched off or the CAN command **ENABLE OFF** is received, the internal speed command value **N** cmd Ramp will be ramped down to zero at a rate defined by **Ramp**-Limit. After a fixed delay time of 50 ms, the **Brake** parameter will switch from 1 to 0. The braking power rises. After the programmed time **Brake** delay has passed, the internal parameter **GO** is switched to 0 and the servo is disabled (no torque applied).

#### Brake release function

If the brake is active and drive enable is switched on, the command value is maintained at 0 and **GO** switches immediately to 1.

After 50 % of the delay time (**brake-delay**) has passed, the brake is switched off, and after the complete delay time has passed, the command value will increase at a rate defined by *Ramp-Acc*.



#### Note:

The sum of the times *R-Lim* plus *brake delay* must be inferior to 1s.

When the enable is switched-off at 1.1s the hardware of the output stage is disabled. The electric braking is interrupted and the drive decelerates freely. When the *R-Lim* plus *brake delay* time is too long and has elapsed, the mechanical brake is triggered and stops the drive. der zu langen Zeit von *R-Lim* plus *Bremse verzug* 

### 10.9 Ballast circuit setting

For the units with a bus circuit setting (ZW monitor digital) *DIG* the ballast circuit is directly controlled from the hardware.

With the bus circuit setting (ZW monitor analog) **ANA** the ballast circuit is controlled from the TMS control board.

With an internal ballast resistance the setting parameters of the unit detection is automatically adjusted.

With an external ballast resistance the values for the resistance (ballast R) and the resistance power (ballast P) are entered as parameters.

Ballast	INT = internal ballast resistor EXT = external ballast resistor
Ballast-P	Enter the resistor power in W
Ballast-R	Enter the resistor power in Ohm



With an internal ballast resistance the ballast power is calculated from the data of the device type.

With an external ballast reistance the ballast power is calculated from the entered values of **Ballast-P** and **Ballast-R**.

The ballast power is displayed as **Ballast-Leistung** (0x45L) on the monitor side.

The dc bus voltage (DC-BUS dir), the ballast switching pulse (I-Regen, IBallast), and the ballast power (Ballast counter) can be shown on the oscilloscope. Selection by means of the drop-down menu.

There will be a warning at 87% of the ballast power (ballast circuit >87 % overloaded 0x8f Bit 31) and at 100 % the device will be switched off and an error message is displayed (ballast circuit overloaded 0x8f Bit15).

The function of the ballast circuit is displayed on the servo. The command value directional bar of the 7-segment display (below left or right) is switched off as long as the ballast circuit is active.
# 10.10 Motor temperature setting

## Motor temperature watchdog

Parameter motor temperature current reduction

#### I-red-TM 0xa2

Set I-red-TM only with linear temperature sensor!

Starting from the trigger point of the motor temperature (I-red-TM 0xa2) the max. current limit is linearly reduced to continuous current until the switch-off point (M-TEMP 0xa3).

Presetting 0xa2 = 5600

Warning *I-MOTORTEMP* when the set value is exceeded.

T-peak	5	s
I-lim-dig	100	%
I-red-N	100	96
I-red-TD	32767	Num
I-red-TE	32767	Num
I-red-TM	5600	Num

5

Parameter motor temperature fault switch-off
M-TEMP 0xa3
Presetting 0xa3 = 7000
Warning message at 87 % of the set M-Temp value.
Warning 6 MOTORTEMP >87 %
When the set value is exceeded, there will be the error
message 6 (MOTORTEMP)



#### Setting with non-linear temperature sensor (PTC resistor) M-TEMP 0xa3

only motor temperature fault switch-off Note: Temperature reduction is not possible



## Example:

Error message and switch-off at 140 °C Setting M-Temp (0xa3) 4302 Num For multiple, series connected sensors the set value is increased.

# Motor temperature watchdog

Parameter overview of the motor temperature						
Short	Function Setting Units Notes ID address					
symbol		range				
I-red-TM	Triggering point current reduction Warning 0x8f-Bit 22 MOTORTEMP Motor temperatuer >87 %	032000	num	Setting parameter	0xa2	
M-Temp	Switch-off point, error message 0x8f-Bit6 MOTORTEMP Motor temperature >100 %	032000	num	Setting parameter	0xa3	
T-motor	Current motor temperature	032000	num	Display parameter	0x49	

## Motor temperature watchdog

Parameter motor temperatuer c	urrent reduction	l-red-TM	0xa2
Parameter motor temperature fa	ault switch-off	M-TEMP	0xa3

# Setting with linear sensor type KTY84



## Example:

Warning and current reduction from 100 °C	Setting I-Red-TM	(0xa2)	5748num
Error message and switch-off at 140 °C	Setting M-Temp	(0xa3)	6935num

# Setting with linear sensor type PT100

## Note:

Inaccurate temperature measuring due to a flat characteristic curve and internal measuring tolerances.

An exact temperature measuring is only possible using a ballast measuring amplifier.



## Example:

Warning and current reduction from 100 °C Error message and switch-off at 140 °C Setting I-Red-TM (0xa2) Setting M-Temp (0xa3) 937num 1036num

# 10.11 Setting of the power connection/bus circuit

AC~, DC=Selection ac or dc voltageMains powerRating of the voltage supply in Vsupply

## Limit of the bus circuit voltage

(Take the setting values of the hardware manual (bus circuit voltage 0xeb)

DC-BUS	Max. voltage limit (software).
max	200 % correspond to 32767 num = 2x rated voltage.
	Setting value for the ballast circuit and over-voltage watchdog.
	Warning at 1.5 times rated voltage
	OVERVOLTAGE 0x8f-24
	Error message in case of over-voltage
	OVERVOLTAGE 0x8f-8, the controller is disabled.
	The hardware voltage watchdog works
	independently from the software setting.

DC-BUSMinimum voltage limit (software).min200% correspond to 32767 num<br/>Below the min. voltage limit the controller is<br/>disabled. In case of undervoltage the controller is<br/>disabled and the error message 'undervoltage'<br/>(power voltage) 0x8f-Bit5 is displayed.



#### Setting values of the hardware manual Example: MANUAL BAMOCAR



# 10.12 Output stage temperature

For units with an analog recording of the output stage temperature the software watchdog can be programmed. (Take the setting values of the hardware manual (bus circuit voltage 0xeb).

- I-red-TD Setting value for the starting point of the current limit reduction depending on the output stage temperature.
- I-red-TE Max. temperature limit (software). At 85% of the max. output stage temperature a warning message DEVICETEMP 0x8f-23 is displayed. When the max. output stage temperature is reached, the controller is disabled and the error message overtemperature 0x8f-7 is displayed.

The output stage temperature watchdog of the hardware works independantly of the software setting.

- Strom		_
Кр	40	
Ti	800	μs
TiM	85	96
xKp2	0	96
Kf	0	
Ramp	150	US
I max pk	10	96
l max pk	1,1	A
l con eff	100	96
l con eff	5,0	Α
T-peak	5	5
I-lim-dig	100	96
I-red-N	100	96
I-red-TD	32767	Num
I-red-TE	32767	Num
I-red-TM	5600	Num

Setting values of the hardware manual **Example: MANUAL BAMOCAR** 



Temperatur-IGBT-Bamocar



Temperatur – Luft - Bamocar

# 10.13 Setting field for rated servo data

Servo setting parameters						
Short	Function	Setting range	Units	Note	ID address	
symbol						
Туре	Unit type	Type plate	Alpha-num		0x63	
S-Nr.	Serial unit no.	Type plate	Alpha-num		0x62	
Axis	Unit position identification	2 letters	Alpha-num		0xf8	
Mains sel	Selection ac/dc voltage	Selection			0x5a-19	
Mains	Power supply voltage	up to 480~, up to 560=	V		0x64	
DC BUS max	Max. bus circuit voltage		num		0xa5 H	
DC BUS min	Min. bus circuit voltage		num		0xa5 L	
ZW monitor	Selection bus circuit	analog-digital			0x5a-Bit 7	
Ballast	Selection ballast resistance	internal external			0x5a-Bit 1	
Ballast-P	Ballast resistance power	Type plate	W		0x65-L	
Ballast-R	Resistance value	5 to 100	Ohm		0x65-H	
BTB/RDY	Selection field BTB	with/without bus circuit voltage			0x5a-Bit 6	
Clock	Drop down menu	Selection			0x5y Bit 20-22	
frequency						
Analog out	Drop down menu	Selection				
		Selection				
Command	Selection field command values	analog digital			0x36 Bit 12-13	

#### Setting field for rated servo data

Type	DS 405
S-Nr.	123456
Achse	ko
Netz wahl	AC DC
Netz	400 V
DC-BUS max	0 %
DC-BUS min	0 %
ZW-monitor	DIG ANA
Ballast	INT EXT
Ballast-P	25 W
Ballast-R	80 Ohm
BTB Power	mit ohne
Taktfreq.	8 kHz
Analogout	Mactual
Analogout	N actual 💌
Analog out	N actual 💌
Analog out Command Mode Digital	Nactual
Analog out Command Mode Digital Cutoff (	N actual V Speed V (dig.) 0
Analog out Command Mode Digital Cutoff Format Cmd	N actual Speed (dig.) 1 Ain 2 +Cmd V
Analog out Command Mode Digital Cutoff ( Format Cmd Offset 0	N actual
Analog out Command Mode Digital Cutoff Format Cmd Offset 0 Nullzon 1000	N actual Speed (dig.) 0 1 Ain 2 +Cmd 0 0
Analog out Command Mode Digital Cutoff ( Format Cmd Offset 0 Nullzon 1000 Scale 1,000	N actual         Image: Constraint of the second secon
Analog out Command Mode Digital Cutoff ( Format Cmd Offset 0 Nullzon 1000 Scale 1,004	N actual         Image: Constraint of the second secon

Туре	The controller type is displayed (changes can only be made in the factory)
S-Nr.	Serial no. is displayed (factory-set)
Achse	Axis specification 2 digits correspond to the circuit diagram of the installation (entered by the user)
Main sel.	Power supply voltage AC~/DC= is displayed (factory-set)
Mains	AC and three-phase current voltage AC (30~ to 480 V~)
	Battery voltage or dc mains (12 V= to 560 V=)
DC-Bus max.	Switching point bus circuit overvoltage
	Error OVERVOLTAGE (overvoltage >1.8 U <sub>N</sub> ) 0x8f Bit 8
DC-Bus min.	Switching point bus circuit under-voltage
	Error POWERVOLTAGE (missing power voltage) 0x8f Bit5
ZW monitor	Selection bus circuit watchdog digital-analog (factory-set)
Ballast	Selection list ballast resistance (internal – external)
Ballast-P	Enter the power value for an external ballast resistor. Input in Watt.
	In case of a ballast resistor overload a warning message is displayed.
	Warning BALLAST (ballast circuit <87 %) 0x8f
	Bit 31
Ballast-R	Enter the resistance value for an external ballast resistor. Input in Ohm. Check the min. value.
BTB-Power	BTB-Message with or without bus circuit under-voltage.
	Selection w-out (without) (BTB without under-voltage watchdog)
	BTB without under-voltage watchdog.
	When the enableand the power supply voltage are switched off the
	RUN/BTB message remains active.
	Selection with (with) (BTB with under-voltage watchdog) BTB with under-voltage watchdog.
	When the enableand the power supply voltage are switched off the RUN/BTB is deactivated.

# 10.14 Setting field for rated servo data

## **Clock frequenz**

Selection of the switching frequency of the output stage Parameter 0x5a Bit 20-22 Presetting 8 kHz Selection via the drop-down menu

Selection : Pulse frequency with constant calculation speed Values: 8, 12, 16, 20, 24 kHz

Current limits reduced at pulse frequency:

100 % 2 to 8kHz 12kHz 85 % 16kHz..... 70 % ab 20kHz 20 %

Selection: Pulse frequency (kHz) with a higher calculation speed (Ix). Values: 2 kHz-I4, 4 kHz-I8, 8 kHz-I16

At the pulse frequencies 2 an 4kHz the continuous performance increases.

## Modification of the pulse frequency

Select frequency Save the parameter set in the EEPROM on level 0 Read the parameter set from the EEPROM level 0 The changed frequency is transferred and the current limits are reduced.

#### Analog out

Selection of analog outputs Selection via the drop-down menu

# **Analog signals**

The output voltage +/- 10 V corresponds to +/- 100 % of the selected signal.

## **Digital signals**

Selected digital signals provide 0 or +10 V.





# 10.15 Command value setting

#### **Analog inputs**

Click the  $\rightarrow$  **button** to open the drop-down menu. Select the command value to be adjusted. The selected function is highlighted in blue and it is transferred into the display by clicking it. Cmd Mode **ID** address **Digital Speed** Digital speed command value CAN-BUS, RS232, step 0x36-12,13 =0 oscilloscope Analog speed command value 0x36-12,13 =2 **Analog Speed** Analog Torque Analog torque command value, voltage +/-10V 0x36-12,13=3 across the analog inputs AIN1 and AIN2 Digi+Ana Speed 0x36-12,13=1 Digital and analog command values are added

#### Analog Speed

Analog speed command value. Input via terminal strip X1. Inputs Ain1 and Ain2 Max. input voltage ±11 V corresponds to ±32767 num

#### Analog Torque

Analog current command value. Input via terminal strip X1. Inputs Ain1 and Ain2 Max. input voltage ±11 V corresponds to ±32767 num This value corresponds to 200 % of the rated current

# Reversal of the rotation direction for a unipolar command value with direction signal

The unipolar command value is reversed by means of the direction command (*N cmd Reverse*) via the programmed digital input. The input must be adjusted to *N cmd Reverse* in the parameter field 'input/output.

#### Standstill with an analog command value for the speed and torque

Activate Speed Ramp 0 via a digital input or send it via the CAN BUS.

#### Format

The analog inputs Ain1 and Ain2 are assigned to a function via the format field.

Format Ain1		ID address
Off	switched off	0x36 Bit0-1 =0
Cmd	Speed command value	0x36 Bit0-1=1
-Cmd	reversed speed command value	0x36 Bit0-1=2
sq (Cmd)	quadratical speed command value	0x36 Bit0-1 = 3
N limit	Speed limiting 0-100%	0.36 Bit15
	for a digital speed and position control	
	(CmdMode = digital)	

Format Ain2		ID address
Off	switched off	0x36 Bit2-3=0
Cmd	Speed command value is added to Ain1	0x36 Bit2-3 =1
-Cmd	Speed command value is subtracted from Ain1	0x36 bit2-3=2
*Cmd	Speed command value is multiplied with Ain1	0x36 Bit2-3=3
l limit	external current limiting 0-200%	0x36 Bit14
	(for CmdMode = digital, analog speed or	
	analog torque)	

Version 2017 / V1

Mode	Digital Spee	ed	-
c	Cutoff (dig.)	0	
Format	Ain 1 Cmd 💌	Air +Cm	d ▼
Offset	0	0	
Nullzon	1000	0	





	Ain 1	Ain 2
Format	Cmd 🔻	+Cmd 💌
		Off
Offset	0	+Cmd
Nullzon	1000	-Cmd
Scale	1,000	*Cmd I limit
	Paramete	er-Step
Mode	-10+ 🔻	-10+ 🔻

## Offset

Compensation of the command value zero error the the input is analog. With the command value OV alter the offset value such that the parameter **Ncmd Ramp** is zero.

## Zero zone

At an analog command value it is possible, by means of the parameter zero zone, to set a range in which the speed is kept at standstill. (Digital capture, 327 corresponds to 1 % of the speed)

## Zero zone at speed command value

The command value is switched to zero within this zone. The drive is at a standstill, no drift (no position parameter entered). For an external torque which is larger than the servo current limit the drive can be turned from the neutral position.

## Zero zone at speed command value with position hold value

Within the zero zone the drive maintains its zero position by means of an internal position-current-control. For an external torque which is larger than the servo current limit the drive can be turned from the neutral position. When the torque is smaller the drive returns to its zero position.

- **Note:** The parameters must be entered in the parameter field *'position-current'*.
- **Note:** When an analog command value is provided from a PLC/CNC position control, the value Ocut should be very low or zero.

#### Scale

Multiplication factor for the analog input signals.

Setting value +/- 0 to 7.500

**Note:** Resulting values superior to 11 V are trimmed. The result of the command value scaling is displayed on the page 'speed at' *Ain1, 2 scaled*. (Ain1,2 scaled = Ain1,2 on +/- Offset x scale)

#### Mode

Input range for	the analog command values
-10+10	Bipolar command value +/-10 V
0+10 V	Unipolar command value
	(directional sign on the page 'Logik' via <i>Ncmd Reverse</i> )
420 mA	Current command value (external resistance 500 Ohm)
+1+9	Command value with potentiometer watchdog

#### **External current limit**

The analog input Ain2 is selected as external current limit via the format adjustment *I limit*.

0 to +10 V correspond to 0-200 % of the current limit for the values programmed in the parameter field **'current'**.

Mode	Digital Speed	<b>_</b>
ł	Cutoff (dig.)	0
Forma	Ain 1	Ain 2 +Cmd 💌
Offset	0	0
Nullzor	1000	0
Scale	1,000	1,000
	Parameter	-Step
Mode	10 + -	10 + -



# Enable

N-Lim+

N-lim-

99 -100

Linear	ramp	function	
Lincai	Tamp	lanction	

96

- Drehzal	nl —		Rcw-Acc	Acceleration - positive rotation direction
Кр	10			
ті	6	ms	Rcw-Dec	Deceleration - positive rotation direction
Td	0	ms		
TiM	20	96	Rccw-Acc	Acceleration - negative rotation direction (1
Kacc	0	96		
Filter	2	Num	Rccw-Dec	Deceleration - negative rotation direction (1
Rcw Acc	25	ms		Deceleration negative rotation direction
Rcw Dec	10	ms		
Rccw Acc	50	ms	D.L.	Environmentaria de la televició Maleria
Rccw Dec	50	ms	R-LIM	Emergency stop, output stage switch ramp
R-Lim	5000	ms		(1 = Function not yet activated
Nmax-100	3000	RPM		
N-lim	100	96		



Linear ramp Time input for 100 % command value Constant acceleration Current peaks and acceleration and deceleration peaks are reduced.

## S-Ramp function / not yet active



## S-Ramp function

The linear time function is altered to a S-shaped function (sine<sup>2</sup>). The constant acceleration and deceleration is altered to continuous changing. Jerk and current peaks are considerably reduced.

#### Command value limited for speed limiting

-	
N-Lim	Speed limiting inferior to Nmax, (0 to 99 % of Nmax)
	Setting of max. speed at position control.
N-lim+	Speed limiting inferior to Nmax for positive rotational direction (0 to 99 %=Nmax)
	Activated via the logic input N clip(neg&pos)
N-lim-	Speed limiting inferior to Nmax for negative rotational direction (0 to -99 %=Nmax)
	Activated via the logic input N clip(neg&pos)

# 10.16 BTB / RDY setting

# **BTB / RDY setting**





ohne

BTB Power

#### **BTB/RDY** message (relay contact)

The BTB relay contact (solid state relay) is closed when the device is ready (residual resistance 300hm). The BTB contact is opened when an error occurs (resistance >1  $M\Omega$ ).

The state BTB/Rdy (ready) is is displayed in the state field as *Rdy*. The state 'not ready/BTB (error)' is indicated by the red LED 'fault' on the front side.

#### BTB and the power supply voltage

When the power supply voltage is switched off the message state can be selected via BTB power in the parameter field servo of the setting window (under-voltage watchdog).

#### Selection BTB Power without

BTB without under-voltage watchdog. When the enable and the power supply voltage are switched off, the message RUN/BTB remains active.

#### **Selection BTB Power with**

BTB with under-voltage watchdog. When the enable and the power supply voltage are switched off, the message **RUN/BTB** is deactivated.

#### Error message and BTB/RDY

When a system-endangering error X (see list of errors) occurs, the BTB signal is switched off. The drive will immediately be disabled internally. (O GO (OxE3) = 0)

#### On the Servo:

The red LED 'fault' (0x8f Bit 1) lights. The error no. is indicated in the 7-segment display.

#### On the pc:

The error states are displayed in the field 'fault'.

The error messages are reset:

Version 2017 / V1

- when the drive enable (RUN) is switched on
- when the auxiliary voltage (+24 V) is switched on
- when the parameter 'cancel error' is sent (can also be programmed as digital input by page Logic)



Warnings
- Fehler
FEEDBACK Schlechtes oder fa MOTORTEMP Motortemperal
Clear warnings and errors

# 11 CAN-BUS settings

# 11.1 Settings CAN-BUS



NBT 37 Unitek 2/4	_
Unitek 4/4	
RxID 201 CANopen	
FireCAN	
Tx ID 181 Nex STD E	EXT

Input fields:		Information	
Rx ID	Receive ID	-Brp	
Tx ID	Send ID	-Sjw	
BTR	Bit rate	-Tseg1	
(Hexwert)		-Tseg2	
		-Sam	
		NBT Bit rate	(kBaud)

## Selection switch

Position	0-14	15
Function	Supplementary value for the basis ID	see chapter 'firmware download'

The addresses for receive/send ID and the bit rate are set in the CAN bus parameter field of the setting window. Switch the auxiliary voltage off and on after changes have been made in the CAN programming!

Address	Short symbol	Presetting (default)	ID address
Receive address	Rx ID (COB-ID RPDO1)	0x201	0x68
Send address	Tx ID (COB-ID TRDO1)	0x181	0x69

Bit rate NBT	BTR setting value	Max. cable length	0x73
1000 kBaud	in prep.	20 m	
500 kBaud	0x4025	70 m	Presetting
625 kBaud	0x4014	70m	LABOD-CNC
250 kBaud	0x405C	100m	
125 kBaud	0x4325	100 m	
100 kBaud	0x4425	100 m	

# 11.2 Aufbau serielles Protokoll

RS 232 16 bit

K3 Z3Z												
Sending from the pc to the drive							Respo to the	onse fre e pc	om the drive			
Char1	Char2	Char3	Char4	Char5	Char6	Char7		Byte 1	Byte 2			
RegID	RegID	Data	Data	Data	Data	Sync		Data	Data			
Bits	Bit s	Bits	Bits	Bits	Bits	"X"		Bits	Bits			
0704	0300	1512	1108	0704	0300			0704	0704			
ascii	ascii	ascii	ascii	ascii	ascii	ascii		binary	binary			

RS 232	RS 232 32 bit													
Sending from the pc to the drive Response from the drive														
							to the	рс						
Char1	Char2	Char3	Char4	Char5	Char6	Char7	Char8	Char9	Char10	Char11	Byte1	Byte2	Byte 3	Byte4
RegID	RegID	Data	Data	Data	Data	Data	Data	Data	Data	Sync.	Data	Data	Data	Data
Bits	Bits	Bits	Bits	Bits	Bits	Bits	Bits	Bits	Bits	"X"	Bits	Bits	bits	Bits
0704	0300	3128	2724	2320	1916	1512	1208	0704	0300		0704	0704	0704	0704
ascii	ascii	ascii	ascii	ascii	ascii	ascii	ascii	ascii	ascii	ascii	binary	binary	binary	binary

Examp	Example: Speed actual (actual speed value) 16 bit				+/-32767 corresponds to +/-100 %				
Sending from the pc to the drive					Response from the drive to the pc				
Char1	Char2	Char3	Char4	Char5	Char6	Char7	Byte 1	Byte 2	
RegID	RegID	Data	Data	Data	Data	Sync	Data	Data	
Bits 0704	Bit s 0300	Bits 1512	Bits 1108	Bits 0704	Bits 0300	"X"	Bits 0704	Bits 0704	
3	D	0	0	3	0	Х	lo	hi	
regID read speed actual read (0x3D) actual speed value (0x30)		ascii	value of	f 0x30					

Aufbau serielles Protokoll

# 11.3 Interface RS232

## Changing the baud rate in the drive

Selection 9600 or 115200

Default 115200

Setting with 0x5a Bit 15 (0x8000)

Bit 150corresponds to 115200Bit 151corresponds to 9600

The baud rate saved in the device is display when switching on the auxiliary voltage 824V=), (after the firmware version is displayed).

Bd0corresponds to 115200Bd1corresponds to 9600

First, the firmware version is displayed (e.g. 2 3 2), then the baud rate (e.g. b d 0)

# **12** Parameter

# **12.1** Current controller parameters

- Strom			Drehzah	nl —		Position		_		
Кр	40		Кр	10		Кр	100			
Ti	800	μs	Ti	6	ms					
TIM	85	96	Td	0	ms	Ti	300	ms		
хКр2	0	96	TiM	20	96	Td	500	ms		
Kf	0		Kacc	0	%	TiM	80	96		
Ramp	150	US	Filter	2	Num	Pos-Refe	erence			
I max pk	10	96	Rcw Acc	25	ms	Speed to	0	RPM		
I max pk	1,1	A	Rcw Dec	10	ms	Speed from	8	RPM		
			Rccw Acc	50	ms	Reso Ed	0	Num		
l con eff	100	96	Rccw Dec	50	ms					
I con eff	5,0	A								
T-peak	5	5	R-Lim	5000	ms	Ref-Ramp	DEC	м		
						Pos-Para	meter			
I-lim-dig	100	96				Tol-wind	100			
I-red-N	100	96	Nmax-100	3000	RPM	Off. Ref.	0			
I-red-TD	32767	Num	N-lim	100	%	ND-Scale	0			
I-red-TE	32767	Num	N-Lim+	99	%					
I-red-TM	5600	Num	N-lim-	-100	96					
- FU-Sta	rt	-	- FU-Stop	17	_	- Option				
T-DC	0	ms	T-DC	0	ms					
U-DC	0,0	96	U-DC	0,0	96					
Umin	0,0	96	Umin	0,0	96					
Fmin	0,0	Hz	Fmin	0,0	Hz					
Ueck	0,0	96	Ueck	0,0	96					
	0.0	H7	Fack	0.0	Hz					

Setting window for the controlling parameters. For further settings refer to the pages 'speed' and 'oscilloscope'.

Parameter	Function	Setting range	Presetting	Units	Step	ID address
Кр	Proportional amplification	0 to 100	10	Num	1=0.1	0x1c
Ti	Integration time	150 to 10000	600	ms	150	0x1d
TiM	max. integrat. time memory	0 to 100	50	%	1	0x2b
xKP2	TiM discharge amplification	0 to 100	0	%	1	0xc9
Kf	Current pilot control	0 to 30	0	Num	1	0xcb
Ramp	I command value ramp	0 to 10000	600	ms	150	0x25
l max	Current limit, peak current	up to 2x I device	2xIdevice	Apeak	0,1	0xc4
l max	Current limit, peak current	up to 2x I device	2xIdevice	Apeak	0,1	0xc4
l con	Current limit, cont. current	0 to I device	Idevice	Aeff	0,1	0xc5
l con	Current limit, cont. current	0 to I device	Idevice	Aeff	0,1	0xc5
T peak	Over-current time	0 to 30	5	S	1	0xf0
I limit (dig)	Current threshold value	0 to 100 lmax	100	%	1	0x46
I-red-N	Current reduction by speed	0 to 100	100	%	1	0x3c
I-red-TD	Start of current reduction	0 to 32767	21000	num	1	0x58
	by power stage					
	temperature					
I-red-TE	Stop of current reducation	0 bis 32767	23000	num	1	0x4c
	by power stage					
	temperature					
l-red-TM	Current reduction by motor	0 bis 32767	5600	num	1	0xa2
	temperature					

## Conversion of the current parameter values

For the digital communication via RS232 or CAN-BUS the numerical values for the rated value have to be observed. The numerical values are displayed in the track field.

Actual current range	l 100% (0xee)	Calibration rated current I-device		Peak current DC disabled		Note	
Max. value +/- 9Bit	mV	num	Aeff	Apeak=	Num	Apeak=	
DS 205/403/405	550	440	5	7	640	10	
DS412	800	640	12	17	920	24	
DS420	700	560	20	28	800	40	
DS 450	416	328	50	70	480	100	
DPC 450	416	328	50	70	480	100	
DPC 460							
DS 475 / BAMO-D3	416	328	75	105	480	150	Limiting in the parameter
BAMOBIL-D3- 50/ 250	870	700	25/125	35/175	1020	50/250	field 'motor' and 'current'.
BAMOBIL-D3-80	560	450	40	56	650	80	The lower value is effective.
BAMOBIL-D3- 100	700	560	50	60	800	100	
BAMOBIL-D3- 120	840	670	60	84	970	120	
BAMOBIL-D3- 350	610	490	175	245	710	350	
BAMOBIL-D3- 450	785	630	225	315	910	450	
BAMOCAR-D3-250	625	700	125	176	1020	250	
BAMOCAR-D3-400	500	560	200	282	810	400	

## Current controller setting window

The current controller parameters are determined by the motor data such as winding inductance and winding resistance.

#### Note:

#### The current controller parameters may only be modified by trained and skilled personal.

Check all setting effects by means of the NDrive oscilloscope.



Improperly set amplification parameters may damage the controller or the drive.

#### Control parameters

Кр	Input for the proportional amplification in the current	
	controller.	St St
	Setting range 0 to 100 (nominal 10 to 40)	Кр
	Presetting 10	Ti
	Formula:	TiM
		хКр2
		Kf
		Ram
		Ima
		Ima
		Icon
		Too
	Kp too low:	1-pe
	compensation error, bad dynamics, low-frequ. vibrations	I-lim
	Kp too high:	I-rec
	strong motor noise, high-frequency vibrations	I-red
	Note: overshoots on the current actual value. Optimize the	I-red
	amplification to min. overshoots.	I-rec
Ті	Input for the integration time in the current controller.	
	Integral – time constant	
	Setting range 150 to 10000 (nominal 600 to 2000)	
	Presetting 800	
	Ti too high: low-frequency vibrations	
	Ti too low: high-frequency vibrations, strong vibration	
	tendency	



# Parameter

TiM	Max, value from the integral memory	Strom	-	
	Setting range 0 to 100% (nominal 70 to 100 %)	Кр	40	
	Dresetting 85 %	Ti	800	μs
	riesetting os //	TiM	85	96
		xKp2	0	96
	If adjusted too low, the speed (output voltage) is not	Kf	0	
	reached.	Ramp	150	US
хКр2	Amplification factor for the attenuation of the current actual	Imaxpk	10	96
	value overshoots.	I max pk	1,1	A
	Setting range 0 to 100 % (nominal 10 bis 50 %)	I con eff	100	96
	Presetting 0%	I con eff	5,0	А
	If adjusted too high, there is a risk of current oscillations.	T-peak	5	s
Kf	Pilot control for the compensation of the operating delay in			
	the controller.	I-lim-dig	100	96
	Setting range 0 to 100 % (nominal 10 bis 50 %)	I-red-N	100	96
	Presetting 0%	I-red-TD	32767	Num
	If adjusted too high, there is a risk of current oscillations	I-red-TE	5600	Num
Pamp	Current increase limiting	Ineg-Iw	5000	
Namp	The surrent increase to 100 % type surrent iss at in us			
	The current increase to 100 % type current iss et in µs.			
	Setting range 0 to 100 % (nominal 10 bis 50 %)			
	Presetting 0%			
	If adjusted too high, there is a risk of current oscillations.			
Current lin	nits			
l max nk	Input for the neak current from 0 to 100 %			
	100% - 2*I device in A pk			
	Display in A pk in the field I may $pk (A eff = 0.707 y Apk)$			
	Display in A pk in the neutrinax pk (A eff = $0.707x$ Apk)			
I con eff	Input for the continuous current from $0 - 100\%$			
	device ratet currnt (I device)			
	I Display in A eff in the field I con eff below	1		

# **12.2 Current reduction parameters**

Static current reduction

Current reduction by means of	Symbol	Function	Parameter	Range
Motor	I max eff	Peak current limiting for the motor	0x4d	0 to xxA
	l nom eff	Continuous current limiting for the motor (type plate)	0x4e	0 to xxA
Servo	l max pk	Peak current limiting for the servo	0xc4	0 to 100 % of Imax
	l nom eff	Continuous current limiting for the servo	0xc5	0 to 100 % of Icon

The respectively lower value of the peak current values and continuous current values are effective. They are displayed as current Imax (in A) in the parameter field *'servo'* and as icon.

Current reduction by	Short symbol	Function	Parameter	Range (with 0 = off)
means of				
Time	T peak	Over-current time function	0xf0	0 to 300 s
Input (command)	I lim-dig	Reduction via digital input (CAN)	0x46	0 to 100 % Imax
Speed	I red-N	Over-current speed function	0x3c	0 to 32767 Num
Power stage temp.	I-red-TD	Start of reduction via power stage/IGBT	0x58	15000 to 24000 Num
		temperature		
Power stage temp.	I-red-TE	End current reduction by power stage	0x4c	0 to 32763 Num
		/IBGT temperature		
Power stage shut off		Emergency stop via the power stage	(Fix)	25200 Num (83 °C)
		temperature		
Motor temperature	I-red-TM	Reduction via the motor temperature	0xa2 0xa3	0 to 32767

# **Dynamic current reduction**

T peak	At a current superior to the adjusted continuous current ( <b>Icon</b> ) a time function is started. When the time function is elapsed the current limit is reduced to the continuous current value. Warning message in the state <b>Iuse-rchd</b> The time is set by means of the parameter <b>T peak</b> (0xf0). If the current is lower than the continuous current (Icon) the time memory is removed. The reset time is 2 x <b>T peak</b> . If the output stage temperature reduction has been selected by means of the parameters <b>I-redTD</b> and <b>I-red-TE</b> the time function is switched off.	T-pea I-lim⊣ I-red- I-red- I-red- I-red-	k 5 5 dig 100 % N 100 % TD 32767 Nu TE 32767 Nu TM 5600 Nu	m m
		State	Warning	Error
I lim-dig	On the logic page a digital input can be programmed at <i>I limit (dig)</i> . If this input is activated or if a CAN command is received for this input, the current limiting is reduced to the parameter value <i>I lim-dig</i> (0x46).	Ird-Dig		
I-red-N	The current limit is linearly reduced from the speed value set in the parameter <i>I-red-N</i> (0x3c). At rated speed the current limit corresponds to the continuous current.	Ird-N		
l-red-TD l-red-TE	There is a state message when the output stage temperature set in the parameter <i>I-red-TD</i> (0x58) is exceeded. If the temperature still increses, the current limit is reduced. When the parameter value <i>I-red-TE</i> (0x4c) is reached, there will be an emergency switch-off. If <i>I-red-TD</i> (0x58) is set to 0 or if the value of <i>I-red-TE</i> (0x4c) is smaller than <i>I-red-TD</i> (0x58), the function is switched off.	Ird-TI	DEVICETEMP > 87 % 0x8f BIT23	DEVICETEMP 0x8f Bit7
l-red-TM	There is a state message when the motor temperature set in the parameter <i>I-red-TM</i> (0xa2) is exceeded. If the temperature still increses, the current limit is reduced. When the parameter value <i>M-Temp</i> (0xa3) is reached, there will be an emergeny switch-off.	IRD-TM	MOTORTEMP > 87 % 0x8f BIT22	MOTORTEMP 0x8f Bit6



## Attention: The warning messages displayed in the field 'state' must be observed! If the current limits are reduced, this might cause failures of the machine or the installation.

# **12.3 Current reduction functions**



States		address
Ird-dig	Current limit reduced to the value programmed as Ilim(dig). Activated with 0xa5 Bit	0x40 Bit 20
luse-rchd	Actual current value at the current limit	0x40 Bit 21
Ird-N	The current limit is reduced when the speed is rising	0x40 Bit 22
Ird-TIR	The current limit is reduced when the output stage temperature is rising	0x40 Bit24
Ird-TI	The current limit is reduced to continuous current via the output stage temperature	0x40 Bit23
<10Hz	If the roatation frequency is smaler 10Hz (blocking protection) (0x5a, bit31=0) current limit will be reduced, (0x5y, bit 31=0) switching frequence will be set to 4 kHz.	0x40 Bit25
Ird-TM	The current limit is reduced when the motor temperature is rising	0x40 Bit26
Ird-Ana	The current limit is reduced via the analog input 2, 0 to 10V = 0 to 100% peak current	0x40 Bit 27
lwcns	Warning - current limit accumulator (accumulator limit) charged to 87.5%.	0x40 Bit28
lcns	The current limit is reduced to continuous current	0x40 Bit5
Measured values	s (monitor)	
Tmotor	Active motor temperature	0x49
Tigbt	Active output stage temperature	0x4a
Tair	Active air temperature in the servo	0x4b
Irda	Active current limit	0x48



# **12.4 Current controller parameters**

## Speed window (current)



# **Current controller**

Block diagram with input fields for the control parameters and display fields for numeric values.

Command values (current)	Command values (current) The current command valueis provided by:		ID address
l Spd	Speed controller output		
l Tor	Torque command value after ramp		
l Pos	Position controller output (Pos -> current)		
l man	Fixed input	input	0x21
l cmd	Current command value	display	0x26
I cmd-Ramp	Current command value after ramp and limiting	display	0x22
Actual values (current)			
Iq actual	Active current	display	0x27
Id actual	Reactive current	display	0x28
l act	Summary current	display	0x20
I act monitor	Summary current after display filter	display	0x5f
Stromregel-Werte			
lq error		display	0x38
Id error		display	0x39
Id ref		display	0x23
Vq		display	0x29
Vd		display	0x2a
DC-BUS	Bus voltage	display	0xeb
V out	Output voltage	display	0x8a
V red			0x8b
V kp			Охас
V Ti			0x8d

Setting field Ramp Parameters are also on the page 'settings'					
Parameter	Function	Address			
Ramp	I-command value ramp	0x25			
I max pk	Peak current Apeak	0xc4			
l con eff	Continuous current	0xc5			
Tpeak	Time peak current	0xf0			
I-lim-dig	Current reduction with input	0x46			
lt	Load	0x61			
I lim inuse	Display current reduction	0x48			



The current command value (I cmd) is processed in the setting field (ramp). The current increase (ramp), the peak current (Imax), the continuous current (Icontin), and the peak current time (T peak) are set.

The summarized current reductions through speed, current, and temperature are displayed at I limit and I lim actual.

At reeduced current the LED Ireduced lights. The result of the current command value processing is shown in the display field 'current command value after ramp' (I cmd-Ramp).

Setting field - Cu	also on the page	
Parameter	Function	Address
Кр	Proportional amplification	0x1c
Ti	Integration time	0x1d
TiM	Max. integration time memory	0x2b
???	???	Охсс
Setting field - Fig	eld control	
ld nom		0xb2
Id min		0xb5
V red	Field weakening from % Vout	0x8b
V kp	Amplification field weakening	0x8c
V Ti	Integration time field weakening	0x8d



The current actual values (I-Ist1, I-Ist2, I-Ist3) are evaluated as Iq-actual and Id-actual. The displayed current actual value (I act monitor) is obtained from the current actual value (I actual) by means of a filter.

The Iq and Id errors are processed in the current controller by means of the amplification parameters (Kp, Ti, TiM). The reference value for the Id control is generated via the vector control feedback.

PWM Display	Parameters are also on the page 'settings'			
Parameter Function		Address		
Vdc-Bus		0xeb		
V out		0x8a		
PWM1	PWM level	Охас		
PWM2	PWM level	Oxad		
PWM3	PWM level	Oxad		



The PWM pulses for the output stage circuit are generated from the current controller output signals Vq and Vd.

## Setting of the current controller amplification

The current controller parameters may only be modified by trained and skilled personal. Setting the current controller is only necessary for unidentified motors. Preset a step function for free-running motors. View the current command value (*I cmd*) and the actual current value (*I actual*) at the oscilloscope. **The actual value must always be smaller than the command value**.

## Setting of the parameter (Current, Kp, Ti, TIM)

<b>KP value too small</b> The difference between the current command value ( <i>lcmd</i> ) and actual current value ( <i>lactual</i> ) is to large. The max. torque is not reached at high speeds.	
<b>KP value to high</b> The actual current value overshoots the current command value. Rough operation and motor noise.	MAN H
<b>Correct KP value</b> Actual current value does not oscillate. The difference between the current command value (lcmd) and actual current value (lactual) is optimal (correction error <5 %)	- Contraction of the second se
<b>Integral part</b> Parameter Ti too large.	- Marina
Integral part Parameter TiM too small. The speed is not reached at max. speed and max. current.	hum
	•



Strom	_		Drehzah	In		Position	_	
Kp	40		Кр	10		Кр	100	
Ti	800	μs	Ti	6	ms			
TiM	85	96	Td	0	ms	Ti	300	ms
xKp2	0	96	TiM	20	96	Td	500	ms
Kf	0		Kacc	0	96	TiM	80	96
Ramp	150	us	Filter	2	Num	Pos-Refe	erence	
I max pk	10	96	Rcw Acc	25	ms	Speed to	0	RPM
I max pk	1,1	A	Rcw Dec	10	ms	Speed from	8	RPM
			Rccw Acc	50	ms	Reso Ed	0	Num
I con eff	100	96	Rccw Dec	50	ms			
I con eff	5,0	A						
T-peak	5	5	R-Lim	5000	ms	Ref-Ramp	DEC	м
						Pos-Para	meter	
I-lim-dig	100	96			1000	Tol-wind	100	
I-red-N	100	96	Nmax-100	3000	RPM	Off. Ref.	0	
I-red-TD	32767	Num	N-lim	100	96	ND-Scale	0	
I-red-TE	32767	Num	N-Lim+	99	96			
I-red-TM	5600	Num	N-lim-	-100	96			
- FU-Sta	rt	_	- FU-Stop		_	- Option		
T-DC	0	ms	T-DC	0	ms			
U-DC	0,0	%	U-DC	0,0	96			
Umin	0,0	96	Umin	0,0	96			
Fmin	0,0	Hz	Fmin	0,0	Hz			
U eck	0,0	96	Ueck	0,0	96			
Feck	0,0	Hz	Feck	0,0	Hz			

Setting window for the speed controller parameters

For further settings please refer to the pages '*speed*' and 'oscilloscope'

1 NDrive-Einstellungen-Para-alles-2

Parameter	Function		Setting range	Presetting	Units	Step	ID address
КР	Proportional amplification		0 to 200	50	num	1=0.1	0x2c
Ti	Integration time		1 to 100	10	ms	0.75	0x2d
Tv	Rate time		1 to 1000	0	ms	0.75	0x2e
TiM	Max. integration time mem	iory	0 to 100	50	%	1	0x3b
Касс	Acceleration amplification		0 to 100	0	%	1	0x5b
Filter	Speed - actual value filter		0 to 10	5	Num	1	0x5e
Ramp-sel							
Rcw-Acc	Speed command value ram acceleration	р,	0 to 10000	100	ms	0.75	0x35
Rcw-Dec	Speed command value ramp, deceleration		0 to 10000	100	ms	0.75	0xed
Rccw-Acc	Speed command value ramp, acceleration		0 to 10000	100	ms	0.75	0x35
Rccw-Dec	Speed command value ramp, deceleration		0 to 10000	100	ms	0.75	0xed
R-Lim	Min. speed command value	e ramp	0 to 10000	10	ms	0.75	0xc7
N max 100%	Max. speed (for 32767 Nun	า)	600 to 50000	3000	RPM	1	0xc8
N-Lim	Speed limit		0 to 100	100	%	1	0x34
N-lim +	Positive speed limit		0 to 100	100	%	1	0x3f
N-lim-	Negative speed limit		0 to 100	100	%	1	0x3e
Actual speed	value range	Calibra	ation speed n-max	ſ	Limiting		
Max. value +/-32767 (15Bit-1) Nn fie		Nmax fields =	value set in the pa = 32767 = 100 %	rameter	Limiting via the parameter field speed with N-Lim		

## Setting field for the speed controller

The amplification parameters KP, Ti, Td, and TiM of the speed controller must be adapted to the drive conditions of the drive and optimized.

(also see MANUAL commissioning instructions)

#### **Amplification parameters**

Parameter				
Кр	Input for the proportional amplification in the speed controller.	Drehzal	nl —	
	Setting range 0 to 200 (nominal 10 to 80)	Кр	10	
	Presetting 40	Ті	6	ms
	Formula:	Td	0	ms
		TiM	20	96
		Kacc	0	96
		Filter	2	Num
		Rcw Acc	25	ms
		Rcw Dec	10	ms
		Rccw Acc	50	ms
		Rccw Dec	50	ms
		R-Lim	5000	ms
	Kp too low:			
	Ko too high:		2000	0014
	strong motor noise, high-frequency vibrations	Nmax-100	3000	Q4
	Optimize the amplification to min, overshoots.	N-lim	100	96
ті	Input for the integration time in the current controller	N-Lim+	100	96
	Integral – time constant	N-IIII-	-100	14
	Setting range 150 to $10000$ (nominal 600 to $2000$ )			
	Dresetting 200			
	Ti too high: low-frequency vibrations			
	Ti too low, high frequency vibrations			
	tondonou			
<b>T</b> -1	Lendency			
Ia	Input for the presetting time in the current controller.			
	Differential – time constant			
	Setting range 3 to 100ms (nominal 6 to 20)			
	Presetting 6			
	Ti too high: high-frequency vibrations, strong vibration			
	tendency	_		
TiM	Max. value from the integral memory			
	Setting range 0 to 100% (nominal 20 to 50%)			
	Presetting 20 %			
	If adjusted too low, the speed is not reached.			
Kacc	Dynamic acceleration value directly to the current controller			
Ruce	Setting range 0 to 100 % (nominal 10 to 50 %)			
	Presetting 0 %			
	If adjusted too high there is a rick of current oscillations			
Filter	Filter for the actual speed value. Zero without filter 10 is the			
Filler	Filter for the actual speed value. Zero without filter, 10 is the			
	Indx. Intel effect.			
	Low filter values: motor noise may occur			
	High filter values: low-frequency vibrations may occur			

		Drehzał	nl —	
Speed com	mand value ramp	Кр	10	
Rcw-Acc	Acceleration ramp, positive direction of rotation for	Ті	6	ms
	speed and position control (can be selected for the	Td	0	ms
	reference run)	TiM	20	96
Rcw-Dec	Deceleration ramp, positive direction of rotation only for	Kacc	0	96
	speed control. Set to <10 ms for position control.	Filter	2	Num
Rccw-Acc	Acceleration ramp, negative direction of rotation for	Rcw Acc	25	ms
	speed and position control	Rcw Dec	10	ms
	Acceleration ramp for torgue control.	Rccw Acc	50	ms
Rccw-Dec	Deceleration ramp, negative direction of rotation only for	Rccw Dec	50	ms
	speed control. Set to <10 ms for position control.	Dition	5000	me
	Deceleration ramp for torgue control.	K-LIM	5000	1115
R-Lim	Minimum braking ramp at limit switch an emergency stop			
	(can be selected for the reference run).	Nmax-100	3000	RPM
		N-lim	100	96
Speed limit	ts	N-Lim+	99	96
N max-	Maximum speed. The set value corresponds to the num.	N-lim-	-100	96
100	value of +/-32767 equals 100 %.			
N-Lim	Speed limiting by means of Nmax, (0 to 99 % of Nmax)			
	Max. speed setting for position control.			
	At torque control as speed limiting 0 to 99 %, at 100 %			
	the speed limiting is not effective.			
N-lim+	Speed limiting inferior to Nmax for a positive rotation			
	direction (0 to 99 % of Nmax)			
	Activated via logic input N clip (neg&pos)			
	For electric vehicle			
	Brake Car Setting on the logic page (digital input):			
	Current limit for braking current at torque command			
	value zero			
N-lim-	Speed limiting inferior to Nmax for a positive rotation			
	direction (0 to 99 % of Nmax)			
	Activated via logic input N clip (neg&pos)			
	For electric vehicle			
	Brake Car Setting on the logic page (digital input):			
	Current limit for braking current at braking switch active.			

# **12.6 Speed controller parameters**

Page 'Speed' (Speed controller)



Schematic diagram with input windows for control parameters and display windows for numerical values

Speed command values		The speed command value is provided by:	ID address
Analog	IN1 / IN2	Analog input 1	0xd5 L / 0xd6 L
Offset	IN1 / IN2	Correction of the zero point error	0x2f L / 0xd7 L
Cutoff	IN1 / IN2		0x50 / 0x53
Scale	IN1 / IN2	Scale for the input value	0x2f H / 0xd7H
Analog int	IN1 / IN2	Processed command value	0xd5 H / 0xd6 H
Dig-Torque		digital torque command value	0x90
Dig-Speed		digital speed command value	0x31
Dig-Cutoff			0x1e
N-Pos		Position controller output Pos->Speed	
Actual value			
Speed actual		Speed actual value signal	
Filter		Filter for the speed actual value	0x5e
N actual		Speed actual value signal for the control	0x30
N act monitor		Speed actual value signal for the display	0xy8

Speed control values		
Ncmd Ramp	Speed command value for the control	0x32
N actual	Actual speed value for the control	0x30
N error	Speed command value minus actual value	0x33

Function	Input 1(Ain1)	Input2 (Ain2)				
Terminal voltage in num (32767)	0xd5L	0xd6L				
Offset correction input amplifier	0x2fL	0x2fL				
Command value - zero range	0x50	0x53				
Amplification factor	0x2fH	0xd7H				
Processed command value Ain x sc. = Ain x on +/- Offset x Scale	0xd5H	0xd6H				
	Function Terminal voltage in num (32767) Offset correction input amplifier Command value - zero range Amplification factor Processed command value Ain x sc. = Ain x on +/- Offset x Scale	FunctionInput 1(Ain1)Terminal voltage in num (32767)0xd5LOffset correction input amplifier0x2fLCommand value - zero range0x50Amplification factor0x2fHProcessed command value0xd5HAin x sc. = Ain x on +/- Offset x Scale0xd5H				

#### Display input field for analog command values

#### Analog Input1 Input2 Ain1 ein 5228 200 Offset 0 0 Nullzone 0 0 Scale 1,000 1,000 Ain1 skaliert 5212 176

## Display input field for analog command values

The direct input values of Input1 and Input2 are displayed under Analog IN.

These signals are processed by means of the parameters offset, cutoff and scale. The result is displayed under 'Analog int'.

It is possible to select either the analog or the digital command value by means of the selection switch 'analog' and 'digital'. When both switches are closed, the digital and the analog command value are added.

The sum at Ncmd must be equal or inferior to 32767 Num.

The digital command values can be entered as digital speed, digital torque, or they are provided by the position controller (NPos).

-							
Command	green function			Ena	Rcw Acc	10	]
Enable	Enable hardware+software			Lim -	Rcw Dec R-Lim	10 10	-
GO	Internal enable (output stage)		Ena	NcRO	N-lim	100	
Lim -	Limit switch minus		GO	UIK	N-Lim+	100	
Lim +	Limit switch plus		•	•	Acc Spec	ed-Limit Dec	í.—
Nc RO	Command value zero		off 0	off		Ramp-	0 N cm
Brake	Brake		Drehzah	ป	S-Pakto		J
Speed - ram	ps						
Rcw Acc	Acceleration ramp right	0x35L					
Rcw Dec	Braking ramp right	0xedL					
R-Lim	Emergency stop ramp	0xc7					
Command v	alue limits						
N-Lim	Speed limit inferior to 100%	0x34					
N-Lim+	Speed limit right (positive)	0x3f					
N-Lim-	Speed limit left (negative)	0x3e					

#### Switch field1 (controlled by means of digital inputs)

The speed command value is only transmitted (green) at enable (*Enable*) and internal enable (GO). It is shown in the display field 'speed command value' (*N cmd*).

When the enable (Ena), the limit switches (*Lim-, Lim+*), not speed=0, and not brake are switched (green), the speed command value (*N cmd*) in the setting field (ramp) is processed. Ramp field

The acceleration ramp (*Ramp-Acc*), the deceleration ramp (*Ramp-Dec*), the limit switches 'emergency stop' ramp (*Ramp-Limit*), and the speed limits (*speed-limit*, *N-limit+*, *N-limit-*) are set. The result is shown in the display field 'speed command value after ramp' (*N cmd-Ramp*).

Switching field 2

#### Speed controller parameters

(Parameters are also on the page 'settings')

Parameters		Address	Kn 20
Кр	Proportional amplification	0x2c	Ti 6
Ti	Integration time (integral part)	0x2d	Td 0 TiM 50
Td	Presetting time (differential part)	0x2e	
TiM	Max. value integral memory (Ti)	0x3b	
			ι κ <sub>ρ</sub>

The actual speed value (*speed actual*) is displayed after the filter in the field 'actual speed value' (*N actual*). At the mix point the actual speed value is subtracted from the speed command value. The result is shown in the display field 'speed error' (*N error*).

The speed correction error is processed in the speed controller (*PID amplifier*). The proportional amplification (*Kp*), the integral part (*Ti*), the differential part (*Td*), and the memory limit for the speed controller are set.

# 12.7 Speed controller optimization

## Setting of the speed controller amplification

The setting of the speed controller is determined by the load, the friction and the inertia presented by the driven axis.

Preset a step function to optimise the settings by monitoring the response at a step input.

The oscilloscope window incorporates a step generator for testing. Monitor the speed command value **(N cmd-ramp)** and the actual speed value **(N actual)** on the oscilloscope. For further information refer to the commissioning manual.

## Speed controller adjustment of the parameter Kp without integral component (Ti = 0)

## KP too low

(Timax = 0)

The difference between the speed command value (Ncmd-Ramp) and the actual speed value (N actual) is too large.

The speed command value is not reached and the acceleration is too weak.

The drive reacts smoothly to command value changes and it can be rotated at standstill.







# KP too high

#### (Timax = 0)

The actual speed value overshoots the speed command value significantly.

Rough operation, strong tendency to vibrations (even at standstill), and motor noise.

## Correct KP value

#### (Timax = 0)

The difference between the speed command value and the actual speed value is optimal (control error approx. < 5%). Remaining errors can be eliminated by means of the integral adjustment.

## Speed controller setting parameters Kp, Ti und TiM

Setting integral part (optimal Kp value) Ti value too low Short overshoots with tendency to high-frequency oscillations. Ti value too high Long overshoots with tendency to low-frequency oscillations.

Adjust the correction error (overshooting) to minimum by means of the parameter *TiM*. Select the Tim value as small as possible.

## **Optimally set speed controller**

**Kp value, Ti value are optimal** No overshooting of the speed.

#### TiM value optimal

There is no speed error occuring.





# **13** Field weakening at synchronous motors

# 13.1 Field weakening mode

The field weakening mode at synchronous motors with surface magnets is only possible within a small range (max factor 1.2) and thus, not economically viable.

At synchronous motors with integrated magnets (salient-pole machines) it is possible to achieve speed ranges up to the factor 4. At optimal rating the motor and the servo can in this case be dimensioned smaller.

## Note:

If the field weakening (power supply switch-off, error switch-off, etc.) fails at max. speeds, the motor can generate high induced voltages.

For devices connected to the power supply the threshold voltage is 400 V or 800 V. For batterydriven devices the counter voltage must always be inferior to the battery voltage.

If the devices or batteries have no external protective circuit they may be destroyed in case of motor overvoltages.

Presettings Motor dates

Motor-Pa	rameter		
Ls-q	0,000	0,000	mH
Ls-d	0,000	0,000	mH
Rs	123	123	mOhm
Lm	1,23	1,23	mH
Rm	0	0	mOhm
TC Stator		0,0	ms
TC Rotor		200,0	ms

- Motor-Nan	neplate		
Nnom	3600	RPM	
Fnom	180,0	Hz	
Unom	0	v	
cos Phi	0,00		
I max eff	10,0	A	
I nom eff	5,0	A	
M-Pole	6		
ld nom		0	96
ld min		0	96

#### Setting parameters - Field weakening

ParameterAddressId nomnominal Id-current 100 %0xb2Id minmin. Id-current -50 to -80 %0xb5from set current at motor1 nom eff0x8bV redOutput voltage for the field weakening (90 to 50 %)0x8c			
Id nomnominal Id-current 100 %0xb2Id minmin. Id-current -50 to -80 %0xb5from set current at motor0xb5I nom eff0xb2V redOutput voltage for the field0x8bweakening (90 to 50 %)0x8c	Parameter		Address
Id minmin. Id-current-50 to-80 % (0xb5)from set current at motor I nom eff0xb5V redOutput voltage for the field weakening (90 to 50 %)0x8bV KnControl amplification for the 0x8c0x8c	Id nom	nominal Id-current 100 %	0xb2
from set current at motorI nom effV redOutput voltage for the field weakening (90 to 50 %)V KnControl amplification for the Ox8c	Id min	min. Id-current -50 to -80 %	0xb5
I nom eff       V red     Output voltage for the field weakening (90 to 50 %)       V Kn     Control amplification for the 0x8c		from set current at motor	
V redOutput voltage for the field weakening (90 to 50 %)0x8bV KnControl amplification for the 0x8c0x8c		I nom eff	
weakening (90 to 50 %)       V Kn     Control amplification for the 0x8c	V red	Output voltage for the field	0x8b
V Kn Control amplification for the 0x8c		weakening (90 to 50 %)	
v np control amplification for the oxoc	V Кр	Control amplification for the	0x8c
field weakening (500-2000)		field weakening (500-2000)	
V Ti Rated time field control 0x8d	V Ti	Rated time field control	0x8d
(0-2000)		(0-2000)	
Note: tendency to oscillate		Note: tendency to oscillate	



Without field weakening

The speed (blue characteristic) is not reached at max. output voltage.

Id –current (light blue characteristic) is controlled to zero.

After the acceleration to the braking (idle speed operation) the Iq –current (red characteristic) is at a low value.

With field weakening

The speed (blue characteristic) is reached.

Id-current (light blue characteristic) is compensated during the field weakening.

At motors with surface magnets a high Id current flows for only a small increase in speed.

After the acceleration to the braking (idle speed operation) the Iq –current (red characteristic) is at a low value.



# 14 Torque control

# 14.1 Torque control



Analog or digital command value as torque command value.

Analog command value 10 V or digital command value (0x90 = 32767num) correspond to 100 % Imax

The torque command value signal is directly transmitted to the current converter via the torque ramps (M R-Acc, M R-Dec).

When there is no speed limiting (**N-lim 100**) the idle speed is only limited by the max. voltage. When the speed limit < 99 % the speed controller starts limiting.

Analog 1 skaliert or M set (dig) display the torque command value.

*Ncmd* and *Ncmd (ramp)* display the numerical value of the limiting (0..99 %=0..32350)

Amplification parameter in the speed controller Kp> 20, Parameter TiM =0 (no integral value)

# **15** Position controller parameters

# **15.1 Setting of the position controller**

- Strom			Drehzal	hl —		Position		
Kp	40		Кр	10		Кр	100	
Ti	800	μs	Ti	6	ms			
TIM	85	96	Td	0	ms	Ti	300	ms
xKp2	0	96	TiM	20	96	Td	500	ms
Kf	0		Kacc	0	96	TiM	80	96
Ramp	150	us	Filter	2	Num	Pos-Refe	erence	
l max pk	10	96	Rcw Acc	25	ms	Speed to	0	RPN
l max pk	1,1	A	Rcw Dec	10	ms	Speed from	8	RPN
			Rccw Acc	50	ms	Reso Ed	0	Nun
con eff	100	%	Rccw Dec	50	ms			
con eff	5,0	A						
T-peak	5	5	R-Lim	5000	ms	Ref-Ramp	DEC	M
						Pos-Para	meter	
l-lim-dig	100	96				Tol-wind	100	
-red-N	100	96	Nmax-100	3000	RPM	Off. Ref.	0	
-red-TD	32767	Num	N-lim	100	96	ND-Scale	0	
-red-TE	32767	Num	N-Lim+	99	96			
l-red-TM	5600	Num	N-lim-	-100	96			
FU-Star	rt		- FU-Stop	,		- Option		_
T-DC	0	ms	T-DC	0	ms			
U-DC	0,0	%	U-DC	0,0	96			
Umin	0,0	96	Umin	0,0	96			
Fmin	0,0	Hz	Fmin	0,0	Hz			
Ueck	0,0	%	Ueck	0,0	96			
Feck	0,0	Hz	Feck	0,0	Hz			

Setting window for the position controller parameters.

For further settings please refer to the pages 'position' and 'oscilloscope'.

Position speed								
Parameter	Function	Setting range	Presetting	Units	Step	ID address		
Кр	Proportional amplification	0 to 200	70	num	1=0.1	0x6a		
Z Factor								
Ti	Integration time	1 to 100	0	ms	0.75	0x6b		
Τv	Rate time	1 to 1000	0	ms	0.75	0x6c		
TiM	Max. integration time memory	0 to 100	0	%	1	0x71		

Reference position							
Parameter	Function	Setting range	Presetting	Units	Step	ID address	
Speed to	Speed compared to the reference position	10 to 32000	3000	num	1	0x76	
Speed from	Loop speed	10 to 2000	500	num	1	0x77	
Reso Ed						0x75	
Dec-Ramp	Switching of 'ramp acc' or 'limit'					0x78	

Parameter position							
Paramter	Function	Setting range	Presetting	Units	Step	ID address	
Tol window	Window - position message	0 to 2000	100	num	1	0x79	
Ref- Off	Zero offset	0 to +/-32676	0	num	1	0x72	
ND-Scale							

## Pos->Speed

#### The amplified position error is the speed command value.

	1 · · · · · · · · · · · · · · · · · · ·		Position	1	
Proportio	nal control amplification	Address	Кр	100	
КР	Proportional amplification position control	0x6a			
	circuit.		Td	500	ms
	Determines the slope of the deceleration ramp.		TIM	80	96
	Formel		Pos-Ref	erence	
Note: The	position control is switched off when no KP-vaue		Speed to	0	RPM
is entered			Speed fro	0	Num
Dynamica	I control amplification		-		
	active in the target range)		P.(P.	DEC T	
		Outh	Ref-Ramp	DEC	M
	Integral part	UX6D	Tol-wind	100	
Td	Differential part	Охбс	Off. Ref.	0	
TiM	Threshold value integral part	0x71	ND-Scale	0	
Pos refere	ence run				
The zero	point of the incremental measuring system is		-		
determine	ed by means of the reference run				
accentin			-		
Speed to	Spood to the limit switch. The limit switch is	0.76	-		
speed to	speed to the limit switch. The limit switch is	0.70			
	passed depending on the speed.		_		
Speed	Reverse speed back to the zero pulse. (loop	0x77			
from	speed)				
Reso Ed		0x75			
Ref-Ramp	The ramp of the reference run is selected	Selection			
	from the ramps RCW-Acc and Ramp-lim.				
Pos parar	neters				
Tol	Position tolerance window (numerical value)	0x79		1 100	
window					
Reference	Mechanical zero offset (numerical value)	0x72	- <u> </u>		/
Offset		0.0.2		ol   🗸   ·	window
		0.70	-		
ND-Scale			-		
0			-		
Une moto	or revolution corresponds to the numerical value of	1 05530.			
			_		
The positi	on command values or the parameter values whic	h are sent from the			

control via RS232 or CAN are immediately processed.


### Position setting window

#### **Position controller**

Block diagram with the input fields for the control parameters and display fields for numeric values.

The position error *Pos error* is calculated at the summing point by subtracting the actual position value (pos actual) from the position target value (pos dest). If the error is inferior to the adjusted tolerance value, this state will be displayed in the field 'tol'. At enable the position target value (pos dest) is proceeded as position command value (pos cmd). The position error is calculated at the summing point by subtracting the actual position value (pos actual) from the position command value (pos actual) from the position command value (pos actual) from the position command value (pos cmd). The resulting error value is displayed in the field 'speed error' (N error).

When the enable states (Ena, GO), the output stage switches (Lim-, Lim+), and the position control amplification (posKp>0) are active (green), the position error (pos error) represents the input to the *Pos -> Speed and Pos -> Current* controllers. For both controllers the proportional amplification (Kp), the integral term (Ti), the differential term (Td), and the memory limiting for the integral term (Tim) are adjusted. This results in the current command value (I pos).

### **Reference run (Referce traverse)**

Block diagram with the input fields for the control parameters and display fields for numeric values.

Settings		Displays	
Speed to	Speed to the reference switch	Ramp Acc	Acceleration to speed (ref. switch)
Speed from	Reverse speed from switch to zero pulse	Ramp Dec	Deceleration to reverse speed (selection 'dec-ramp')
Offset	Mechanical zero offset	Ramp-Limit	Deceleration to reverse speed limit

# Position controller parameters



#### N-Drive2-NDrive-Pos-funktionen

Acceleration:			
Rcw-Acc	Acceleration ti	ime tb to max, speed in ms.	
	Acceleration	a = v / tb	
Constant run:			
N-Lim	Speed limit < m	max. speed.	
	(max. speed (1	100 %) = 32767 num)	
Deceleration:			
Rcw-Dec	For position co	ontrol, adjust to < 10 ms	
Setting via the param	eter window 'po	osition'	
(Pos->Speed KP).	The slope of th	ne deceleration results from the	
proportional amplification.			
Deceleration time			
T Ramp	(tv) from max.	speed (32767 num) to zero,	
	displayed in ms	is in the window 'position'	
Deceleration a in m/s	2		
a = v / tv	v = m	nax velocity in m/s	
,	tv = 0	deceleration time (T Ramn) in s	S-F
			Rai
Example v = 3m/s, tv =	= 0.261 a = 3	a = 3 / 0.261 = 11.5 m/s <sup>2</sup>	
Calculating Kn from a	given sneed an	nd deceleration time	A
$K_{\rm D} = \sqrt{2} \times 2602 / v$	Biven speed and	$\sqrt{11} = \sqrt{2602} / 2 = 00.0 \%$	
Ramn target distance	кр –	v 11.5 x 2005 / 5 - 55.5 /6	
$s = v^2 / s x a$	s = 9/	/ 2x 11.5 = 0.391 m	De

### Conversion of the units for position control

Actual position value range	Resolver	Increment
Pulses/rpm	65536 pro rpm	65536 pro
Max. value +/-2147483647		
(31Bit-1)		
Resolution (smallest value)	16 (65536/4096 (12Bit))	65536/Ink
Example	Travel 1000 mm = 200rpm	Increment
Positioning axis	200rpm = 13107200	Travelg 1
5mm slope/rpm	Resolution 65536/4096 = 16	200rpm =
		Pacalution

Normd	Ramp	
S-Form		
N-Limit	100	%
Ramp-Acc	10	ms
T-Ramp	955	ms
Acc Nett	T-Ramp Dec-Dist	N cmd-Ramp 17 Speed
N-eff	0	Command
Dec-Dist	-1330	

10

6

0

20

0

2 Rew Acc 25

> 5000 m

100 96

99 -100 % .96

Rcw Dec 10

Rccw Acc 50

Rccw Dec 50

Nmax-100 3000

ma

ms

96

96

Num

ms

ms

ms

ms

RPM

Кр Ti

Td

TIM

Kacc

Filter

R-Lim

N-lim

N-Lim+ N-lim-

tal encoder rpm

x4 tal encoder 2048 inc./rpm 1000mm = 200Upm 1638400 Resolution 65536/8192 = 8

### 15.2 Reference run

A reference run is initiated in order to determine the axis reference position.



Speed to	Speed, moving to the limit switch. The limit switch is passed depending on the speed.	0x76
Speed from	Speed, reverse run to the limit switch rising edge (Reso) or to the zero pulse after the limit switch rising edge (Inc.). (loop speed)	0x77
Reso Ed	Correction value at Reso. Enter measurement value 'zero capture'	0x75
Dec-Ramp	Set the switch for the ramp at speed reversion from 'speed to' to 'speed from'.	Selection
Rcw Acc	The ramp programmed at RCW-Acc is used.	0x35 L
R-Lim	The ramp programmed at RCW-Lim is used.	0x7c

The reference switches are selected in the parameter field 'digital inputs'. After the machine and the enable (RUN) are switched on, the reference run **(Start Ref Drive)** is started via a digit input (Din1, Din2) or the interface (CAN-BUS, RS232 0x78).

#### Note:

Driving commands such as **Start Ref drive**, **N** cmd , etc. are recognized only after 5ms after the enable. Close or send the enable first, then send the driving commands.

#### **Reference run**

The drive runs to the limit switch at the speed 'speed to', passes the limit switch at loop speed 'speed from' and returns. With a reference switch the drive runs in a positive direction loop, and in a negative direction double loop. The device position zero point is set after the limit switch rising edge at the incremental encoder zero signal. At the resolver the absolute value of the position (within half a motor revolution) is saved at the limit switch rising edge (zero capture).

The mechanical zero point can be shifted in positive or negative direction by means of the parameter 'Offset'.

Logic-Inp	out-Output			Reference switch	
Limit1	Ref. & Limit Plus	•	AL AH	Ref&LimitPLUS	Limit switch - positive rotation direction is the reference switch
Din1	[Start] Ref. Drive	-	AL AH	Ref&LimitMinus	Limit switch - negative rotation direction is the reference switch
2 mz	-01-	Ľ		RefPLUS	The switch rising edge in positive rotation direction is the reference switch independently from the limit switches

Via the selection window *Dec-Ramp* (parameter field servo) the delay is switched from *Ramp-Limit* to *Ramp-Dec* when changing from *Speed to* to *Speed from*.

### **Reference run functions**



# 15.3 Position controller optimization

### Amplification setting Pos->Speed

The amplified position error provides the speed command value.

– Posit	ion —	
Кр	100	
ті	300	ms
Td	500	ms
TiM	80	96

**Complete presentation** 

Proportional o	control amplification			
Кр	The proportional amplification for the position			
	controller determines the slope of the			
	deceleration ramp.			
Note:	The position control is switched off when no Kp			
	value is entered.			
<b>Dynamic cont</b> final position)	rol amplification, (only effective during ramp-up to			
Ti	Integral component			
Τν	Differential component			
TiM	Threshold value - integral component			
T Ramp	Position ramp time, ramp-up to final position,			
	Delay time (in ms) from max. speed.			
Position run				
Acceleration is	determined by the parameter Ramp Acc.			
A travel at eve	n speed is determined by means of the parameters			
Speed Limit.				
The ramp-up t of the position to zero speed	o final position is determined by the <i>Kp</i> amplification controller. The deceleration time from 100 % speed is displayed in the field ' <i>T Ramp</i> '.			
A small Kp amplification results in a long deceleration ramp. A high Kp amplification results in a short, steep deceleration ramp. If the Kp amplification is too high, the axis will overshoot and oscillate in the target position.				
The optimal tin necessary.	me ramp is as long as possible and as short as			



#### **Position parameters**

Tol window	Position tolerance window (numeric value) When <b>pos-actual &lt; tol window</b> the output <b>O</b> <b>Toler</b> is set to 1 and displayed as state ' <b>Tol'</b>
Reference Offset	Zero position shift (numerical value) The mechanical zero position is shifted in positive or negative direction.

One motor revolution corresponds to a numerical value of 65555.

The position command values or parameter values sent from the controller via the RS232 or the CAN are immediately executed.

### **15.4** Position scaling

### Display factor for the position values

The display of the values for Pos dest, Pos cmd, and Pos actual is adjusted by means of the parameter ND-Scale (0x7c, Pos-display factor) in the window 'position'. At zero the display corresponds to the numerical value (1 motor revolution = 65536 num).

Position	ND-Scale 0
destination	ND-Offset 0
Pos dest	Pos cmd
428463416	428463416

### Adaption of the display to the feed value

Calculate the conversion factor necessary for converting the feed distance to motor revolutions. For the display this factor must be multiplied by the constant 65536.000 (corresponds to 1.000 mm per revolution).



### Example: distance in mm

Slope 5 mm Gear i=20 Conversion factor for one revolution 1/5 \*20 = 4

Position display factor 65536.000\* 4 = 262144.000

NDrive scale = 262144.000

Displayed value in mm for Pos dest, Pos cmd, and Pos actual



### Example: angle in degree

Transmission: 1 degree = 10 motor revolutions

Conversion factor for one revolution = 10

Position display factor 65536.000\* 10 = 655360.000

NDrive scale = 655360.000

Displayed value in degree for Pos dest, Pos cmd, and Pos actual

# **16 Frequency converter parameters**

Frequency control without feedback encoder Setting field for the frequency converter in the field motor motor values(FU)

For standard motors with mains operation the data for 50/60 Hz operation and star-delta circuit are often written on the type plate. These data are internationally standardized.

For motors with converter mode the rated operating point is at a fixed frequency, usually above the 50/60 Hz power supply frequency.

Further data are not always completely indicated by the manufacturers.

Partly the rated speed at the rated operating point (rated frequency, rated load) is not indicated or cosphi is not indicated. Partly the values are unclearly specified, e.g. voltage refered to phase to phase (terminal voltage) or the phase voltage (terminal to star point) or dc bus voltage. Please check the manufacturer data and dimensions carefully (V, VAC, VDC, A, Arms, etc).

Motor		
Туре	EC-Serve	•
Nnom	3000	RPM
Fnom	500,0	Hz
Unom	0	v
Uphi	0,00	Num
I max eff	5,0	A
I nom eff	5,0	A
M-Pole	6	

Rated data	Designation NDrive	Motor example 50Hz	Motor example 60Hz	Dim.
Power supply	Fnom	50	60	Hz
frequency				
Rated power		0.56	0.63	kW
Rated voltage	Unom	220-240, 360-420	255-275, 440-486	V
Rated current	Inom	2.33-2.25, 1.35-1.30	2.26-2.18, 1.30-1.26	А
Rated speed	Nmom	2820	3385	rpm
Cosphi	Cosphi	0.85	0.85	

By means of the drive internal function 'calc from motplate' and using the above mentioned rated data it is possible to determine further values for the motor model.

(Page 'Auto' in NDrive or see table further below).

The updating of the display in the NDrive is effected during the offline-online process. (Switch off and on again the RS232 communication.)

#### Sonderfunktionen, Regler gesperrt



# **16.1 Frequency converter parameters**

#### Setting window for the frequency converter control parameters

Parameter	Function	Setting range Presetting		Unit	Step	Id address	
FU start							
T-DC	Pre-magnetization time	10 to 2000	250	ms	1	0x07 L	
U-DC	Pre-magnetization dc voltage	0 to 20	5	%	1	0x08 L	
U min	Minimal voltage (boost)	0 to 100	10	%	1	0x0a L	
F min	Minimal frequency	0 to 100.0	10,0	Hz	0.1	0x0b L	
U eck	Maximale voltage	0 to 100.0	100.0	%	0.1	0x0c L	
F eck	Frequency at max. voltage	1 to 1000.0	50.0	Hz	0.1	0x0d L	

art	_
200	ms
0,3	96
4,0	96
1,0	Hz
100,0	96
88,0	Hz
opt	•
	art 200 0,3 4,0 1,0 100,0 88,0

### **Description FU start**

-	
T-DC	Pre-magnetization time
	Delay between the switch-on and the start of the
	frequency.
U-DC	Pre-magnetization dc value
Umin	Minimal voltage (boost) at motor standstill.
	U/F characteristic is raised.
Fmin	Minimal frequency at motor standstill.
U eck	Maximal output voltage at base freuquency.
F eck	Base frequency for a max. output voltage.
Current I	

Parameter	Function	Function Setting range Presetting		Unit	Step	Id address
FU stop						
T-DC	Braking current time	10 to 2000	0	ms	1	0x07 H
U-DC	dc value for the dc braking	0 to 20	0	%	1	0x08 H
U min	Minimal voltage (boost)	0 to 100	0	%	1	0x0a H
F min	Minimal frequency	0 to 100.0	0	Hz	0.1	0x0b H
U eck	Maximale voltage	0 to 100.0	0	%	0.1	0x0c H
F eck	Frequency at max. voltage	1 to 1000.0	0	Hz	0.1	0x0d HL

T-DC	200	ms
U-DC	0,3	96
Umin	4,0	96
Fmin	1,0	Hz
Ueck	100,0	96
Feck	88,0	Hz
Current	l ant	

### **Description FU stop**

	-
T-DC	Braking current time
	Delay between the reaching of F-DC and the
	switch-off of the current feed.
U-DC	Pre-magnetization dc value
Umin	Minimal voltage (boost) at motor standstill.
	U/F characteristic is raised.
Fmin	Minimal frequency at motor standstill.
U eck	Maximal output voltage at base freuquency.
F eck	Base frequency at stop operation
Current I	

# 17 Logic

# 17.1 Logic setting window

Preliminary setting window for digital inputs and outputs

							Linghood	1.40		_	_	_
Log	zic-Input-O	utput										
INPL	υτ _				_							
Limi	it1 [S	Start] Ref. I	Drive		AL	AH						
Limi	it2 R	ef. Plus			AL	AH						
Din1	1 [F	Preset] Po:	s=Var3		AL	AH						
Din2	2 Н	landrad			AL	AH						
ουτ	PUT											
Dou	nt1 W	Varning-Er	ror map	-	On	•	Var3	-				
Dou	it2 Si	tatus map	6	•	On	•	Var4	-				
Dou	rt3	Off		-	abs>	•	Var1	-				
Dou	it4 -	-Off		-	On	-	Var3	-				
Var!	1 0					0x0000	0000					
Var2	2 0					0x0000	0000					
Var3	3 3.	2				0x0000	0020					
Var4	4 4	096				0x0000	1000					
Var-	* 4	090				0x0000	1000					

Inputs	
Limit1	Programmable digital input, with preference given to an output stage switch and reference switch
Limit2	Programmable digital input, with preference given to an output stage switch and reference switch
Din1	Programmable digital input
Din2	Programmable digital input
Outputs	
Dout1	Programmable digital output (operant and comparison variable)
Dout2	Programmable digital output (operant and comparison variable)
Dout3	Programmable digital output (operant and comparison variable)
Dout4	Programmable digital output (operant and comparison variable)
	Dout4 is not available for all units
Var1 bis Var4	Comparison variable

### 17.2 Digital inputs



#### Digital inputs

#### Select function

Click the down arrow to open a drop-down menu showing a list of function options. Click the required option. The selected function is highlighted in blue and is transferred to the display field by clicking it.

#### Select the switching functions

AL = Active Low (e.g. output stage switch) AH = Active High

#### Saving

The function is saved in the RAM and activated by pressing the **'enter'** key.

The state of the output stage switches inputs Limit1and Limit2 are displayed in the field 'state' as Lim+ and Lim-..

Example	
Digital inputs	Function selected
Limit1	Output stage switch (+) as reference switch (AL active low)
Limit2	Output stage switch (Al active low)
Din1	Start reference travel (AH active high)

Zuordnung-Eingänge	Funktion
Ref & Limit Plus	Limit switch positive direction is also the reference switch
Ref & Limit Minus	Limit switch negative direction is also the reference switch
Ref Plus	Referen ce switch positive direction
Limit Plus	Limit switch positive direction
Limit Minus	Limit switch negative direction
Limit Plus & Minus	Limit switch positive and negative direction
Cancel Error(s)s	Delete error memory
[Start ]Ref Drive	Start reference run
Speed Ramp 0	Speed command value internally switched to 0 (during speed 0 active)
[Start] Dest > Var1	Position variable1 is started
[Start]Dest > Var2	Position variable2 is started
Ncmd Reverse	Command value polarity is switched over
[Preset] Pos = Var3	Actual position value is set to variable3
[Capture] Var 3 = Pos	Sets the variable 3 as position (target) and travels to the position
[Capture ]Var 4 = Pos	Sets the variable 4 as position (target) and travels to the position
[Switch] Spd Ain1 / Ain2	Switching-over command 'command value Ain1 or Ain2'
[Switch] Spd !Var1 / !Var2	Switching-over command 'command value Ain1 or Ain2'
I limit (dig)	Current limiting to I limit
N clip (neg & pos)	Speed limiting to N clip
[Switch]Cmd = !Dig/Ana	Addition command value digital +analog setting Command Mode Digi+Ana Speed
Speed Ramp 0 +Pos	
Hand wheel	Incremental command value from the hand-wheel encoder (2nd counter input)
Brake Car	Regenerative braking function Current setting at N-Lim+ and N-Lim-
recu_disab	Regenerative braking function switched off
rising bank1,falling bank2	PARA_UPDATE
[Start] Dest = Var1,2,3,4	Pos_kombi
[Start] cw = Var1,2,3,4	Cw_kombi

The inputs **End1**, **End2** (Limit1, Limit2) are default set to output stage switch function. However, it is possible to assign them to any of the input functions **Din1**, **Din 2** available.

### 17.3 Digital outputs

in POI			incent.			
Limit1	[Start] Ref. Drive	-	AL	AH		
Limit2	Ref. Plus	*	AL	AH		
Din1	[Preset] Pos = Var3		AL	AH		
Din2	Handrad	-	AL	AH		
OUTPUT						
Dout1	Warning-Error map		On		Var3	-
Dout2	Status map	*	On	*	Var4	
Dout3	pwm3 (5/6)	*	abs>	•	Vari	-
Dout4	T-motor Tigbt Tair		On	¥	Var3	•
Var1	Ballast Zähler			0x00	000000	
Var2	(dbg) temp Logik Freq.			0x00	000000	
Var3	(dbg)*ptr1 (dbg)*ptr2			0x00	000020	
Var4	Warning-Error map			0x00	001000	
1.000	Status map					_
	N-lim					
	Leistung					
	Arbeit					
	Zero-Capture					
	fpga Status					
	M set (dig.)					
	N set (dig.)					
	Vdc-Bat					

#### **Digital outputs**

.

The parameter selected in the first column of the drop-down menu are compared with the variables in the third column by means of the operands (second column).

The logic result of the comparison is given at the selected digital output as low (<1 V) or high (>10 V) value..

Click the arrow keys to open the drop-down menu. Select the assignment. The selected function is highlighted in blue and transferred to the display field by clicking it.

The output functions can be modified during operation. The function is saved in the RAM and activated by pressing the 'enter' key.

Example	
Digital outputs	Selected function
Dout1	Current superior to variable 3
Dout2	Speed equal to variable 4

**Note**: When inductances are connected (relays, brakes, etc.) connect an over-voltage protective device such as recovery coils or varistors. The output driver is switched off in case of over-voltages.

Assignment of the output parameters (selection)	Function	ID address
I_cmd	Current (I) command value (Speed controller output)	0x26
I_actual	Current(I) actual value	0x20
N cmd Ramp	Speed command value	0x32
N actual	Speed actual value	0x30
Pos cmd	Position command value	
Pos actual	Position actual value	0x6d
I_error	Current(I) error	0x23
N error	Speed error	0x33
Pos error	Position error	0x70
Brake	Brake control signal	0xF2
All parameters of the list 'measured	value selection' can be assigned to the respective ou	tputs.

Operands	Function
Off	off
On	on
1Hzz	Test
=	equal
!=	not equal
>	superior to
<	inferior to
abs>	Absolut valuesuperior to
abs<>	Absolut value inferior to
tol>	Tolerance input TOL-wind
Tol<	Tolerance input TOL-wind
>=	superior or equal to
<=	inferior or equal to
hyst>=	Hysteresis at >=
Hyst<=	Hysteresis at <=
window	Tolerance window +/-25 %

Variable	Function	ID
		address
0	Logic signal zero	
1	Logic signal 1	
VAR1	Numerical value of the entered	0xd1
VAR2	variable fields	0xd2
VAR3		0xd3
VAR4		0xd4
Ain1	Numerical value of the voltages	
Ain2	across the analog inputs	

### Outputs assigned on Status-Map and Warn-Err-Map

Display of the	Function	ID addr	ess
state		0x40	Dec
Ena	Enable drive	Bit 0	1
NcR0	Speed command value = 0 (drive stopped)	Bit 1	2
Lim+	Limit switch plus assigned	Bit 2	4
Lim-	Limit switch minus assigned	Bit 3	8
ОК	Drive ok (no uncontrolled control-voltage reset seen)	Bit 4	16
lcns	Current is limited to the continuous current level	Bit 5	32
T-Nlim	Speed-limited torque mode active	Bit 6	64
P-N	Position control possible	Bit 7	128
N-I	Speed control possible	Bit 8	256
<n0< td=""><td>Acutal speed less than 0.1% (standstill)</td><td>Bit 9</td><td>512</td></n0<>	Acutal speed less than 0.1% (standstill)	Bit 9	512
Rsw	Reference switch tripped	Bit 10	1024
Cal0	Calibration move active	Bit 11	2048
Cal	Calibration move completed (position calibrated)	Bit 12	4096
Tol	Position within tolerance window	Bit 13	8192
Rdy	Drive is ready (BTB/TDY contact is closed)	Bit 14	16384
Brk0	De-energized brake with motor active	Bit 15	32768
SignMag	Speed internally inverted	Bit 16	65534
Nclip	General speed limiting (if ≤ 90 %) possible	Bit 17	131072
Nclip+	Additional switchable positive speed limiting possible	Bit 18	262144
Nclip-	Additional switchable negative speed limiting possible	Bit 19	524288
Ird-Dig	Current limiting (switchable) reached	Bit 20	1048576
luse-rchd	Actual current limit reached	Bit 21	2097152
Ird-N	Current limited (speed)	Bit 22	4194304
Ird-TI	Current derating (power-stage temperature) possible	Bit 23	8388608
Ird-TIR	Current limited to the continuous current (power-stage temperatue)	Bit 24	16777216
> 10 Hz	Additional current limit if frequency less than 10 Hz	Bit 25	33554432
Ird-TM	Current limit due to motor temperature reached	Bit 26	67108864
Ird-ANA	Current derating due to analog input (if ≤ 90 %) possible	Bit 27	134217728
lwcns	Current peak value warning	Bit 28	
RFEpulse	Pulsed RFE-input monitoring active	Bit 29	
M+D	free	Bit 30	
HndWhl	Hand-wheel function selected		

### State to digital outputs

Set output (Dout1, 2, 3) onto the Status-Map via the drop down menu. Set function to **= (inverted on !=)** Select variable. Select state values (Dec) from the table (multiple state values possible) and write them into the selected variable (Var1-Var4).

Example: Feedback that the drive is enabled. Output 2

Dout2 , Status-Map , On Variable Var4 State value Dec=1 (drive enabled)

INPUT						
Limit1	[Start] Ref. Drive	•	AL	AH		
Limit2	Ref. Plus	-	AL	AH		
Din1	Off	•	AL	AH		
Din2	Off	•	AL	AH		
OUTPUT						
Dout1	Warning-Error map	-	On	•	Var3	•
Dout2	Status map	-	On	-	Var4	-
Dout3	O Brake	-	!=	-	1	-
Dout4	Off	-	On	•	0	•
Var1	0			0x000	00000	
Var2	0			0x000	00000	
Var3	32			0x000	00020	
Inch	1			0-000	00001	

# 17.4 Logic links

Fault or warning signals to digital outputs.

Set output (Dout1, 2, 3) onto the Warn-Err-Map via the drop down menu. Set function to = (Invertiert auf !=). Select variable. Select Warn-Err values (Dec) from the table (multiple values possible) and write them into the selected variable (Var1-Var4).

### Example:

Feedback that the power voltage supply is switched on. Dout1, Warn-Err-Map, On Variable Var3

Error value Dec=32 (POWERVOLTAGE , no power supply voltage)

	15 (25)		100201	-		
Limit1	[Start] Ref. Drive	~	AL	AH		
Limit2	Ref. Plus	×	AL	AH		
Din1	Off	$\sim$	AL	AH		
Din2	Off	~	AL	AH		
OUTPUT						
Dout1	Warning-Error map	Ŷ	=	~	1	~
Dout2	Status map	~	= ~		1	Ý
Dout3	O Brake	~	le .	~	1	~
Dout4	Off	~	- ~		1	~
Var1	0			0x000	00000	
Var2	0			0x000	00000	
Var3	32			0x000	00020	

Display on	Fault message on	Description	ID address	
the servo	NDrive			
	NOREPLY-NoRS	RS232 interface not plugged or		
		disturbed		
			REGID0x8f	Dec
0	BADPARAS	Defective parameter	Bit 0	1
1	POWER FAULT	Output stage fault	Bit 1	2
2	RFE FAULT	Defective safety circuit	Bit 2	4
3	BUS TIMEOUT	Transmission fault BUS	Bit 3	8
4	FEEDBACK	Faulty encoder signal	Bit 4	16
5	POWERVOLTAGE	No power supply voltage	Bit 5	32
6	MOTORTEMP	Motor temperature too high	Bit 6	64
7	DEVICETEMP	Device temperature too high	Bit 7	128
8	OVERVOLTAGE	Overvoltage >1.8 x UN	Bit 8	256
9	I_PEAK	Over-current 300 %	Bit 9	512
А	RACEAWAY	Racing (without command value,	Bit 10	1024
		wrong direction)		
В	USER	User - Fault selection	Bit 11	2048
С	I2R	Overload	Bit 12	4096
D	RESERVE		Bit 13	8192
E	ADC-Int	Current measuring fault	Bit 14	16384
F	BALLAST	Overload of the ballast circuit	Bit 15	32768

Display on the servo	Fault message on NDrive	Description	ID address	
			REGID0x8f	Dec
0	WARNING_0	Inkonsistent device identification	Bit 16	65534
1	ILLEGAL STATUS	RUN signal	Bit 17	131072
2	WARNING_2	FE signal inactive	Bit 18	262144
3			Bit 19	524288
4			Bit 20	1048576
5	POWERVOLTAGE	Power supply voltage missing or too	Bit 21	2097152
		low		
6	MOTORTEMP	Motor temperature > 87 %	Bit 22	4194304
7	DEVICETEMP	Device temperature > 87%	Bit 23	8388608
8	OVERVOLTAGE	Overvoltage >1.5 x UN	Bit 24	16777216
9	I_PEAK	Over-current 200 %	Bit 25	33554432
А			Bit 26	67108864
В			Bit 27	134217728
С	I2R	Overload > 87 %	Bit 28	268435456
D			Bit 29	536870912
E			Bit 30	1073741824
F	BALLAST (unit dependent)	Overload of the ballast circuit >87 %	Bit 31	

# **18 Diagnosis**

# 18.1 Diagnosis window

		Einstellungen	Drehzahl I	Position	Logik	Bus	Ozilloskop	Monitor	Diagnose	Auto	Extra			
	Manual R	ead/Write	- Manual Re	ad/Write				Track					Information	
	Tra	ick	Schreibe	in IDr	register	0x31		N cmd (r	amp)	500	0 (0x1388	3)	Logik Freq.	65000 Hz
	Inform	nation		_				pwm1(1	/2)	609	(0x261)		fpga 1. Fehler	0x0000
	Zeige alle	e Register		val	ue	5000		nwm2 (3	(4)	576	(0x240)		fpga Status	0x0000
Zeig	e ausgew	ählte Register	Lesen	ID	register	0x30	L .	pwinz (5		208	1 (0x821)		Mode	0x0008
	Auto	-Reso		_				13 adc		1 207	0 10-014			
	Auto-O	ptimize		val	ue	(0x13d	(Ot	12 adc		207	9 (0x811)			Schließen
	So	ript						Status m	ар	3357	1217 (0x2)	004191)		
	Erro	r-Log			Schließen				3	chließen				
				_										
RegNr	Тур	Hexwert	Dezimalw	ert Be	zeichn	ung	(	interner	r Name)		Be	eschreibu	ng	
0x00	(UK):	0x000x0	0	??	()		(	rsv	) :	?? (	)			<u> </u>
0x01	(RW):	0x000x0	0	Us	r-Opt		(	USER_OPT	( SMOIT	(Deif)	Optic	ons		
0x02	(RW):	0x000x0	0	SC	-info		(	USER_STA	ATE )	(Deif)	Safet	y-State		
0x03	(RW):	0x000x0	0	Cm	d-Spec		(	USER_SP	CIALS)	Deif)	Cmd-S	Specials		
0x04	(SP):	0x0000	0	??	()		(	USER_KEY	Z ) 1	?? (	)			
0x05	(RW):	0x1388	5000	F	nom		(	MOTOR_NO	DM_F ) N	lotor	nomina	al Freque	nz (FU)	
0x06	(RW):	0x000x0	0	U	nom		(	MOTOR_NO	M_V ) N	lotor	nomina	ale Spann	ung (FU)	
0x07	(RW):	0x000000x0	0	T-1	DC		(	UF_TDC	) :	leit I	DC-Best	cromung (	FU)	
0x08	(RW):	0x00000000	0	U-1	DC		(	UF_UDC	) 5	Strom	DC-Bes	stromung	(FU)	
0x09	(RW):	0x0000000	0	F-	DC		(	UF_SPEZ:	TAL )	??				
0x0a	(RW):	0x0000000x0	0	U	min		(	UF_UMIN	) 1	linima	alspann	ung (FU)		
0x0b	(RW):	0x000000x0	0	F	min		(	UF_FMIN	) 1	linima	alfrequ	lenz (FU)	1	
0x0c	(RW):	0x0000000x0	0	U	eck		(	UF_UECK	) 5	Spannu	ing für	max. Fr	equenz (FU)	
0x0d	(RW):	0x0000000x0	0	F	eck		(	UF_FECK	) ]	reque	enz für	max. Sp	annung (FU)	
0x0e	(RW):	0x0000	0	U	phi		(	UF_POWF	) ]	eistu	ingsfa)	ctor (FU)		
0x0f	(RW):	0x000x0	0	??	()		(	UF_EXTRA	A) (	?? (	)			
0x10	(SP):	0x0007	7	Ch	an		(	CAPTURE	CHAN ) (	szil]	loskop	Triggerk	anal	
				Schließ	en	Neu le	isen A	lle Register sp	eichern	Drucke a	Ille Registe	r		

NDrive-Diagnose-alles-1

# Setting window for the diagnosis

Manual Read / Write	Direct read or write of the parameter values
Track	Display of the numeric value of the selected parameter
Information	Information about transfer errors
Zeige alle Register	Parameter list with parameter Ids
Zeige ausgewählte Register	List of all parameters selected and their parameter Ids
Auto-Reso	see page AUTO
Auto-optimize	see page AUTO
Fehler-Historie	not yet implemented
Script	not yet implemented

# 18.2 Manual read/write

Direct reading and entering of the parameter values Note: only for service!

#### **Reading parameters:**

Enter the parameter address	into the input field <i>ID register.</i>			
Key <b>lesen</b>	Click it			
	Below the input field the parameter			
	designation and its contents is			
	displayed as numerical and hex			
	value.			
Writing parameters:				
Enter the parameter address	into the input field <i>ID register.</i>			
Enter the value for the select	ed parameter in the input field Value.			
Click key 'write'				
The parameter values are im	mediately transferred.			



NDrive-Manual-RW-de-1

# 18.3 Track display field

#### Track

#### Display of the parameter values

The numerical values and hex values (0x) of the selected parameters are
displayed in the track display.
Click the arrow key to open the scroll menu for the selection of a parameter
value.
Teh value is selected by means of the arrow keys or the scroll bar in the
scroll field.
The selected value is highlighted in blue. When the value is selected the

The selected value is highlighted in blue. When the value is selected the scroll field closes.

### Note:

# Alle parameter values can also be displayed on the oscilloscope



Logik Freq.	65000	Hz
fpga 1. Fehler	0x0000	
fpga <mark>Status</mark>	0x0000	
Mode	0x0008	
Mode	0x0008	
	Schließer	1

# Information

Display for current states (no input possible)

Foreground	Speed of the foreground program
Motor pos spikes	Actual speed value error
RS232 resync	Transmission error RS232
CAN overruns	Transmission error CAN-BUS
Mode	Mode bit setting

# 18.4 Information

RegNr	Тур	Hexwert	Dezimalwert	Bezeichnung	(interner Name)	Beschreibung
0x00	(UK) :	0x0000	0	?? ()	(rsv )	?? ()
0x01	(RW):	0x0000	0	Usr-Opt	(USER_OPTIONS )	(Deif) Options
0x02	(RW):	0x0000	0	SC-info	(USER_STATE )	(Deif) Safety-State
0x03	(RW):	0x0000	0	Cmd-Spec	(USER_SPECIALS)	(Deif) Cmd-Specials
0x04	(SP) :	0x0000	0	?? ()	(USER_KEY )	?? ()
0x05	(RW):	0x1388	5000	F nom	(MOTOR_NOM_F )	Motor nominal Frequenz (FU)
0x06	(RW):	0x0000	0	U nom	(MOTOR_NOM_V )	Motor nominale Spannung (FU)
0x07	(RW):	0x00000000	0	T-DC	(UF_TDC )	Zeit DC-Bestromung (FU)
0x08	(RW):	0x00000000	0	U-DC	(UF_UDC )	Strom DC-Bestromung (FU)
0x09	(RW):	0x00000000	0	F-DC	(UF_SPEZIAL )	??
0x0a	(RW):	0x00000000	0	U min	(UF_UMIN )	Minimalspannung (FU)
0x0b	(RW):	0x00000000	0	F min	(UF_FMIN )	Minimalfrequenz (FU)
0x0c	(RW):	0x00000000	0	U eck	(UF_UECK )	Spannung für max. Frequenz (FU)
0x0d	(RW):	0x00000000	0	F eck	(UF_FECK )	Frequenz für max. Spannung (FU)
0x0e	(RW):	0x0000	0	U phi	(UF_POWF )	Leistungsfaktor (FU)
0x0f	(RW):	0x0000	0	?? ()	(UF_EXTRA )	?? ()
0x10	(SP):	0x0007	7	Chan	(CAPTURE_CHAN )	Oszilloskop Triggerkanal
						· · · · ·
			Sc	hließen Neu lesen	Alle Register speichern	Drucke alle Register

# Display field for registers

Show all registers	All 255 registers are shown in a table. The register contents cannot be modified.
Show selected registers	Only the registers which are important for the user are display in a table. The registers can be selected via the file 'Reglist.txt'.
	The register contents cannot be modified.

### Selection in the footer

Close	Display field is closed
Re-read	The parameter values are read again from the servo.
Save registers	The displayed registers are written into a file.
Print registers	The displayed registers are printed.

Information

# **19 Monitor**

# **19.1 Measured values**

ele		Einstellungen	Drehzahl	Position	Logik	Bus	Ozilloskop	Monitor	Diagnose	Auto	Extra		
	Operating states		_							-12	-		
1	N cmd (ramp)		20000					<u> </u>		150%			
1	Nactual		19729							150%			
	I cmd		24							150%			
	lact (filt)		29							150%			
	ld actual		0							150%			
P	lq actual		45							150%			
1	l2t		5							150%			
	Leistung		192							150%			
1	Vdc-Bus (dir.)		0					<u> </u>		150%			
	Ballast-Leistung		0							150%			
	T-motor		1655					<u> </u>		150%			
	T-igbt		135							150%			
	T-air		136							60 C			
1	l lim inuse		126							150%			
1	Vout		31							150%			

States	Function	Unit	Range	ID address
Ncmd Ramp	Speed command value after ramp and limit	num	0 to +/-32767	0x32
N actual	Actual speed value	num	0 to +/-32767	0x30
Icmd Ramp	Current command value after ramp and limit	num	0 to 600	0x26
lact monitor	Actual current value (filtered)			
I actual D	Actual current value D (reactive current)	num	0 to 600	0x28
I actual Q	Actual current value Q (active current)	num	0 to 600	0x27
l2t	Capacity I2xt	num	0 to 4000	0x45_L
P-Motor	Motor power	num	0 to 4000	0xf6
DC-BUS	Bus circuit voltage	num	0 to +/-32767	0xeb
P-Regen	Ballast power	num	0 to 4000	0x45_H
Tmotor	Effective motor temperature	num	0 to 32767	0x49
Tigbt	Effective output stage temperature	num	0 to 32767	0x4a
Tair	Effective air temperature in the servo	num	0 to 32767	0x4b
Ireda	Effective current limit	num	0 to 600	0x48
Vout	Output voltage	num	0 to 4000	0x8a

# 20.1 Recuperation for vehicles (Brake Car)

### Setting BAMOCAR parameter 'Brake Car' at torque control

Only positive torque command value Activate function on the page 'logic' Set a digital input to '**Brake Car'**. (Select **Brake Car** via the drop-down menu)

Logic-Inp	out-Output			
INPUT			_	-
Limit1	Off	-	AL	AH
Limit2	Off	-	AL	AH
Din1	N cmd Reverse		AL	AH
Din2	Brake Car	•	AL	AH

Switched on at Din2 = higher braking torque

Enter the values on the page 'settings/parameters/speed Input parameters : *Nmax* speed value for 100% speed Input parameters : *N-lim* speed limiting at torque control

Braking current at torque command value 0 (minimal braking torque) Input parameters: *N-lim+* (Function changed for minimal braking torque)

Braking current at switched-on brake pressure-contact (e.g. brake light) Input parameters: *N-lim-* (Function changed for increased braking torque)



### **Rotation direction at Brake Car**

The torque command value must always be positive. Changing the rotation direction at analog command value via *Scale.* (positive value = rotating clockwise, negative value = rotating anti-clockwise). Changing the rotation direction at digital and analog command value. Select a digital input (e.g. Din1) on the page 'Logik' as *N cmd reverse.* The direction of rotation can be selected by means of the switch position.

Nmax-10	0 6000	RPM
N-lim	95	96
N-Lim+	30	96
N-lim-	-70	96

# **21** Automatic setting functions

# 21.1 Setting window Auto

Sonderfunktionen, Regler sperren 1885	Motor-Para	meter			Motor-Nan	neplate		1	Analog	
[Fn4] Phasing rot	L sigma-q	Oxb1	0xb1	mH	Nnom	0x59	RPM		Look-up	Ox1a
idle	L sigma-d	Oxbb	Oxbb	mH	Fnom	0x05	Hz		Vdc-Bus	Oxeb
[Fn1] Tuning Still	R stator	Oxbc	Oxbc	mOhm	Unom	0x06	v			
[Fn2] Tuning Rotating [Fn3] Phasing Still	TC Stator		Oxbd	ms	Cos Phi	0x0e				
[Fn4] Phasing rot	L magnet.	0xb3	0xb3	mH	I max eff	0x4d	A			
[Fn5] DC-Bestromung	R rotor	0xb4	0xb4	mOhm	I nom eff	0x4e	A			
[Fn7] Tacho-Offset	TC Rotor		0xb6	ms	M-Pole	0x4f				
[Fn8] Berechnung von Motor Typenschild	FB-Offset	0x44	0x44	Deg	ld nom		0xb2	%		
[Fn9] Abgleich VdcBus Null [Fn10] Abgleich VdcBus Spannung	Vdc-Bus		Oxeb		ld min		0xb5	96		
[Fn11]	-									
[Fn12]										
[Fn14]										
[Fn15]										

pecial fun	iction			Function	Description	ID
Sonderfunkt	ionen, Regler	sperrenh:85		idle		0x85
(En4) Phasir	og rot			tuning still	not used	0
idle	ig ior		-	tuning rotating	not used	1
[Fn1] Tunine	Still			phasing still	not used	2
[Fn2] Tuning	Rotating			nhasing red	Automatic reading of the rotor angle	4
[Fn3] Phasir	ng Still			phusingreu	(Reso-Offset)	-
[Fn4] Phasir	ngrot			DC ourrent	Fixed surrent food angle. Set by means	
[Fn5] DC-Bes	stromung Offent			DC-current	Fixed current feed angle. Set by means	
[Fn7] Tacho	-Offset				of Reso-Offset	
[Fn8] Berech	hnung von Mo	tor Typensch	nild			
[Fn9] Abglei	ch VdcBus Nul	I		Analog-Offset	Automatic adjustment of the analog	6
[Fn10] Abgle	eich VdcBus Sp	annung			inputs	
[Fn11]				Tacho-Offset	Automatic adjustment of the segment	7
[Fn12]					offset at bl-Tacho	
[Fn14]				Calc from	Calculation of the motor data acc. to the	8
[Fn15]				motplato	type plate	0
lotor para	ameters			Function	Description	
				Function	Description	
Wotor-Par	ameter		1000	LS-Q	Stator leakage inductance in $\mu$ H (without	UXD1
Ls-q	0,000	0,000	mH		comma), at ACIM Lsd = Lsq	
Ls-d	0,000	0,000	mH			
Rs	123	123	mOhm	Ls-d		0xbb
1.00	1 22	1 22	mH	Rs	Stator resistance in m $\Omega$ (without comma)	0xbc
LIII	1,25	1,25		Lm	Main inductance in 10 $\mu$ H (without	0xb3
Rm	0	0	mOhm		comma)	
TC Stator		0,0	ms	R-r	Rotor resistance in $m\Omega$ (without comma)	0xb4
TC Rotor		200.0	ms	TC-Stator		0xb6
TC NOLOT						
FB-Offset	-70	-58	Deg	TC-Rotor	Lm/Rr in ms (without comma), rotor time constant	0xbd

tor Typenschild		Function	Description			
				N nom	Rated speed at rated voltage	
			12	F nom	Rated frequencies at rated	
Wotor-Nam	acon	DDM			voltage	
Feem	180.0	Hz		U nom	nominal voltage	
Unom	0	v		Cos Phi		_
cos Phi	0,00			I max eff	Motor peak current effective	
I max eff	10,0	A		I nom eff	Motor continuous current	_
I nom eff	5,0	A			effective	
M-Pole	6			M-Pole	Motor -Pole	
ld nom		0 9	6	Id nom	reactive current	
ld min		0 9	i i	Id min	Minimum reactive current	
Anal	og			Vdc-Bus	DC link voltage Num	Oveb
swerte						
Anal	og			LOOK-up	DC Connection Voltage III V	0110
Look-	up	Ox1a		Vuc-Bus	DC link voltage Num	daxu
Vdc-E	lus	Oxeb				

#### Note:

For the automatic adjustment Command Mode must be set of Digital Speed.

After the execution of the auto-functions the correct values must be saved on the EEPROM level0.



Do not used functions which have not been released (currently 'tuning still, tuning rotating, pasing still').

## 21.2 Tuning still (0x85-1)



# 21.3 Tuning rotating (0x85-2)

Sonderfunktionen, Regler gesperrt	
tuning rotating 🗾 💌	Function not yet released
text f2 0	
text f2 1	
Text Button Auto Start 2	
text f2 3	
Status Text 9_0	
text f2 4	

# 21.4 Phasing still (0x85-3)

phasingstill	<b>_</b>
text f3 0	
text f3 1	
Text Button	Auto Start 3
Text Buttor text f3 3	n Auto Start 3
Text Buttor text f3 3 Status Text 9 0	n Auto Start 3
Text Buttor text f3 3 Status Text 9_0 text f3 4	n Auto Start 3

Function not yet released

### 21.5 Measuring the encoder offset (phase angle)

### Execution of phasing red (0x85 -4)

Check the no. of motor poles (MOTOR-Pole) and correct, if necessary. Limit the motor current:

Set the parameter *Inom eff* in the field 'motor' to max. 30 % of the rated current value.

Set the rotation speed: Set the parameter **Speed from** in the field 'pos-reference' to 3 % of the rated speed. Apply the power supply to the device, **Enable open** 



Function	Message at NDrive	7-segment display
Click function - request phasing		
Switch on enable within 10 s	Wait for RUN= 1 (enable)	40
Enable closed	Current ramp	41
Current built up (rotation starts)	Rated value reached	42
	Output rotating field	
Pole angle and reading of the no. of motor poles executed	End	43
Correct end	End, wait for RUN=0 (switch off FRG)	49
Error switch-off		
Enable switched off during the measuring process	Error	47
Time out , measuring time exceeded		48

During the automatic phase angle reading the states are shown in the 7-segment display of the device (sequence: 4-0, 4-1, 4-2, 4-3, 4-9).

When the no. of motor poles and the connection are correct, the motor rotates clockwise for one revolution (electric periode (360degree)  $\times$  no. of poles/2). If the motor rotates more than one revolution, the no. of poles is too high. If it is less than one revolution, the no. of poles is too small.

If the motor rotates anti-clockwise check the motor connection.

At **End**, **Wait for RUN=0** (49) the result is transmitted to the parameter *FB-Offset* (0x44). Switch off enable.

After reading EEPROM level 0 the value is correctly displayed in 'Feedback Offset'.

Set the motor current limiting and the reference run again to the original values.

Write the data into the EEPROM level 0!!

**Checking the encoder offset setting, fine adjustment** Operate the motor without load at approx. 50 of the rated speed.

Read the value on the page 'speed at the parameter Vd (0x2a).

IF the value is superior to 100, adjust this value to minimum by means of slight

changes in 'setting encoder offset (page 'settings 0x44).

Read the changed value to the EEPROM level0.



old value new value



Motor-Parameter

Ls-q

Ls-d

Rs

Lm

Rm

TC Stator

TC Rotor

FB-Offset

0,000

0,000

123

1.23

0

-70

0.000

0,000

123

1.23

0

0,0

-58

200.0

mH

mH

mH

ms

ms

Deg

mOhm

mOhm

# 21.6 Preset current feed angle (0x85 – 5)/fixed motor position (0x85-5)



When a current feed angle is preset (angle) the rotor (motor shaft) is moved into this angle and held.

Reduce the current limit for the rated current *Inom eff* to 30 %.

(DC current feed is controlled to rated current, no rotating field).

The function is started as follows:

Preset the requested angle by

means of the parameter **FB**-**Offset** (0x44) on the page 'settings'.

RESO	LVER	-
FB-Pole	2	
FB-Offset	-58	Deg
Inc-Mot	2048	Inc/Rev

Apply the power supply to the device, er	nable open
Description	7-segment display
The motor shaft rotates to the preset	
angle.	

The motor shaft stops at the new angle.

feed'.

Click the function 'start dc current

Switch on enable

Function

	0.000	0.000	mH
Ls-q	0,000	0,000	min
Ls-d	0,000	0,000	mH
Rs	123	123	mOhm
Lm	1,23	1,23	mH
Rm	0	0	mOhm
TC Stator		0,0	ms
TC Rotor		200,0	ms
FB-Offset	-70	-58	Deg

As long as the enable is closed, a new angle can be preset in the field 'motor parameter **FB-Offset'** on the left (yellow field). When opening the enable, the function is stopped.

### Note :

For further motor operation the correct value for FB-Offset must be entered and saved (level 0).

If the FB-Offset value is incorrect, the drive may rotate or move uncontrolled!



# 21.7 Analog offset (0x85 -6)

Offset adjustment of the analog inputs.

### **Execute function**

Apply voltages across the device, enable open

			text f6 0
Function	Message at NDrive	7-segment display	text f6 1
Click function 'start analog offset'		60	Text Button Auto Start 6
Switch on enable			text f6 3
Correct end		69	
			Status Text 9_0
Error switch-off			text f6 4
Enable switched on during the measuring process		66	Text Links 6 Text Rechts 6

When the adjusting process is started, 6-0 is shown in the 7-segment display. The adjusting process is finished when 6-9 is displayed.

### 21.8 Tacho offset (0x85 -7)

Adjustment of the segment offset error at brushless tacho systems.

### **Execute function**

Apply voltages across the device, enable open

Function	Message at NDrive	7-segment display
Click function 'start analog		70
offset'		
Switch on enable		
Correct end		79
Error switch-off		
Enable switched on during the		76
measuring process		
Movement at the rotor		77
detected		
No tacho connected		78

tacho offset	<b>_</b>	
text f7 0		
text f7 1		
Text Button	Auto Start 7	
Text Button text f7 3	Auto Start 7	
Text Button text f7 3 Status Text 9_0	Auto Start 7	
Text Button text f7 3 Status Text 9_0 text f7 4	Auto Start 7	

Sonderfunktionen, Regler gesperrt

analog offset

When the adjusting process is started, 7-0 is shown in the 7-segment display. The adjusting process is finished when 7-9 is displayed.

# 21.9 Calc from Motorplate (0x85-8)

Sonderfunktionen, Regler gesperrt    calc from motplate   Eingabe Motordaten, Einstellungen   Wenn CosPhi unbekannt, null eingeben			errt Jungen eingeben	Calculation Enter the sheet into	n of the motor data for asynchronous motors motor data of the type plate or the motor data the left column (highlighted in yellow).	I
Anzeige	Berechnur	ng Starten		After the c displayed	calculation is finished the resulting values are in the right column and saved in the device.	
Berech text f8	nung fertig 4	Text R	erhts 8	1		
Motor-P	arameter			Function	Description	ID
Ls-q	0,000	0,000	mH	Ls-q	Stator leakage inductance in $\mu$ H (without	0xb1
Ls-d	0,000	0,000	mH	•	comma), at ACIM Lsd = Lsq	
Rs	123	123	mOhm	Ls-d		0xbb
Lm	1,23	1,23	mH	Rs	Stator resistance in m $\Omega$ (without comma)	0xbc
Rm	0	0	mOhm	Lm	Main inductance in 10µH (without comma)	0xb3
TC Stator	r	0,0	ms	R-r	Rotor resistance in m $\Omega$ (without comma),	0xb4



200,0

-58

ms

Deg

TC- tator

**TC-Rotor** 

Bild 1: T-Modell, stationary,[2]

-70

TC Rotor

FB-Offset



Bild 2: inverses Gamma Modell, stationary,[2]



- Rr Rotor resistanceLso Stator leakage induct.
- iµ Current through Lm
- ict.  $\sigma$  Complete leakage fact.
- im Magnetization current

#### General information

constant

Various literature display motor models which are identical in principle. Abbreviations used in the diagrams may vary. Differences can only be found concerning physically measurable quantities (T-model) or further abstraction for simplified calculation models (inverse gamma model).

Lm/Rr in ms (without comma), rotor time

Some manufacturers provide additional data such as no. of poles, idle current at a specified idle voltage (= magnetization current), ohmic resistance of the stator winding, stator impedance at a specified frequency, as well as values referring to rotor quantities.

These manufacturer data are usually correct and helpful. The real, physical quantities can be measured through direct measuring for stator values and through indirect measuring for rotor values, i.e. by measuring the retroactive effect on the stator.

The graphic representation of the motor models does partly not refer to the real, physical quantity but to converted quantities.

0xb6

0xbd

#### **Basic procedure**

At operating mode FU (page setting 'type') for new or unknown motors it is possible to check the following assignment first: positive speed command value = clockwise rotating field U, V, W = clockwise rotation = positive actual speed value. Set the values on page 'settings' FU left field after U/f-characteristic. Operation in the rated point without load results approx. in the magnetization current.

#### **Optimization procedure**

Connect a load machine with aprox. 20 to 50 % rated torque. Setting of a corresponding torque on the scope side of the NDrive (step generator to torque, drive enabled).

Thus, a stationary speed is adjusted.

The Lm or Rr value can be changed when the machine rotates (T-rotor = Lm/Rr). The result is immediately effective in the control. The target is to optimize the T-rotor to a higher speed at the same load. At operation this results in a smaller current consumption at the same load torque.

The value of the T-rotor (in ms) is not updated by the NDrive until the offline-online process.

At a second stage Idnom (NDrive page 'speed') can be varied, field weakening not active (Vred = 0). This can be noticed during standstill (current = magnetization current). When the machine rotates thisvalue is also immediately effective. The target is again a higher speed at the same load. At operation this results in a higher final speed when reaching the voltage limit (max. modulation).

Compare the values achieved from the tests with existing manufacturer values. Save them and reset the drive (off-on). Check the values and functions again.

# 21.10 VdcBus Adjustment

#### From firmware FW466 onwards

The calibration is made in the factory. In case a component is exchanged it is necessary to re-adjust again.

Adjustment of measuring errors errors oft he bus circuit voltage measurement.

Sonderfunktionen, Regler sperren 2000	
[Fn9] Abgleich VdcBus Null 🗸 🗸	Zero point adjustment
Controller mit Endstufe	No power supply voltage!
Power Versorgung AUS	
	Bus circuit 0 V (to be short-circuit.)
START	Start adjustment via key START"
	After approx A seconds the value for
ldle	After approx. 4 seconds the value for
Sonderfunktionen, Regler sperren 10000	Slope error adjustment
[Fn10] Abgleich VdcBus Spannung 🛛 🗸	After the 0 adjustment it is necessary to adjust
Controller mit Endstufe	the slope error.
Power Versorgung EIN	
	With bus circuit voltage without ripple:
START	Measure the bus circuit voltage by means of a
	voltmotor and register the value in Kalibr
Idle	Start the adjustment
	Start the adjustment.
	After approx. 4 sec. the measurement value
Anna and Anna	for VdcBus is displayed (Num).
	In case there is no exact hus circuit voltage
Analog	
Kalibr. V	
Vdc-Bus 58062	Adjustment without power supply voltage:
_	Bus circuit voltage = 0 V
	Enter 0 V in the field "calibration" and start
	the adjustment.
Analog	
Kalibr. 320,0 V	Save the determined measured values
Vdc-Bus 58062	nermanently by means of the EPROM-STORE

# Oscilloscope

Overview

# 22 Oscilloscope

### 22.1 Overview



# 22.2 Oscilloscope settings

### Screen functions

Trigger settings



Option	Time basis (per grid)
Join	Pixels connected
Over	The display remains and is over-
	written
Zero	Zero line visible
Units	Display as num or real values
Trig	Trigger line visible
Label	Channel designation visible
AbsDe	
Screen colour	S
В	Oscilloscope background
К	Oscilloscope grid
Z	Oscilloscope zero line
Т	Oscilloscope trigger line

Trigger					
On	Chan 1	-			
Edge	Rise>Lev	-			
Level	100				
	Capture				
Buf	2000	•			
Run	Normal	-			
Timescalı	500ms	-			
Pre trig	25%	-			

		Function		
State	Colour	Status idle		
waiting (0)	red	Display of the last recording and waiting for a new triggering		
waiting (xx)	green	triggered, data are saved		
reading	blue	Reading of the data from the drive to the pc		
drawing		Display of the data on the		
idle	white	Frozen data after 'Stop capture'		
Run Stop	1	▶Run Stop		
Run		The oscilloscope recording is focused via the key field 'run capture'. The recording is started at		
Stop		The recording is cancelled via 'stop		
		capture and the display is frozen.		
Zoom		Zoom		
Zoom +		The screen content is enlarged		
Zoom -		The screen content is reduced		
File		File *.uof		
File left		Load the oscilloscope file from the pc		
File middle		Save the oscilloscope file into the pc		
File right		Save the oscilloscope file as excel file		
Trigger				
On		Selection of the channel for the		
Educ		trigger function		
Edge		Selection of the trigger function		
Level		i rigger level (numerical)		
Capture				
Buf		Resolution, horizontal pixels for all		
Run	+	Selection trigger switching function		
Timescale		Time unit per horizontal grid line		
Pre trig	1	Horizontal shifting of the trigger		
		line. Measured value display before the trigger line.		

	Value	Delta Value	Channel	Pos	U/Div		1. A.
1	1373 RPM	406 RPM	N cmd (ramp 🔻	0	20000	2	С
2	1364 RPM	1159 RPM	N actual 💌	0	20000	•	С
з		7,97 A	l cmd (ramp) 🔻	0	600	▼	C
4		7,50 A	l actual 💌	0	600	•	С
5	1	0	in Run (Frg) 🔻	0	2		С
6	18103	750	Vdc-Bus 💌	0	20000		C
7	2022	1398	V out 💌	0	4000		С
8		-	Off 🔻	0	30000		С
	Time 415ms	Delta 300ms					

# 22.3 Arrow key for the channel selection

Field	Function
Value	Value at the first cursor line (numerical or real)
Time	Time from the trigger line to the first cursor line
Delta Value	Difference values from the first to the second cursor
Delta (Time)	Difference time from the first to the second cursor
Channel:	All measured values from the selection table can be displayed on the
	oscilloscope. The drop-down menu opens by clicking the arrow key. The
	required measured value is selected and assigned to the channel no.
	The channel is switched off at 'off'.
	Channels which are not required must always be switched off! (Off)
Pos:	The value of 100 corresponds to a horizontal grid line.
	E.g.: At value 50 the zero line of the selected channel is shifted upwards by
	half a square.
U/Div:	Units for a horizontal grid line.
	E.g.: U/Div = 32768 at N cmd Ramp. (N max parameter = 3000 rpm)
	The numerical value (32768) of the speed command value corresponds to a
	horizontal line at 3000 rpm.
	At cursor request a horizontal line equals 100.
	Thus, the cursor value 100 corresponds to a speed of 3000.
Switch cabinet	The display of the channel is switched on and off.
	The switched-off channel remains in the background and is also saved.
Channel colours	A colour selection window is opened by clicking the colour key C.
	Select the new channel colour and accept it by clicking 'ok'.

### 22.4 Trigger settings

Test generator for the selection of command values in rectangle functions



Selection	
Current	Generator function is the current command value
Torque	Generator function is the torque command value
Speed	Generator function is the speed command value
Position	Generator function is the position command value
2Step	Selection 2 or 3 Step
Functions	
Step1	Value1 for current, speed, or distance
Time1	Time for value 1
Step2	Value 2 for current, speed, or distance
Time2	Time for value 2
Stop 3	Standstill value for current, speed, or distance
Time 3	Stopp time
Start Stop	Starts or stops the generator function
Note: The time in	outs (time) may vary acc. to the pc for values >2000.

Command value step functions are preset by means of the test generator. The ramps are determined via the parameter settings for the current and speed controller. When the controller enable (RUN/Frg) is active, the drive is started by clicking the field 'start' and it is stopped by clicking 'stop'. The functions can be selected as current, torque, speed, or position values. The value for 'stop' at current, torque, and speed should be 0 for standstill. 'Stop' can also be used like 'step(1,2)'.

#### Note: Maximal values for step1, step2, and stop

At current	+/- 330
At torque	+/- 32767
At speed	+/- 32767
At position	+/- 2147483647
At time	32767

### **Particular attention**

If the travel distance is limited it has to be ensured that the travel distance of the test settings is within the machine limits. At the test setting 'current' and 'torque' the drive may rotate at max. speed.

Over-speed may be achieved at field weakening.



# Oscilloscope

### 22.5 Display of measured values



The recording of the measured values is displayed with the selected colours.

The first vertical **trigger line** is tagged with an arrow symbol at the upper and lower edge of the screen.

The second vertical line is the first cursor line.

The active second cursor is displayed as horizontal and vertical crossline.

The measured values at the first vertical **cursor line** are displayed at **value** and saved. The measured value at the **second cursor (crossline)** are displayed in the fields **delta value** as difference values to the values at the first cursor.

The time from trigger line to the first cursor line is displayed at time. The time between the first cursor line and the second cursor line is displayed at **delta time**.

If the box **units** is ticked the displayed values are transformed from numerical to real values.

### 22.6 Parameters on the oscilloscope page

- Stro	n	_	– Drehz	zahl	
Кр	40		Кр	10	
Ti	800	μs	Ti	6	ms
TiM	85	96	Td	0	ms
xKp2	0	%	TiM	20	96
Kf	0		Kacc	0	96
Ramp	150	US	Filter	2	Num
l max pk	10	96	Row Acc	25	ms
I con eff	100	96	Rcw De	10	ms
T-peak	5	5	R-Lim	5000	ms
Pos			Nmax-1	3000	RPM
Кр	100		N-lim	100	96
Ti	300	ms	N-Lim+	99	96
Td	500	ms	N-lim-	-100	96
TiM	80	96			
– Field			- FU		-
ld nom	0	96	T-DC	0	ms
ld min	0	96	U-DC	0	96
Vired	100	%	Umin	0	96
Vkp	0		Fmin	0	Hz
V-Ti	0		Ueck	0	96
			Feck	0	Hz

The parameters of the page 'oscilloscope' can be changed during the test function.

The modifications are transferred to the current parameter set.

The result is immediately displayed on the oscillioscope screen after the next triggering.

### 22.7 Test operation



#### Test

Setting : Command mode = digital speed Direct input and execution of speed or torque. Selection via the drop-down menu. **Dis** : Software enable (only if hardware enable is active)

Position in numerical values.

#### Speed or torque

Enter the speed value. The entered speed is immediately processed when the key + or - is clicked. The command value is internally set to zero when the 'stop' key is clicked.

#### Position

Enter the position value. When clicking the key 'dest.' the drive travels immediately at the speed selected at Nmax(Nlim) to the entered position. When clicking the key 'calib.' the drive travels a reference cycle.

The entered position is imported as actual position and command value position via the key P.

#### Note :

Only for test function. The functions are directly executed!



# 23 Parameters

# 23.1 Parameter tables

# Motor value settings

Short symbol	Function	Setting range	Units	Note	<b>REGID</b> address
Туре	see type				
N nom	Rated motor speed	Type plate	rpm		0x59
F nom	Rated frequency	Type plate	0.1 Hz		0x05
U nom	Rated voltage	Type plate	1 V		0x06
U phi	Cosinus Phi	Type plate	Dec		0x0e
l max	Max. motor current	Type plate	0.1 A		0x4d
l nom	Continuous motor current	Type plate	0.1 A		0x4e
M-Pole	No. of motor poles	248	num		0x4f
Direction	Global rotation direction	Switch			0x5a.8
Brake	Brake with/without	Switch			0x5a.9
Brake Delay	Brake delay	0 to 1000	ms		0xf1
coast stop	Coasting when not enabled				0x5a.3
Feedback	see motor options	Selection			0x4a
F- Pole	No. of feedback encoder poles	212	num		0xa7
Offset	Phase angle feedback	0360	0.1 degree		0x44
Inc-Mot	Incremental encoder resolution	10248192	pulses/rpm		0xa6
2.Feedback	see motor options	Selection			0x4a
Inc-Out	see motor options	Selection			0x4a

### **Motor Type**

Short symbol	mbol Function		Address
Motor type			REGID 0xa4
EC (sinusoidal)	Synchronous servo motor sinusoidal voltage	0	Bit 810
AC (induction)	Asynchronous motor	1	
DC	DC motor	2	
EC (trapezoidal)	Synchronous servo motor trapezoidal voltage	3	

### Motor - Optionen

Short symbol	Function		Address
Feedback			REGID 0xa4
ROTENC_TTL	Incremental encoder TTL 5 V with rotor position tracks	0	Bit 04
RESOLVER	Resolver	1	
ABSENC_SC	Incremental encoder Sin/Cos 1Vss with commutation track	2	
ROT_TACHO	Rotor position encoder with brushless tacho	3	
ROT	Rotor position encoder (without tacho)	4	
DC_TACHO	DC tacho generator	5	
DC_ARM	Armature voltage (internal)	6	
BL_ARM	EC-AC-motor without tacho	7	
ENC_TTL	Incremental encoder TTL 5 V without rotor position	8	
ENC_SC	Incremental encoder Sin/Cos 1Vss without commutation track	9	
ABS_SC	Incremental encoder Sin/Cos 1Vss per motor pole pair	10	
DC_ARM_VIR	Without sensor (DC motor without tacho, without armature	11	
	voltage measuring)		
SLS	Without sensor	12	
SLS_SMO	not activated	13	
SLS_Usens	not activated	14	
Analn1-calc	not activated	15	
Analn2-calc	not activated	16	
PANA	Serial encoder system	17	

•

es
P
ta
5
Ĕ
ne
ar
ar
n

# Parameters

2. Feedback	Function		Address
Off		0	Bit 57
INC-IN	X8 as position input	1	
INC-OUT	X8 display only	2	
HAND	X8 as handwheel input	3	
Inc-Out			
Factor	Output factor with SINCOS		
Inc-Out	Output with resolver		

# Servo settings

Short symbol	Function	Setting range	Units	Note	REGID address
Туре	Display of the unit type				0x67
SNr.	Display of the serial no.	Type plate			0x62
Achse	Axis designation	Customer			0xf8
Mains sel	Voltage selection dc/ac	Switch			0x5a-19
Mains	Power voltage supply	Type plate	1 V		0x64
DC-BUS max	max. bus circuit voltage		1%		0xa5H
DC-BUS min	min. bus circuit voltage		1%		0xa5L
ZW-Monitor	Bus circuit measurement dig./anal.	Switch			0x5a-7
Regen	Internal/external ballast resistance	Switch			0x5a-1
Regen-P	Ballast resistance power		1 W		0x65L
Regen-R	Ballast resistance value( Ohm)		1Ω		0x65H
BTB Power	BTB message	Switch			0x5a-6
	with/without power voltage				
Takfreq.	see clock frequency	Selection			
Analog Out	Selection drop-down list	Selection			

# **Clock frequency settings**

Short symbol	Function		Address REGID
Clock frequency			0x5a
8kHz		0	Bit 2022
24kHz		1	
20kHz		2	
16kHz		3	
12kHz		4	
8kHz I16	internal 16 kHz	5	
4kHz I8	internal 8 kHz	6	
2kHz I4	internal 4 kHz	7	

Short symbol	Function	Setting range	Units	Note	REGID address
Mode	see command mode	Selection			
Cutoff-digital-cmd	Zero-zone digital command value	+/-32767	Num		0x1e
Format Ain1, Ain2	see command format	Selection			
Offset Ain1	Command value offset analog input 1	+/-32767	Num		0x2fL
Cutoff Ain1	Zero-zone command value analog input 1	+/-32767	Num		0x50
Scale Ain1	Scaling command value analog input 1	+/-32767	Num		0x2fH
Offset Ain2	Command value offset analog input 2	+/-32767	Num		0x2fL
Cutoff Ain2	Zero-zone command value analog input 2	+/-32767	Num		0x50
Scale Ain2	Scaling command value analog input 2	+/-32767	Num		0x2fH
Mode Ain1, Ain2	see Ain1, Ain2 mode	Selection			

### **Command (command values)**

### **Command mode**

Short symbol	Function	Address	
Command mode			REGID 0x36
Digital Speed	Digital speed command value of RS232 or BUS	0	Bit 1213
Analog Speed	Analog speed command value	1	
Analog Torque	Analog torque command value	2	
Digi + Ana Speed	Digital plus analog command value	3	

### **Command format**

Short symbol	Function	Address	
Command format Ain 1			REGID 0x36
Off	Open, not used	0	Bit 01
Cmd	Analog command value 1	1	
-Cmd	Analog command value 1 negated	2	
sq(cmd)	Analog command value 1 quadratic	3	
N-Limit	Analog input 1 as speed limit		Bit 15
Command format Ain2			Bit 23
Off	Open, not used	0	
+Cmd	Analog command value 2 added to the analog command value 1	1	
-Cmd	Analog command value 2 subtracted from the analog command value 1	2	
* Cmd	Analog command value 2 multiplied by the analog command value 1	3	
I-Limit	Analog input 2 as current limit		Bit 14

# Command mode range

Short symbol	Function		Address
Mode range Ain1			REGID 0x36
-10+10V	Command value plus-minus max. 10 V	0	Bit 45
0+10V	Command value plus max. 10 V	1	
420mA (+2V+10V)	Command value 4 to 20 mA at 500 Ohm	2	
Mode Range Ain2			Bit 89
-10+10V	Command value plus-minus max. 10 V	0	
0+10V	Command value plus max. 10 V	1	
420mA (+2V+10V)	Command value 4 to 20 mA at 500 $\Omega$	2	
### **Current controller parameter**

#### Command values, actual values, control errors (current)

Short symbol	Function	Setting range	Units	Note	REGID
					address
l man	Manual current command value	+/- 2048	Num		0x21
l cmd	Current command value	+/-2048	Num		0x26
I cmd ramp	Current command value after ramp	+/-2048	Num		0x22
lq actual	Actual active current value	+/-2048	Num		0x20
Id actual	Actual reactive current value	+/-2048	Num		0x28
l act	Total current - actual value	+/-2048	Num		0x20
I act monitor	Total current - actual value	+/-2048	Num		0x5f
	after display filter				
lq error	Active current control fault	+/-2048	Num		0x38
ld error	Reactive current control fault	+/-2048	Num		0x39
ld ref	Reference value	+/-2048	Num		0x23

# Current limits, ramps

Short symbol	Function	Setting range	Units	Note	REGID address
+l max	Current limit peak current positive	0100	%		0xc4
+l con	Current limit continuous current positive	0100	%		0xc5
-I max	Current limit peak current negative	0100	%		
-l con	Current limit continuous current negative	0100	%		
Tpeak	Tiem peak current	030000	ms		0xf0
I-lim-dig	Current limit switched via input	0100	%		0x46
I-red-N	Current limit controlled via speed	0100	%		0x3c
I-red-TD	Current limit controlled via output stage	032767	Num		0x58
	temperature				
I-red TE	Current limit controlled via rms current	032767	Num		0x4c
	(I2t)				
I-red-TM	Current limit controlled via motor	032767	Num		0xa2
	temperature				
I2t actual	Display rms current + time	032767	Num		0x25
I-lim actual	Display resulting current limit	032767	Num		0x48

#### **Output stage voltages**

Short symbol	Function	Setting range	Units	Note	REGID
					address
Vq	Internal calculated value FOC				0x29
Vd	Internal calculated value FOC				0x2a
Vout	Output voltage	0 to 4096			0x8a
Vred	Starting point field weakening				0x8b
Vkp	P amplification field weakening				0x8c
VTi	I time field weakening				0x8d
DC-Bus	Bus circuit voltage	0 to 32767			0xeb

#### Control parameters of the current controller

Short symbol	Function	Setting range	Units	Note	REGID address
КР	Proportional amplification	0 to 200	num	1=0.1	0x1c
Ti	Integration time	300 to 2000	ms	150	0x1d
TiM	Max. integration time memory	0 to 100	%	1	0x2b

#### Speed controller parameters

#### Command value, actual value, speed, torque

Short symbol	Function	Setting range	Units	Note	REGID
					address
Analog int Ain1	Analog input 1 internally processed				0xd5H
Analog int Ain2	Analog input 1 internally processed				0xd6H
Dig-Speed	Digital speed command value				0x31
Dig-Torque	Digital torque command value				0x90
N cmd	Speed command value	+/-32767	num		0x5d
N cmd Ramp	Speed command value after ramp	+/-32767	num		0x32
N actual	Actual speed value	+/-32767	num		0x30
N act monitor	Actual speed value after display filter	+/-32767	num		0xa8
N error	Speed control fault	+/-32767	num		0x33

#### Limits, ramps, speed, torque

Short symbol	Function	Setting range	Units	Note	REGID
					address
Ramp-sel	see selection ramp sel		Selection		
RCW-Acc	Acceleration positive speed	030000	ms		0x35L
RCW-Dec	Deceleration positive speed	030000	ms		0xedL
RCCW-Acc	Acceleration negative speed	030000	ms		0x35H
RCCW-Dec	Deceleration negative speed	030000	ms		0xedH
S-Form	see selection ramp form		Selection		
RCW-Lim	Delay emergency stop	030000	ms		0xc7
Nmax 100%	max. speed for 100%	600 to 50000	rpm		0xc8
N-Lim	Speed limiting	0100	%		0x34
N-Lim+	Positive speed limiting	0100	%		0x3f
N-Lim-	Negative speed limiting	0100	%		0x3e
Filter	Speed actual value filter	07	num		0x5e

# Control parameters of the speed controller

Short symbol	Function	Setting range	Units	Note	REGID address
КР	Proportional amplification	0 to 200	Num	1=0.1	0x2c
Ti	Integration time	5 to 100	ms	0.75	0x2d
Td	Rate time	1 to 10000	ms	0.75	0x2e
TiM	Max. integration time memory	0 to 100	%	1	0x3b

#### **Position controller parameters**

#### **Reference run**

Short symbol	Function	Setting range	Units	Note	REGID address
Speed to	Speed to the reference position	10 to 32000	num	1	0x76
Speed from	Loop speed	10 to 2000	num	1	0x77
Reso Ed					0x75
Dec-Ramp	Acc Ramp or Limit Ramp	Switch			

# Position controller Pos->Speed

Short symbol	Function	Setting range	Units	Note	REGID
					address
КР	Proportional amplification	0 to 200	num	1=0.1	КР
Z-Faktor					Z-Faktor
Ti	Integration time	10 to 500	ms	0.75	Ti
Td	Rate time	500 to 10000	ms	0.75	Td
TiM	Max. integration time memory	0 to 100	%	1	TiM

#### **Position controller parameters**

Short symbol	Function	Setting range	Units	Note	REGID address
Tol-wind	Proportional amplification	0 to 100	num	1=0.1	0xc9
Ref- Off	Zero offset	0 +/- 2147483647	num	1	0x72
ND-Scale	Display - factor		num	1	0xcb
ND-Offset	Display - offset		num	1	0xcd
Pos dest	Position target				0x6e
Pos cmd	Position command value				0x91
Pos actual	Actual position value				0x6d
Pos error	Position control fault				0x70
Inc-Out	Increment output				
Inc-ext	Increment 2. feedback				
Faktor-ext	Factor 2. feedback				0x7e

### Frequency converter parameters

# Frequency converter (FU) settings

Short symbol	Function	Setting range	Units	Note	REGID
					address
Start					
T-DC	dc magnetization time		ms		0x07L
I-DC	dc magnetization		1%		0x08L
Umin	min. voltage		0.1 %		0x0aL
F min	min. frequency		0.1 Hz		0x0bL
U eck	Voltage at rated speed		0.1 %		0x0cL
F eck	Frequency at rated voltage		0.1 Hz		0x0dL
Stop					
T-DC	dc magnetization time		ms		0x07H
I-DC	dc magnetization		1%		0x08H
Umin	min. voltage		0.1 %		0x0aH
F min	min. frequency		0.1 Hz		0x0bH
U eck	Voltage at rated speed		0.1 %		0x0cH
F eck	Frequency at rated voltage		0.1 Hz		0x0dH
F-sh	see F-shape				

#### F-shape frequency converter settings

Short symbol	Function		Address
			REGID 0x0f
F-sh Start			Bit 12
linear	presently only linear	0	
quad/2		1	
quad		2	
opt		3	
F-sh Stop	presently only linear		
linear			
quad/2			
quad			
opt			

### Logic parameters

#### Logic BIT

Short symbol	Function	Address
		REGID 0xD8
Limit 1	Digital input limit 1 active	Bit 0
Limit 2	Digital input limit 2 active	Bit 1
Din 2	Digital input Din 2 active	Bit 2
Din 1	Digital input Din 1 active	Bit 3
FRG (RUN)	Hardware enable active	Bit 4
		Bit 5
		Bit 6
		Bit 7
Dout 1	Digital output Dout 1 connected	Bit 8
Dout 2	Digital output Dout 2 connected	Bit 9
BTB (Rdy)	Hardware relay output BTB-Rdy connected	Bit 10
GO	Internal enable GO active	Bit 11
Dout 3	Digital output Dout 3 connected	Bit 12
Dout 4	Digital output Dout 4 connected	Bit 13
		Bit 14
		Bit 15

# Logic comparison variable

Short symbol	Function	Setting range	Units	Note	REGID
					address
0	Logic signal zero	1/0	Logic		
1	Logic signal one	1/0	Logic		
VAR1					0xd1
VAR2	Numerical value of the entered variable	1/22767	num		0xd2
VAR3	fields	+/-52/07	num		0xd3
VAR4					0xd4
Ain 1	Analog value input Ain1	+/-32767	num		
Ain 2	Analog value input Ain2	+/-32767	num		

### Interface settings

#### **CAN-BUS**

Short symbol	Function	Setting range	Units	Note	REGID address
Rx ID	Receiving address		dec.	Default 201	0x68
Tx ID	Sending address		dec.	Default 181	0x69
BTR	Transmission rate	see table	hex		0x73

#### Messages, errors, warning messages

#### **Error BIT**

Error message	Fault	Address
NOREPLY-No RS	RS232 interface not plugged-in or faulty	
		REGID 0x8f
BADPARAS	Parameter damaged	Bit O
POWER FAULT	Output stage fault	Bit 1
RFE FAULT	Defective safety circuit (only active with RUN)	Bit 2
BUS TIMEOUT	Transmission fault BUS	Bit 3
FEEDBACK	Faulty encoder signal	Bit 4
POWERVOLTAGE	Missing power voltage supply	Bit 5
MOTORTEMP	Motor temperature too high	Bit 6
DEVICETEMP	Device temperature too high	Bit 7
OVERVOLTAGE	Overvoltage >1.8 x UN	Bit 8
I_PEAK	Over-current 300 %	Bit 9
RACEAWAY	Racing (without command val., wrong direction)	Bit 10
USER	User – fault selection	Bit 11
I <sup>2</sup> R	Overload	Bit 12
RESERVE		Bit 13
HW-FAIL	Firmware is not compatible with the hardware	Bit 14
BALLAST (device dependent)	Overload of the ballast circuit	Bit 15

# Warning BIT

Error message	Fault		Address	
			REGID 0x8f	
WARNING_0	Inconsistent device determination		Bit 16	
ILLEGAL STATUS	RUN signal disturbed, EMI		Bit 17	
WARNING_2	RFE signal inactive (without RUN)		Bit 18	
			Bit 19	
			Bit 20	
POWERVOLTAGE	Power voltage too low or missing		Bit 21	
MOTORTEMP	Motor temperature >87 %		Bit 22	
DEVICETEMP	Device temperature >87 %		Bit 23	
OVERVOLTAGE	Overvoltage >1.5 x UN		Bit 24	
I_PEAK	Over-current 200 %		Bit 25	
			Bit 26	
			Bit 27	
I2R	Overload >87 %		Bit 28	
			Bit 29	
			Bit 30	
BALLAST (device dependent)	Overload of the ballast circuit >87 %		Bit 31	

#### State BIT

State display	Description	Address
		REGID 0x40
Ena	Drive enable (Hardware enable)	Bit 0
NCR0	Speed command value = 0 (drive stopped)	Bit 1
Lim+	Limit switch plus assigned	Bit 2
Lim-	Limit switch minus assigned	Bit 3
ОК	Drive in order (no uncontrolled reset)	Bit 4
lcns	Current limit reduced to continuous current	Bit 5
T-Nlim	Speed limited torque mode	Bit 6
P-N	Position control	Bit 7
N-I	Speed control	Bit 8
<n0< td=""><td>Speed inferior to 0.1 %</td><td>Bit 9</td></n0<>	Speed inferior to 0.1 %	Bit 9
Rsw	Reference input selected	Bit 10
Cal0	Reference run (Bit 11+Bit12 = Ref. loop travel)	Bit 11
Cal	Reference position identified	Bit 12
Tol	Position within tolerance window	Bit 13
Rdy	Ready (BTB,Rdy)	Bit 14
Brk	active brake	Bit 15
SignMag	inverted command value	Bit 16
Nclip	Speed limiting via switch	Bit 17
Nclip+	Positive speed limiting via switch	Bit 18
Nclip-	Negative speed limiting via switch	Bit 19
Ird-Dig	Current limiting via switch	Bit 20
luse-rchd	Active current reduction	Bit 21
Ird-N	Current reduction via speed	Bit 22
Ird-TI	Current reduction via output stage temperature	Bit 23
Ird-TIR	Current limiting to continuous current via output stage	Bit 24
	temperature	
>2Hz	Current reduction for frequencies inferior to 2Hz	Bit 25
Ird-TM	Current reduction via motor temperature	Bit 26
Ird-ANA	Current limiting via analog input 2	Bit 27
lwcns	Current value lxt superior to 87 %	Bit 28
RFE-plus		Bit 29
rsvd2:1		Bit 30
Handrad	Handwheel input selected	Bit 31

## **Measured values**

Short symbol	Function	Unit	Range	ID address
Ncmd Ramp	Speed command value after ramp and limit			0x32
N actual	Actual speed value			0x30
Icmd Ramp	Current command value after ramp and			0x26
	limit			
I actual D	Actual current value D			0x28
I actual Q	Actual current value Q			0x27
l2t	Capacity I2xt			0x45_L
P-Motor	Motor power			0xf6
DC-BUS	Bus circuit voltage			0xeb
P-Regen				0x45_H
Tmotor	Effective motor temperature			0x49
Tigbt	Effective output stage temperature			0x4a
Tair	Effective air temperature in the servo			0x4b
Ireda	Effective current limit			0x48

## Switch and selection settings Mode BIT

Short symbol	Function	Address
		REGID 0x51
Reserve		Bit 0
SPEED = 0	Drive stop	Bit 1
ENABLE OFF	Drive disabled	Bit 2
CANCEL CAL-CYCLE	Reference run stopped	Bit 3
d(status)->CAN		Bit 4
I-clip on	Current limit in % of the type current active	Bit 5
N-clip on	Speed limiting (positive and negative)	Bit 6
Mix ana on	Digital plus analog speed command value	Bit 7
Allow sync		Bit 8
Handwheel	2. feedback as handwheel	Bit 9

# Core option BIT

Short symbol	Function	Address
		REGID 0x5a
DC-BUS-comp	Analog measured bus circuit value influences Uout	Bit 0
BALLAST_EXT	External ballast resistor	Bit 1
TJ_SPECIAL	Sensor specialties	Bit 2
coast stop	Coast Stop active, coasting to standstill	Bit 3
IISTINVERSE	Inverted actual current value polarity (factory-setting active for	Bit 4
	DS450, BAMO-D3)	
REFSOFT	Reverse ramp for reference run set from Limit to ,Dec'	Bit 5
NOUESP_BTB	BTB signal also at under-voltage error messages	Bit 6
ANA_UESP	Analog ZW-voltage watchdog	Bit 7
BTB_DELAY	Enable delay	Bit 8
Hxinv	Inverted sequence of the Hall signals	Bit 9
H2inv	Hall signal 2 inverted	Bit 10
OL_comp	Sensor specialties	Bit 11
MotorType	Motor selection	Bit 12
MotorType	Motor selection	Bit 13
ANA_0up	Measuring range (Vdc bus, Vdc-Bat) 0 to 5 V (0 = 2.5 to 5 V)	Bit 14
lowbd	Interface RS232 9600 Baud	Bit 15
S-ramp	Selection ,S-ramp' active	Bit 16
4-ramp	Selection ,4 ramps' active	Bit 17
MotBrake	Selection ,with brake' active	Bit 18
ACDC		Bit 19
PWM-Frequenz	Clock frequency setting	Bit 20
PWM-Frequenz	Clock frequency setting	Bit 21
PWM-Frequenz	Clock frequency setting	Bit 22
NTC		Bit 23
delta	Motor phase triangle	Bit 24
DC_1QdirVolt	DC 1-quadrant, direct voltage regulation PWM	Bit 25
DC_field	DC field controller	Bit 26
DEAD_2	Dead band *2	Bit 27
block	Block current at ROT feedback	Bit 28
DC_1QMV	DC 1-quadrant, min. switching losses	Bit 29
DC_1Q3P	DC 1-quadrant, no High-Side, parallel -UB switch	Bit 30
Frd<10Hz	<10 Hz switching frequence set to 4 kHz	Bit 31

#### **Monitor parameters**

Short symbol	Function	Unit	Range	ID address
Ncmd Ramp	Speed command value after ramp and	num	0 to +/-32767	0x32
	limit			
N actual	Actual speed value	num	0 to +/-32767	0x30
Icmd Ramp	Current command value after ramp and	num	0 to 600	0x26
	limit			
lact monitor	Actual current value (filtered)			
I actual D	Actual current value D (reactive current)	num	0 to 600	0x28
I actual Q	Actual current value Q (active current)	num	0 to 600	0x27
l2t	Capacity I2xt	num	0 to 4000	0x45_L
P-Motor	Motor power	num	0 to 4000	0xf6
DC-BUS	Bus circuit voltage	num	0 to +/-32767	0xeb
P-Regen	Ballast power	num	0 to 4000	0x45_H
Tmotor	Effective motor temperature	num	0 to 32767	0x49
Tigbt	Effective output stage temperature	num	0 to 32767	0x4a
Tair	Effective air temperature in the servo	num	0 to 32767	0x4b
Ireda	Effective current limit	num	0 to 600	0x48
Vout	Output voltage	num	0 to 4000	0x8a