

DIGITAL SERVO DRIVES FOR BRUSHLESS AC MOTORS



XtrapulsEasy™

User Guide

WARNING

This is a general manual describing a series of servo drives having output capability suitable for driving AC brushless sinusoidal servo motors.

Please see also:

- **XtrapulsEasy™ User Guide** for the operation of the drive (commissioning, configuration, ...)
- **XtrapulsEasy™ STO** for the Safe Torque Off function
- **Gem Drive Studio software Quick Start** manual for the drive parameterization.

Instructions for storage, use after storage, commissioning as well as all technical details require the MANDATORY reading of the manual before getting the drives operational.

Maintenance procedures should be attempted only by highly skilled technicians having good knowledge of electronics and servo systems with variable speed (EN 60204-1 standard) and using proper test equipment.

The conformity with the standards and the "CE" approval is only valid if the items are installed according to the recommendations of the drive manuals. Connections are the user's responsibility if recommendations and drawings requirements are not met.



Any contact with electrical parts, even after power down, may involve physical damage. Wait at least 10 minutes after power down before handling the drives (a residual voltage of several hundreds of volts may remain during a few minutes).



Caution: Hot surface, risk of burns (wait for cooling after power down).

**ESD INFORMATION (ElectroStatic Discharge)**

This drives are designed for being best protected against electrostatic discharges. However, some components are particularly sensitive and may be damaged if the drives are not properly stored and handled.

STORAGE

- The drives must be stored in their original packaging.
- When taken out of their packaging, they must be stored positioned on one of their flat metal surfaces and on a dissipating or electrostatically neutral support.
- Avoid any contact between the drive connectors and material with electrostatic potential (plastic film, polyester, carpet...).

HANDLING

- If no protection equipment is available (dissipating shoes or bracelets), the drives must be handled via their metal housing.
- Never get in contact with the connectors.

**WASTE DISPOSAL**

In order to comply with the 2002/96/EC directive of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE), all devices are labelled with a sticker symbolizing a crossed-out dustbin as shown in Appendix IV of the 2002/96/EC Directive.

This symbol indicates that devices shall be eliminated by selective disposal and not with household waste.


All electrical industrial automatisms which lifetime is coming to its end are Waste Electronic and Electrical Equipment (WEEE) according to article R543-172 of the French Environmental Code.

WEEE classification of this products ®	Categorie 9: Monitoring and control instruments
--	---



Information and sorting instructions regarding INFRANOR® products

	Type of waste	Waste category	Waste management
Packaging	Cardboard	Recyclable waste	Waste disposal centre / collection point of recyclable waste
Documents	Paper	Recyclable waste	Waste disposal centre / collection point of recyclable waste
Mechanics	Metal	Recyclable waste	Waste disposal centre / metal collection point
Heatsinks	Metal	Recyclable waste	Waste disposal centre / metal collection point
Electronical boards and components	WEEE (Waste Electronic and Electrical Equipment)	Dangerous industrial waste	France: www.reylum.com/recycler/industrie/ Abroad: Country-specific regulation

 Sorting instructions may vary according to regions / countries.

INFRANOR does not assume any responsibility for any physical or material damage due to improper handling or wrong descriptions of the ordered items.

Any intervention on the items, which is not specified in the manual, will immediately cancel the warranty.

INFRANOR reserves the right to change any information contained in this manual without notice.

Content

CONTENT	4
CHAPTER 1 - GENERAL DESCRIPTION	5
1.1 - INTRODUCTION	5
1.2 - ARCHITECTURE	5
1.3 - OTHER DOCUMENTS	6
CHAPTER 2 - COMMISSIONING	7
2.1 - PC SOFTWARE INSTALLATION	7
2.1.1 - <i>Installation</i>	7
2.2 - STARTING THE SOFTWARE	10
2.3 - DRIVE COMMUNICATION	10
2.4 - PARAMETER SETTING	11
2.4.1 - <i>Configuration of the drive enabling</i>	11
2.4.2 - <i>Configuration of the motor</i>	12
2.4.3 - <i>Position sensors</i>	18
2.4.4 - <i>Servo loops adjustment</i>	18
2.4.5 - <i>Quick test of the servo drive</i>	23
2.4.6 - <i>Adding the motor into the catalog</i>	24
2.4.7 - <i>Logic Inputs</i>	24
2.4.8 - <i>Logic Outputs</i>	26
2.4.9 - <i>Braking Resistor</i>	26
2.5 - DRIVE PARAMETER SAVING	26
2.6 - OSCILLOSCOPE	27
2.7 - DIALOG TERMINAL	27
CHAPTER 3 - REFERENCE	28
3.1 - CANOPEN COMMUNICATION	29
3.1.1 - <i>Communication objects</i>	29
3.1.2 - <i>Network Initialisation</i>	45
3.2 - DEVICE PROFILE	48
3.2.1 - <i>Device Control</i>	48
3.2.2 - <i>Drive Parameters</i>	72
3.2.3 - <i>Operation Modes</i>	116
3.2.4 - <i>Application Feature</i>	161
3.2.5 - <i>Maintenance</i>	176
3.3 - OBJECT LIST	180

Chapter 1 - General Description

1.1 - INTRODUCTION

XtrapulsEasy all-digital drives with sinusoidal PWM control are servo drives that provide the control of brushless AC motors.

The standard control interface can be:

- CANopen,
- Analog.

Series XtrapulsEasy drives are dedicated to basic applications that do not have a high level of requirements in terms of functionalities and where cost effectiveness is very important.

XtrapulsEasy drives are delivered as standard with the integrated protection **Safe Torque Off : STO SIL 1**.

The XtrapulsEasy can be used in following typical applications:

- Axes controlled by CANopen fieldbus according to the DS402 protocol,
- Stand-alone operation as a sequencer with control by means of logic I/Os,
- Traditional analog speed drive or analog torque drive with +/- 10 V command.

The configuration and parameterization software tool Gem Drive Studio allows a quick configuration of the XtrapulsEasy drives according to the target application.

In this manual, we will use the generic and standard vocabulary to describe these variables. The variables are specified as "parameters" from the communication side.

Each parameter is identified by:

- an Index number and a Sub-index number,
- a Name.

Each parameter has the following properties:

- Access type: it is possible to read it, to write it....; "ro" means "read only" , "rw" means "read & write".
- Length: byte, word (16 bit), long (32 bit).
- Possibility or not to access the parameter by using fast communication CANopen services (Process Data Object service PDO). If yes, the field "PDO mapping" of the object dictionary will be "yes".

Convention: A numerical field can be filled-in with numerical values described as "hexadecimal" or "decimal". An hexadecimal value will be written "0xvalue".


1.2 - ARCHITECTURE

XtrapulsEasy is a freely configurable drive.

The drive configuration includes servo-loop parameters, motor and sensor parameters, communication parameters and I/O configuration parameters. The configuration parameters can be stored into the drive non-volatile memory.

The **XtrapulsEasy** drive can be controlled via the CANopen fieldbus, via the analog input (analog torque or speed drive), or via the digital I/Os (stand-alone positioner) according to the selected operation mode.

The following diagram describes the functional architecture of the **XtrapulsEasy** drive:



1.3 - OTHER DOCUMENTS

- XtrapulsEasy STO manual
- XtrapulsEasy Installation guide
- Gem Drive Studio Quick Start manual

Chapter 2 - Commissioning

This chapter describes the commissioning procedure of the drive by means of the "Gem Drive Studio" software.



CAUTION !

Do not perform the drive parameterization by means of both "Gem Drive Studio" software tool and CANopen bus at the same time.

2.1 - PC SOFTWARE INSTALLATION

2.1.1 - Installation

The **Gem Drive Studio** software is PC compliant under Windows® and allows an easy parameterization of the **Xtrapuls** drive.

Please see our website www.infranor.com for downloading the "Gem Drive Studio" software.

Minimum Configuration

The use of the **Gem Drive Studio** software requires the minimum PC configuration described below:

- Pentium III processor,
- 512 MB RAM,
- 15" screen, 256 colour screen, 1024x768 resolution
- Keyboard + mouse
- Windows® XP Service pack2 operating system
- Microsoft .NET Framework V3.5 or V4.0 installed
- 55 MB available on hard disk
- RS232 cable or USB/RS232 adapter cable or CAN IXXAT peripheral.

Restrictions

Under Windows 7 Professional 64 bit, the Service Pac 1 must be installed.

Important note: If using a USB/RS232 adapter, it is highly recommended to choose an industrial product rather than a consumer product, because of reliability and performances. It is in particular mandatory to have shielded cables (see application note regarding the use of USB/RS232 adapters).

2.1.1.1 - Installation procedure

- Unzip the GemDriveStudioVx.xx.zip file in a directory.
- Execute the Setup.exe file from this directory and follow the installation instructions.

2.1.1.2 - Important notes


- A. Before installing the new **Gem Drive Studio** version, we strongly advise to uninstall the former versions:
 - Select "Parameters", then "Control panel" in the "Start" menu of Windows,
 - Click on the "Add/remove program" icon and select "Gem Drive Studio" in the list, then click on "Add/remove".

Former versions can also be uninstalled from the menu "Start/Gem Drive Studio/Uninstall Gem Drive Studio".

- B. If the installation program is detecting that files already installed on the hard disk are more recent than those of the installation, we advise to keep these hard disk files.
- C. For a correct operation of the software tool, use ONLY the dot "." as decimal separator when entering digital values. Do not use any thousands separator.
- D. The installation of **Gem Drive Studio** under Windows XP, Vista or Seven requires the opening of an Administrator session. The software can later be used by users having rights but not mandatorily administrator rights.
- E. Import module of old projects
From version 4.X of the software, important changes have been introduced into the organization of the installed files for allowing the use of the software by people without administrator rights. Consequently, some files (configuration, passwords, motors, projects) which have been created with a former software version (3.X) cannot be accessed anymore from version 4.x. But a module has been implemented into the installer which allows importing these older files.
- F. For any complementary information regarding the installation, please see the "readme.txt" file. This file also contains the historical background of the software evolutions.

Architecture of the software

The software is made of several independent software modules. Each of them can communicate with the drive(s) via a communication server.



- The server is automatically started when a client module is trying to establish a communication with a drive.
- The server is commissioning the drivers of the hardware peripherals.
- The server stops when the last connected client is stopped.

The format of the exchanged data is the same whichever the communication type (RS232, CAN, ...).

2.2 - STARTING THE SOFTWARE

User levels

When starting the software, various user levels can be selected. The drive parameter modification levels are protected by passwords. **Administrator** is the highest level with full access.

Passwords

The Administrator can change all passwords by using the Tools/User identification menu. The default **password** for the administrator level is "admin".

Project management

The **Gem Drive Studio** software allows the parameterization of all **Xtrapuls** drives for a given application. All **Xtrapuls** drives of a given application, connected together via CANopen, are included in the same **project**. Each **Xtrapuls** drive of the project is identified by a **node ID** which is coded in the drive. The **Xtrapuls** drive node ID code values must all be different from each other in the same project.

The different software commands allow:

- Creating a project,
- Opening an existing project,
- Adding and/or removing axes in the project,
- Archiving/Unarchiving a project,

Axis directory

For each new axis of the project, the software creates, in the project file directory, a new directory with the axis name. There will then be one directory per axis and each of these directories will contain the parameter files and the sequence files.

Object dictionary

Each parameter (object) of the drive can be defined by an **Index**, a **Sub-index** and several properties (Save type, Data type, Unit, Min value, Max value, Default value). The drive supported object list with the corresponding properties is the **object dictionary** file in XML format. This file, named **EEDS** (for Extended Electronic Data Sheet), is used by Gem Drive Studio to read and write parameters on the drive. A Gem Drive Studio software command allows the import of an EEDS file to the EEDS library.

Starting Gem Drive Studio

- Start the software with the **Administrator** level.
- Create the **project**:
 - Define a project name
 - Select an output directory
 - Define all the axes of the application.
- Define the different project **axes**:
 - Select the device type
 - Define the axis name
 - Identify the Node ID for this axis

Once a project created, each axis can be independently selected by using the tree structure.

2.3 - DRIVE COMMUNICATION

Powering the drives

Please see manual "[Installation Guide](#)" before switching on the drives for the first time. For switching on the drives, proceed as follows:

- Switch on the +24 V auxiliary supply:
The red front panel LED "**ERR**" must be blinking ("Undervolt" error displayed).
The AOK output is closed. It is then possible to control the Power ON relay.
- Switch on the power supply:
The red **ERR** LED must be unlit. The drive is ready to be enabled.

Starting the communication

The **Gem Drive Studio** software can communicate with an **Xtrapuls** drive by using either the RS232 serial link or the CANopen fieldbus.

- Connect the serial link RS232 or the CANopen fieldbus between the PC and one drive of the application,
- Start the **Gem Drive Studio** software on the PC,
- Select the **Scan** function for starting the communication,
- Select the drive node ID (the default node ID value is 1),
- Select the communication interface between the drives and the PC (Serial link or CANopen bus),
- Start the communication.

All **Xtrapuls** drives of a given application can be connected together via CANopen. In this case node ID values must be different from each other.

- Connect sequentially to each drive as described above,
- Set the node ID code value in GemDriveStudio software: menu "Tools", sub menu "Node ID setting" (node ID value must be unique for each drive),
- Save the new node ID in the drive parameter file,
- Switch off and on again all the drives,
- Select the **Scan** function for starting the communication,
- Select the drives node ID list,
- Select the communication interface between the drives and the PC (Serial link or CANopen bus),
- Start the communication.

Remarks:

The default value of CAN bus baudrate is 1 Mbit.

The CAN bus baudrate can be set the same way as for the node ID via Gem Drive Studio (Tools / CAN bus speed setting).

The new baudrate is effective only after saving in drive parameter file and switching off and on the drive.

2.4 - PARAMETER SETTING

This chapter describes the parameterization procedure of the drive by means of the "Gem Drive Studio" software.

2.4.1 - Configuration of the drive enabling

The IN4 physical input is internally connected to the Inhibit input. This input is used for the drive STO function operation. It must be set to logic 1 (24V) in order to enable the drive power stage.

When "Enable control by **SOFTWARE**" is selected, the drive is enabled and disabled by using the control word (On/Off command in GemDriveStudio or fieldbus control).

When "Enable control by **HARDWARE**" is selected, the drive can be enabled and disabled by using the Enable input. In this case, the Enable input must be connected to a physical input (IN1 to IN3).

The drive can also be enabled and disabled by using directly the IN4 input internally connected to Inhibit. In this case **Enable by hardware** must be configured on **High level** (the **Rising edge** configuration is not operating).



CAUTION !

This configuration is not suitable for the drive STO function operation.

The **AutoStart** selection allows setting the control word bit 4 with the hardware enable signal. This selection is useful for standalone application with the sequence control mode.

If the motor is operating in sensorless control, a phasing procedure is automatically executed at the drive enabling. This phasing introduces a delay of about 2 seconds before the drive switches into "operation enabled" status. The phasing may generate a motor displacement with maximum amplitude equal to one pole pitch.

2.4.2 - Configuration of the motor

If the motor is referenced in the **Gem Drive Studio** motor catalog, it can be simply selected in the proposed motor list.

If the motor is not referenced in the **Gem Drive Studio** motor catalog, the motor parameters can be manually adjusted or calculated by using the drive's built-in procedures: current loop calculation, auto-phasing. The motor can then be referenced in the **Gem Drive Studio** motor catalog by using the **Add new motor** command (see **Gem Drive Studio** quick start manual). The motor and the position sensor parameter values are manually entered and then saved in the **Gem Drive Studio** motor catalog with a new motor reference.

2.4.2.1 - Selection in the motor list

In the motor list, select the motor used in the application. The motor selection will automatically set the following drive parameters: position sensor (resolver or encoder), thermal sensor, current limits, speed limit, current loop gains, and motor control parameters. Servo loop gains are also calculated according to the motor inertia value (load inertia is not considered).

Check that the thermal sensor calibration is complying with the motor application and modify the threshold values if necessary.

Check that the current limit and the I²t protection adjustment are complying with the motor application, and modify them if necessary.

Check that the motor speed limit is complying with the application and reduce its value if necessary.

If external inductances are serially connected with the motor winding for filtering, renew the current loop gain calculation by using the total value of the phase-to-phase inductance.

If the position sensor adjustment (resolver or HES) has been modified, the auto-phasing procedure can be used to find the new adjustment (position offset).

2.4.2.2 - Manual motor configuration

If the motor configuration must be manually made (motor is not referenced in the **Gem Drive Studio** catalog), adjust first the position sensor parameters (resolver, encoder, HES, or sensorless) and then the motor parameters.

The required motor data for the manual setup are listed below:

- Motor current limits: rated current and peak current
- Motor speed limit
- Motor pole pairs
- Motor winding inductance
- Motor torque constant (for HES only feedback or sensorless control)
- Motor inertia (for HES only feedback or sensorless control)
- Motor electrical time constant (for sensorless control)
- Motor winding resistance (for sensorless control)
- Motor Emf constant (for sensorless control)

2.4.2.2.1 – Position sensor configuration

Position Feedback Selection

Select the position sensor currently mounted on the motor (resolver, encoder, HES) or select sensorless control operation. The position sensor mounted on the motor is used by the drive for the motor torque or force control and for the speed regulation loop.

Select the position sensor to be used for the position regulation loop in the drive, according to the application. Generally, the position regulation loop is using the motor position sensor (same sensor selection as in the previous case). However, for specific applications (motor sensorless control), the position sensor to be used for the position regulation loop can be directly mounted on the mechanical load.

Resolver input configuration

Select **Enable resolver input** if a resolver is connected to the drive. Otherwise, the **Enable resolver input** can be unselected.

A **Transmitter** resolver is supplied by the drive modulation signal at 8 kHz. Transformation ratios from 0.3 to 0.5 are acceptable. The modulated Sine and Cosine signals of the resolver are connected to the drive “feedback” input.

Enter the **Pole pairs** for a rotating resolver: number of Sine or Cosine signal periods over one shaft revolution (generally, the value is 1). This parameter affects only the motor RPM speed display.

Adjust the resolver **Zero mark shift** and **Zero mark width** parameter values. The resolver provides one zero mark per pole pair.

Select **Reverse position** in order to reverse the resolver counting direction, if required.

Encoder input configuration

Select **Enable encoder input** if an encoder is connected to the drive. Otherwise, the **Enable encoder input** can be unselected.

Select the appropriate encoder type:

- TTL encoders refer to square quadrature signals electronically compatible with RS422 standard.
- Hall Effect Sensors (HES) refer to commutation channels for the motor current commutation. Hall effect sensor signals are adapted to the motor pole pairs.

Incremental encoder setting:

Enter the **Resolution** parameter value according to the encoder mounting and the mechanical ratio for a given application.

- If the encoder is directly mounted on the motor: **Resolution** = 4 x number of encoder signal periods per shaft revolution for a rotating motor or number of encoder signal periods per pole pitch for a linear motor.
- If the encoder is coupled to the motor according to a mechanical ratio, the value of the mechanical ratio must be considered for the **Resolution** parameter calculation.

Enter the **Zero Mark pitch** parameter value if the encoder has got a Zero mark channel. **Zero Mark pitch** is the number of encoder increments between 2 successive zero mark signals. If the encoder is not equipped with a Zero mark channel, set **Zero Mark pitch** value at 0.

Select **Reverse direction** in order to reverse the counting direction of the encoder, if required.

Adjust the encoder **Zero mark shift** and **Zero mark width** parameter values if the encoder has got a zero mark channel.

Note: With an incremental encoder only, a motor phasing procedure must be executed at each drive power up before the motor enabling.

Incremental encoder + HES setting:

Enter the **Resolution** parameter value according to the encoder mounting and the mechanical ratio for a given application.

- If the encoder is directly mounted on the motor: **Resolution** = 4 x number of encoder signal periods per shaft revolution for a rotating motor or number of encoder signal periods per pole pitch for a linear motor.
- If the encoder is coupled to the motor according to a mechanical ratio, the value of the mechanical ratio must be considered for the **Resolution** parameter calculation.

Enter the **Zero Mark pitch** parameter value if the encoder has got a Zero mark channel. **Zero Mark pitch** is the number of encoder increments between 2 successive zero mark signals. If the encoder is not equipped with a Zero mark channel, set **Zero Mark pitch** value at 0.

The parameters **HES type** and **Reverse HES tracks** depends on the HES signal wiring and mechanical mounting. They are automatically calculated when the Auto-phasing procedure is performed.

Select **Reverse direction** in order to reverse the counting direction of the encoder, if required.

Adjust the encoder **Zero mark shift** and **Zero mark width** parameter values if the encoder has got a zero mark channel.

HES only setting:

Enter the motor **Pole pair** value according to the motor catalogue.

The parameters **HES type** and **Reverse HES tracks** depends on the HES signal wiring and mechanical mounting. They are automatically calculated when the Auto-phasing procedure is performed.

Select **Reverse direction** in order to reverse the counting direction of the encoder, if required.

Adjust the encoder **Zero mark shift** and **Zero mark width** parameter values if the encoder has got a zero mark channel.

Sensorless control configuration

Select **Enable sensorless control** for the drive operation without motor position sensor. Otherwise, the **Enable sensorless control** can be unselected.

For the motor sensorless control, its electrical characteristics are required.

-Enter the motor **Pole pair** value according to the motor catalogue.

-Enter the motor **Electrical time constant** value according to the motor catalogue.

-Enter the motor **Phase-phase resistance** value according to the motor catalogue.

-Enter the motor **Emf constant** value according to the motor catalogue. This parameter corresponds to the rms phase-phase voltage at 1000 rpm. The parameter value is equal to $60,46 \times \text{Motor torque constant (Nm/A)}$.

-Enter the motor **Inductance ratio** value. This parameter refers to the motor inductance variation according to the rotor position. If the value is not indicated in the motor catalogue, set the parameter value to 0.

-Enter the motor **Low speed threshold** value. This parameter defines the motor speed value for the commutation between the "sensorless frequency control" (SFC) at low speed and the "sensorless vector control" (SVC) over the threshold value. The parameter is defined as the higher value between (Motor max speed / 8) and (3000 / Motor Pole pair).

Select **Reverse direction** in order to reverse the motor running direction, if required.

2.4.2.2.2 - Motor parameters

Current limit adjustment

The **Maximum current** parameter defines the maximum output current value of the drive. It may vary between 20 % and 100 % of the drive current rating.

The **Rated current** parameter defines the limitation threshold of the drive output RMS current (I_t). It can vary between 20 % and 50 % of the drive current rating.

Current loop adjustment

Enter the value of the total **phase-to-phase inductance** connected to the drive (motor internal winding inductance + external filtering inductance if used).

Select the current loop **Bandwidth**:

-The **High bandwidth** selection will give a high current loop gain values suitable for running high speed multi-pole motors (up to 900 Hz motor current frequency). Furthermore, the speed loop bandwidth can also be set high because the internal current loop delay is minimized. This is the default current loop bandwidth value.

-The **Low bandwidth** selection will introduce a low pass filter in the drive current measurement in order to significantly reduce the audible whistling noise with some motor technologies. In this case, the max. motor current frequency is limited at 400 Hz. The "Low bandwidth" choice for the current loop will also introduce a higher internal delay inside the speed loop. This reduces the speed loop stability margin and consequently the speed loop bandwidth.

The current loop gains are automatically calculated when the **Calculate current loop gains** command is selected.

NOTE

If the drive supply voltage value is changed, the current loop gains are automatically adjusted accordingly, inside the drive. A new calculation is not required.

Configuration of the motor thermal sensor

Selection of the sensor type

The motor can be equipped either with a CTN sensor (ohmic resistance = decreasing temperature function) or with a CTP sensor (ohmic resistance = increasing temperature function).

Check that the selected thermal sensor type actually corresponds to the sensor type mounted on the application motor.

Triggering threshold adjustment

Enter the sensor ohmic value (kOhm) corresponding to the required temperature value for the release of the motor over-temperature protection, according to the manufacturer's specifications.

Warning threshold adjustment

Enter the sensor ohmic value (kOhm) corresponding to a warning temperature value. When the warning temperature is reached, the warning bit in status word is set.

Note

When using a CTN sensor, the warning ohmic value will be higher than or equal to the triggering ohmic value. When using a CTP sensor, the warning ohmic value will be lower than or equal to the triggering ohmic value.

I²t protection adjustment

2 selection modes are available: Fusing or Limiting.

It is advisable to use the Fusing mode during the commissioning phases.

In **Fusing** mode, the drive is disabled when the current limitation threshold is reached.


In **Limiting** mode, the motor current is only limited at the value defined by the **Rated current** parameter when the limitation threshold is reached.

Operation of the Current Limitation in "Fusing" Mode

When the drive output RMS current (I_t) reaches 85 % of the rated current, the I²t warning is displayed. If the RMS current (I²t) has not dropped below 85 % of the rated current within 1 second, the I²t error is released and the drive disabled (otherwise, the I²t warning is removed).

When the drive output RMS current (I^2t) reaches the rated current value, the I^2t limits the drive output current at this value.

Diagram of the drive output current limitation in an extreme case (motor overloaded or shaft locked):



The maximum current duration before release of the warning is depending on the value of the parameters **Rated current** and **Max. current**. This value is calculated as follows:

$$T_{dyn} \text{ (second)} = t_1 - t_0 = 13,3 \times [\text{rated current (A)} / \text{max. current (A)}]^2 \text{ (shaft locked conditions)}$$

$$T_{dyn} \text{ (second)} = t_1 - t_0 = 40 \times [\text{rated current (A)} / \text{max. current (A)}]^2 \text{ (motor running with current frequency value higher than 2 Hz)}$$

The maximum current duration before limitation at the rated current is also depending on the value of the **Rated current** and **Max. current** parameters. This value is calculated as follows:

$$T_{max} \text{ (second)} = t_2 - t_0 = 16 \times [\text{rated current (A)} / \text{max. current (A)}]^2 \text{ (shaft locked conditions)}$$

$$T_{max} \text{ (second)} = t_2 - t_0 = 48 \times [\text{rated current (A)} / \text{max. current (A)}]^2 \text{ (motor running with current frequency value higher than 2 Hz)}$$

NOTE


When the "Max. current / Rated current" ratio is close to 1, the T_{dyn} and T_{max} values given by the formula above are quite below the real values. But this formula remains very precise as long as the "Max. current / Rated current" ratio is higher than 3/2.

Operation of the Current Limitation in "Limiting" Mode

When the drive output RMS current (I^2t) reaches 85 % of the rated current, the I^2t warning is displayed. When the RMS current (I^2t) drops below 85 % of the rated current, the I^2t warning is removed.

When the drive output RMS current (I^2t) reaches the rated current value, the I^2t protection limits the drive output current at this value.

Diagram of the drive output current limitation in an extreme case (motor overloaded or shaft locked):



The maximum current duration before warning ($t_1 - t_0$) and before limitation at the rated current ($t_2 - t_0$) is calculated the same way as in the "Fusing" mode.

Speed limit adjustment

The **Maximum speed** parameter defines the speed limit of the motor. This value is given in the motor catalog according to the rated supply voltage and the rated load conditions. If the drive output voltage is lower than the motor rated voltage value, the **Maximum speed** must be reduced accordingly.

The maximum value for the speed set point in the application must be adjusted in order to get a motor speed value lower than the **Maximum speed** parameter. A margin of 10 % to 20 % is recommended.

Auto-phasing of the motor

The **Auto-phasing** procedure identifies the motor parameters **Pole pairs**, **Phase order** and **Position sensor offset**.

- The **Pole pairs** parameter defines the number of motor pole pairs.
- The **Phase order** parameter defines the sequence of the motor phases.
- The **Position sensor offset** parameter defines the mechanical shift between the motor and the position sensor (resolver or absolute encoder) reference.

Before executing the **Auto-phasing** procedure, proceed as follows:


- Check that the values of the **Maximum current** and **Rated current** parameters are compatible with the motor. Otherwise, modify them according to the motor specifications.
- Select the I²t protection in fusing mode. The **Fusing** mode should be used for the commissioning phases.
- Uncouple the motor from the mechanical load and check that the motor shaft is free and for free rotation (1 revolution) that is not dangerous for the operator.

Remark:

- When the motor is operating in HES only feedback, the motor **Pole pairs** parameter must be entered manually before executing the **Auto-phasing** procedure.
- When the motor is operating in sensorless control, auto-phasing is not supported.

2.4.2.3 - Linear motor configuration

The **Encoder resolution** parameter is calculated as described below:



$$\text{Encoder resolution (inc)} = 4000 \times \frac{\text{Motor pole pitch (mm)}}{\text{Encoder signal pitch (\mu m)}}$$



1 encoder signal pitch = 4 counting increments

The motor **Maximum speed** parameter value in rpm is calculated according to following formula:

$$\text{Maximum speed (rpm)} = 60 \times \frac{1000}{\text{Motor pole pitch (mm)}} \times \text{Maximum motor speed (m/s)}$$

The linear speed value in m/s is calculated according to following formula:

$$\text{Linear speed (m/s)} = \frac{\text{Motor speed (rpm)}}{60} \times \frac{\text{Motor pole pitch (mm)}}{1000}$$

The **User position scaling** is adjusted as described below:

User position scaling = motor displacement for 1 pole pitch = Motor pole pitch (mm)

2.4.3 - Position sensors

The **XtrapulsEasy** drive can operate with different position sensor types: resolver, encoder, or Hall Effect Sensors (HES). The position sensor is connected to the drive “feedback” input.

Different encoder types can be connected to the **XtrapulsEasy** drive encoder input: incremental encoder with TTL (square) signals, or incremental encoder with TTL (square) signals + HES channels. **XtrapulsEasy** drive can also operate with HES signals only.

All internal position setpoints and displays are given by using the “user unit” definition. All internal speed setpoints and displays are given by using the “user unit / second” definition. So, it is necessary to define inside the drive the relationship between sensor data and “user unit” value.

User Position Scaling

Select the position unit according to the application.

Select the display factor according to the desired decimal number in the position set point and display.

Enter the load displacement value (in the previously defined position units) corresponding to one revolution for a rotating motor or one pole pitch for a linear motor. This parameter depends on the mechanical ratio between motor and load.

2.4.4 - Servo loops adjustment

The **XtrapulsEasy** drive speed and position loop gain values can be automatically calculated by using the Auto-tuning procedure. This procedure identifies the motor and mechanical load specifications and calculates the appropriate gain values.

The Auto-tuning procedure can be executed with the drive disabled or enabled (for a vertical load). When the drive is enabled, the Auto-tuning can only be executed if the motor is at standstill.

When using a low resolution position sensor (HES only), or when the motor is operating in sensorless control, the Auto-tuning procedure cannot be performed. In this case, the Servo loop gains calculation procedure must be used.

The Servo loop gains calculation procedure can be executed with the drive disabled or enabled. This procedure calculates the appropriate gain values according to the motor and mechanical load specifications. The mechanical load specifications must be entered by the user. This procedure is useful for application with vertical load. The gains value can be initialized in order to get a stable servo loop before the execution of the Auto-tuning procedure.

Auto-tuning of the drive regulator

Select the **Controller type** according to the application:

- In Velocity mode, only the speed loop gains are calculated.
- In Position mode, all gains of both speed and position regulators are calculated.

Select the **Position loop requirements** if the position mode was selected before:

- The choice **Minimum following error** allows getting an accurate following of the position reference value during the whole motor displacement. In this case, all feedforward gain values are calculated.
- The choice **Minimum position overshoot** allows getting a motor positioning without any overshoot of the target position. In this case, all feedforward gain values are set at 0, and the motor position is lagging with regard to the position reference value during the whole motor displacement.

Select the **Speed measurement** filter time constant according to the motor position sensor resolution and the acceptable noise level in the speed measurement. The higher the time constant value, the lower the speed

measurement noise, but also the lower the speed loop gains because of the increased speed measurement delay.

When **Auto-select** is selected, the most appropriate value is chosen during the Auto-tuning procedure execution.

Select the servo loop **Filter type** according to the application:

- The choice of the **Anti-resonance** filter is necessary in case of loud noise in the motor, due to motor/load coupling elasticity.
- The choice of the **Maximum stiffness** filter allows getting the maximum stiffness on the motor shaft with regard to the torque disturbances. However, this choice is only possible without any resonance due to the motor/load coupling elasticity.

Select the desired closed loop **Bandwidth** (cut-off frequency value of the closed loop frequency response) according to the dynamic performances requirements of the application (Low = 50 Hz, Medium = 75 Hz, High = 100 Hz).

- **High** bandwidth means short response time of the servo loop and high gain values.
- **Low** bandwidth means larger response time of the servo loop and lower gain values.

Before executing the Auto-tuning procedure, check that the motor shaft is free and that its rotation over one revolution is not dangerous for operator and machine. Check also that the brake is released (the Auto-tuning command does not control the brake).

After the Auto-tuning, in case of loud noise in the motor at standstill or when running, check the rigidity of the mechanical transmission between motor and load (backlashes and elasticity in motor and couplings). If required, start a new Auto-tuning procedure by selecting a lower Bandwidth. If the instability remains, start a new Auto-tuning procedure by activating the Anti-resonance filter. If necessary, adjust more accurately the loop response stability by adjusting the Gain scaling factor.

In case of loud noise in the motor, only when running, during the acceleration and deceleration phases, set **Feedforward acceleration gain** value at 0.

In the case of an axis with vertical load, proceed as follows:

- Select the **Limiting** current limitation mode (in order to avoid the drive being disabled in case of an I²t protection release).
- Initialize the speed loop gains corresponding to the unloaded motor (execute therefore the Auto-tuning procedure with the motor uncoupled from its mechanical load).
- Couple the motor to its load. If possible, make a control in speed mode; otherwise, close the position loop with a stable gain.
- Move the axis until a stall position where one motor revolution is not dangerous for operator and machine (far enough from the mechanical stops).
- Then execute the Auto-tuning procedure with the motor at standstill. If the axis is moving, the Auto-tuning procedure has not been accepted by the drive.

Drive regulator gains calculation

Enter first the system parameters:

- Enter the motor **Torque constant** value according to the motor catalogue.
- Enter the motor **Inertia** value according to the motor catalogue.

Remark: When a motor is selected in the GemDriveStudio motor list, these parameter values are automatically initialized.

- Enter the **Load inertia** value reflected to the motor shaft according to the mechanical coupling. If this parameter value cannot be estimated, set its value at 0.

Select the **Controller type** according to the application:

- In Velocity mode, only the speed loop gains are calculated.
- In Position mode, all gains of both speed and position regulators are calculated.

Select the **Position loop requirements** if the position mode was selected before:

- The choice **Minimum following error** allows getting an accurate following of the position reference value during the whole motor displacement. In this case, all feedforward gain values are calculated.
- The choice **Minimum position overshoot** allows getting a motor positioning without any overshoot of the target position. In this case, all feedforward gain values are set at 0, and the motor position is lagging with regard to the position reference value during the whole motor displacement.

Select the **Speed measurement** filter time constant according to the motor position sensor resolution and the acceptable noise level in the speed measurement. The higher the time constant value, the lower the speed measurement noise, but also the lower the speed loop gains because of the increased speed measurement delay.

When **Auto-select** is selected, the most appropriate value is chosen during the procedure execution.

Select the servo loop **Filter type** according to the application:

- The choice of the **Anti-resonance** filter is necessary in case of loud noise in the motor, due to motor/load coupling elasticity.
- The choice of the **Maximum stiffness** filter allows getting the maximum stiffness on the motor shaft with regard to the torque disturbances. However, this choice is only possible without any resonance due to the motor/load coupling elasticity.

Select the desired closed loop **Bandwidth** (cut-off frequency value of the closed loop frequency response) according to the dynamic performances requirements of the application (Low = 50 Hz, Medium = 75 Hz, High = 100 Hz).

- **High** bandwidth means short response time of the servo loop and high gain values.
- **Low** bandwidth means larger response time of the servo loop and lower gain values.

After the Servo loop gains calculation, in case of loud noise in the motor at standstill or when running:

- check that the system parameters values are correct (motor torque constant, motor inertia, load inertia),
- check the rigidity of the mechanical transmission between motor and load (backlashes and elasticity in motor and couplings).

If required, start a new Servo loop gains calculation procedure by selecting a lower Bandwidth. If the instability remains, start a new Servo loop gains calculation procedure by activating the Anti-resonance filter.

In case of loud noise in the motor, only when running, during the acceleration and deceleration phases, set **Feedforward acceleration gain** value at 0.

If the **Load inertia** value is unknown and the parameter has been set at 0 before the Servo loop gains calculation, increase the **Gain scaling factor (KJv)** in order to adjust the servo loop stability.

Remark: When using a low resolution position sensor (HES only), or when the motor is operating in sensorless control, **Medium Bandwidth** and **Anti-resonance** filter are automatically selected during the procedure execution.

Regulator gains

Speed loop gains are the most critical to adjust because they greatly depend on the mechanical load characteristics (inertias, frictions, coupling stiffness, resonances,...).

- **Proportional speed gain (Kpv):** defines the proportional gain of the controller which acts on the speed error. The higher this parameter value, the faster the speed loop response.
- **Integral speed gain (Kiv):** defines the integral gain of the controller which acts on the speed error. The higher this parameter value, the better the axis stiffness.

- **Integrator low frequency limit (Kl_{vf} in Hz)**: defines the low frequency value from where the controller integrator term is saturated. This parameter is used for reducing the motor heating in applications with large dry frictions due to the mechanical load.

- **Damping gain (KC_v)**: defines the proportional gain of the controller which acts only on the speed feedback. This parameter allows reducing the speed loop overshoot in response to a step-like set point change.

- **Derivative speed gain (KD_v)**: defines the derivative gain of the controller which acts on the speed error.

- **Derivator high frequency limit (KD_{vf} in Hz)**: defines the high frequency value from which the controller derivative term is saturated.

- **Gain scaling factor (KJ_v)**: defines a multiplying factor for all speed regulator gains. This parameter scales the speed regulator gains in order to avoid any saturation when high values are required. This parameter also allows adjusting the servo loop stability in case of load inertia changes.

The **Current command filter** is a 3rd order, low-pass type filter, with 3 adjustable cut-off frequencies. Each cut-off frequency value can be freely adjusted according to the application for the filtering of high frequency noise or the filtering of mechanical resonances.

The **Speed measurement filter** is a 1st order, low-pass type filter, with 3 selectable time constant values. The higher the time constant value, the lower the speed measurement noise, but also the lower the speed loop gains because of the increased speed measurement delay. The **Speed measurement filter** time constant is selected according to the motor position sensor resolution and the acceptable noise level in the speed measurement.

Position loop gains mainly influence the servo motor behaviour during the displacements (following error, position overshoot, audible noise, ...).

- **Proportional position gain (KP_p)**: defines the proportional gain of the controller which acts on the position error. The higher this parameter value, the better the axis stiffness and the lower the following error.

- **Position loop Error low pass filter (PosErrLF)**: defines the low pass filter which acts on the position loop error. This filter is useful for application with low resolution position sensor (HES only) in order to reduce the motor position flickering at standstill.

- **Feedforward speed 1 gain (KF_p)**: defines the feedforward speed amplitude corresponding to the speed input command. This term allows reducing the following error during the motor displacement. Its value is set at maximum (65536) after the autotuning procedure, if a following error as small as possible is required.

- **Feedforward speed 2 gain (KB_v)**: defines the feedforward speed amplitude corresponding to the viscous frictions. This term allows reducing the viscous friction effect during the motor displacement. The gain value is equal to the damping gain value + the viscous friction compensation term. After the auto-tuning procedure, the feedforward speed 2 gain is set equal to the damping gain value, if a following error as small as possible is required. The viscous friction compensation term can be calculated by measuring the current/speed ratio at various motor speed values.

- **Feedforward acceleration gain (KA_v)**: defines the feedforward acceleration amplitude corresponding to the acceleration input command. This term allows reducing the following error during the motor acceleration and deceleration phases. Its value is calculated by the amplifier during the auto-tuning procedure if a following error as small as possible is required.

- **Position Deadband window (PosErDbd)**: When the position error is within the deadband window, the position loop is open. This parameter can be used for application with low resolution position sensor (HES only) in order to avoid the motor position flickering at standstill.

When the **Auto-tuning** procedure is executed, the motor + mechanical load specifications are identified and the appropriate gain values are calculated according to the requirements selected by the user (controller type, filter type, bandwidth value, ...). All gain values can then be manually modified by the user, if required.

When the **Gains calculation** procedure is executed, the gain values are calculated according to the requirements (controller type, filter type, bandwidth value, ...) and the motor + mechanical load information specified by the user. All gain values can then be manually modified by the user, if required.

Following error

Speed error threshold defines the speed following error triggering threshold. It is important to correctly adjust this value in order to get a good protection of the drive and the application.

The **Speed error threshold** parameter can be adjusted like follows:

- Get the motor running with the required operation cycles and measure the maximum value of the speed error in the digital oscilloscope (Max. speed error value);
- Then set the **Speed error threshold** parameter = 1.3 to 1.5 x Max. speed error value.


Position error threshold defines the triggering threshold of the position following error. It is important to correctly adjust this value in order to get a good protection of the drive and the application.

The **Position error threshold** parameter can be adjusted like follows:

- Make the motor running with the required operation cycles and measure the maximum value of the following error in the digital oscilloscope (max. following error value);
- Then set the **Position error threshold** parameter = 1.3 to 1.5 x Max. following error value.


The **Position error detection mode** defines the operation mode of the axis following error protection.

- When **Absolute** is selected, the following error protection is operating as described below:



The measured position error value is continuously compared with the **Position error threshold** parameter value. When the measured position error is exceeding the **Position error threshold**, the position following error is released. This configuration is used for applications requiring the smallest possible following error.

- When **Relative to dynamic model** is selected, the following error protection is operating as described below:



The measured position error value is continuously compared with the theoretical position error given by the position loop model. When the difference is exceeding the **Position error threshold**, the position following error is released. In this configuration, when the position servo loop is adjusted to get the motor position continuously lagging the reference position (applications for positioning without overshoot and with a high following error value), any small anomaly in the actuator behaviour can be detected.

2.4.5 - Quick test of the servo drive

The servo loop stability can be tested on-line by moving the motor in speed profile mode or in position profile mode. The regulator gains can be either automatically calculated or manually optimized. For resolver feedback and encoder feedback, the auto-tuning procedure can be used for the automatic gain calculation. For HES feedback only and sensorless control, the servo loop gains calculation procedure can be used for the automatic gain calculation.

Profile Velocity parameters

Enter the **Maximum velocity** parameter value according to the motor **Maximum speed** and the limitation due to the mechanical load in the application. For the first tests, a reduced velocity range is preferred in order to prevent hazardous movements with wide amplitude. This parameter is active in both velocity profile mode and position profile mode.

Enter the **Acceleration** and **Deceleration** parameter values. Small values can be used as a starting point in order to prevent sharp movements on the mechanical load. This parameter is active in both velocity profile mode and position profile mode.

Profile Position parameters

Enter the **Maximum velocity** parameter value according to the motor **Maximum speed** and the limitation due to the mechanical load in the application. For the first tests, a reduced velocity range is preferred in order to prevent hazardous movements with a large amplitude. This parameter is active in both velocity profile mode and position profile mode.

Enter **Acceleration** and **Deceleration** parameter values. Small values can be used as a starting point in order to prevent sharp movements on the mechanical load. This parameter is active in both velocity profile mode and position profile mode.

Enter the **Profile velocity** parameter value according to the desired motor displacement speed. The **Profile velocity** parameter value must be lower than or equal to the **Maximum velocity** parameter value.

Checking the servo loop stability

In velocity mode:

Disable the motor brake, enable the drive, and check the servo loop stability at standstill: in case of loud noise in the motor, check the rigidity of the mechanical transmission between motor and load (backlashes and elasticity in motor and couplings). If required, start a new **Auto-tuning** procedure by selecting a lower **Bandwidth**. If the instability remains, start a new **Auto-tuning** procedure by activating the **Anti-resonance** filter. If necessary, adjust more accurately the servo loop stability by adjusting the **Gain scaling factor**.

Move the axis in both directions (low velocity set point value), and check the servo loop stability in movement: in case of loud noise in the motor during the displacement, the **Speed measurement filter** time constant can be increased. For high frequency noise or mechanical resonances, use the 3rd order low-pass **Current command filter** and adjust the 3 cut-off frequencies with the most appropriate values.

Move the axis in both directions (higher velocity set point value), and check the servo loop time response. In case of undesired overshoot for a step-like velocity set point change, increase the **Damping speed gain** value and reduce the **Proportional speed gain** value accordingly.

NOTE

- When the motor is operating in sensorless control, the stability must be checked at speeds over the **Low speed threshold** value. At low speed and standstill (in the SFC mode), the speed regulator is not operating.
- When the motor is operating with HES only feedback, the drive can be switched in the SFC mode at low speeds and at standstill. So, the speed regulator stability must be checked at speeds over the commutation threshold value

In position mode:

Disable the motor brake, enable the drive, and check the servo loop stability at standstill: in case of loud noise in the motor, check the rigidity of the mechanical transmission between motor and load (backlashes and elasticity in motor and couplings). If required, start a new **Auto-tuning** procedure by selecting a lower **Bandwidth**. If the instability remains, start a new **Auto-tuning** procedure by activating the **Anti-resonance** filter. If necessary, adjust more accurately the servo loop stability by adjusting the **Gain scaling factor**.

Move the axis in both directions with a low **Profile velocity** value, and check the servo loop stability in movement. In case of loud noise in the motor during the displacement, the **Speed measurement filter** time constant can be increased. For high frequency noise or mechanical resonances, use the 3rd order low pass **Current command filter** and adjust the 3 cut-off frequencies with the most appropriate values.

Move the axis in both directions with a higher **Profile velocity** value and check the motor positioning behaviour. In case of loud noise in the motor during the acceleration and deceleration phases, set **Feedforward acceleration gain** value at 0. In case of undesired position overshoot at the end of the deceleration phase, reduce the **Feedforward speed 1** value.

NOTE

- In Profile velocity mode, only the speed regulator gains are active.
- In Profile position mode, all gains of both speed and position regulators are active. However, if the Auto-tuning was executed in Velocity mode, all position loop gains are equal to 0 and the motor cannot move.
- In Interpolated Position Mode, Feedforward Acceleration Gain must be manually cleared after the Auto-tuning procedure.

2.4.6 - Adding the motor into the catalog

The motor can then be referenced in the **Gem Drive Studio** motor catalog by using the **Add new motor** command (see **Gem Drive Studio** quick start manual). The motor and the position sensor parameter values are manually entered and then saved in the **Gem Drive Studio** motor catalog with a new motor reference.

Remark: The sensorless control parameters are automatically calculated according to the entered motor data. They are then saved in the motor catalog regardless of the sensor selection. So, when the motor is selected in the **Gem Drive Studio** motor list, the sensorless control parameters are initialised with these values.

2.4.7 - Logic Inputs

XtrapulsEasy drives offer the use of built-in functions for the drive operation. These functions can be controlled by using "logical signal" or digital input. The default configuration is "logical signal". If required, any digital input can be connected to a given function for the hardware control.

"ENABLE" INPUT

This function allows enabling and disabling the drive when the "Enable control by HARDWARE" is selected.

Note: when a digital input is connected to this function for the hardware control, it is recommended to use a 24Vdc signal on the input to enable the drive by choosing the appropriate value for the polarity parameter.

"INHIBIT" INPUT

The INHIBIT input is internally connected to the IN4 physical input used for drive STO function operation. So, the IN4 physical input must be set to logic 1 (24 V) in order to enable the drive power stage. Activating the INHIBIT input during the operation (logic 0 on physical input IN4) will disable the drive power stage.

"LIMIT SWITCH" INPUT

The "Limit switch" inputs are inputs for a detection sensor that allows stopping the motor with maximum deceleration. The purpose of both limit switches, when they are mounted at the right place on the axis stroke, is to protect the mechanics in case of uncontrolled movements.

The limit switches are only defined according to the motor hardware rotation. They are independent from the "rotation/counting direction" selection.

For checking the wiring of the limit switch inputs:

- move the motor in one direction,
- activate the limit switch placed in the rotation direction (artificially, if necessary),
- then check the motor stopping; if the motor goes on moving, reverse the wiring of the limit switch inputs.

Notes:

- When activating a limit switch input, the motor is stopped with maximum deceleration.
- The limit switch inputs must be setup to be activated if disconnected from the +24 V potential.

"HOME SWITCH" INPUT

In Homing mode, according to the machine structure, it may be necessary to connect a digital sensor to identify the real position of an axis. In this case, a digital I/O has to be connected to this function. Home switch input is also a possible input for the capture function.

"CAPTURE" INPUT

The Capture function allows recording motor position and/or second sensor measurement when an external signal is changing.

"QUICK STOP" INPUT

Activating the QUICK STOP input during the operation makes the axis decelerate. At the end of the deceleration, the motor is either maintained enabled at standstill or disabled according to the parameter setting.

"START PHASING" INPUT

The START PHASING input allows starting the motor phasing procedure at the drive power up when the motor is equipped with an incremental encoder without HES.

"ERROR RESET" INPUT

The ERROR RESET input allows erasing a released drive fault when the cause of the fault release is eliminated.

"SEQ START" INPUT

The SEQ START input allows starting the selected sequence when the drive Sequence mode is selected.

"SEQ STOP" INPUT

The SEQ STOP input allows stopping any sequence execution when the drive Sequence mode is selected.

"SEQ SEL 1" INPUT

The SEQ SEL 1 input is connected to bit 0 of the sequence number selection when the drive Sequence mode is selected.

"SEQ SEL 2" INPUT

The SEQ SEL 2 input is connected to bit 1 of the sequence number selection when the drive Sequence mode is selected.

"SEQ SEL 3" INPUT

The SEQ SEL 3 input is connected to bit 2 of the sequence number selection when the drive Sequence mode is selected.

"SEQ SEL 4" INPUT

The SEQ SEL 4 input is connected to bit 3 of the sequence number selection when the drive Sequence mode is selected.

"SEQ COND 1" INPUT

The SEQ COND 1 input can be used as a start condition or an end condition for a sequence when the drive Sequence mode is selected.

"SEQ COND 2" INPUT

The SEQ COND 2 input can be used as a start condition or an end condition for a sequence when the drive Sequence mode is selected.

"SEQ COND 3" INPUT

The SEQ COND 3 input can be used as a start condition or an end condition for a sequence when the drive Sequence mode is selected.

"SEQ COND 4" INPUT

The SEQ COND 4 input can be used as a start condition or an end condition for a sequence when the drive Sequence mode is selected.

2.4.8 - Logic Outputs

Any drive state signal can be connected to a digital output.

"AOK" OUTPUT

This signal is deactivated when a fault is released inside the drive. Undervoltage fault is not considered for the AOK signal deactivation.

"BRAKE" OUTPUT

This signal is useful for the motor brake control when the drive is enabled or disabled.

"FAULT" OUTPUT

This signal indicates that a fault is released inside the drive.

"WARNING" OUTPUT

This signal indicates that a warning is released inside the drive.

"UNDERVOLTAGE WARNING" OUTPUT

This signal indicates that the DC bus voltage value is dropping below the "Undervoltage Warning Threshold" parameter value.

"VOLTAGE ENABLED" OUTPUT

This signal indicates that the drive is powered (Undervolt. is over).

"PHASING NOT OK" OUTPUT

This signal indicates that the motor is not ready to be enabled because a phasing or auto-phasing procedure is required.

"DRIVE ON" OUTPUT

This signal indicates that the motor is enabled and under servo control.

"IN POS" OUTPUT

This signal indicates that the motor has reached the target position when the drive Profile position or Sequence mode is selected.

"SEQ", "POS", "SPEED", "OUT1", "OUT2", "OUT3", "OUT4" OUTPUTS

These signals concern the sequence execution when the drive Sequence mode is selected.

2.4.9 - Braking Resistor

The **XtrapulsEasy** drive has no internal braking resistor with power dissipation capability. If braking energy dissipation is required, an external braking resistor must be connected on the X4 connector.

The parameter **Braking resistor duty cycle limit** allows limiting the external braking resistor average power in order to protect it against overheating and failure. Its maximum value is 70 per thousand: this means a maximum braking transistor conduction of 70 ms over a period of 1 second.

The **Duty cycle limit** parameter value is calculated according to the external braking resistor specifications as described below:

Duty cycle limit = Braking resistor rated power (W) x Braking resistor ohmic value (Ohms) / Braking on threshold (V) / Braking on threshold (V)

2.5 - DRIVE PARAMETER SAVING

When all adjustments and settings have been tested, they can be stored in the non-volatile drive memory by selecting the command **Drive parameter file > Store parameters to flash memory**. In this case, all drive standard parameters are saved in the drive file DRIVEPAR.TXT.

The drive file DRIVEPAR.TXT can then be transferred to the project directory in the PC by selecting the command **Drive parameter file > Backup parameters to PC file**.

The command **Drive parameter file > Restore parameters** allows transferring a file DRIVEPAR.TXT saved in the PC directory to the drive.

A user parameter list can also be edited and saved in the file USER_PAR.TXT by using the command **User parameter file > Edit Parameters**. The USER_PAR.TXT file can then be transferred to the drive by selecting the command **User parameter file > Restore parameters**. A drive file USER_PAR.TXT can be transferred from the drive to the PC directory by selecting the command **User parameter file > Backup parameters to PC file**. The user parameter file USER_PAR.TXT can be used for saving drive parameters that are not saved in the file DRIVEPAR.TXT (standard drive parameter list).

Note: The commands **Tools > Drive file backup** and **Tools > Drive file restoring** concern all project drive files: DRIVEPAR.TXT, USER_PAR.TXT, SEQUENCE.TXT, and so on.

2.6 - OSCILLOSCOPE

The oscilloscope can be launched in the **Gem Drive Studio** software or in stand-alone mode.

This oscilloscope allows displaying any drive signal by using the Index / Sub-index identification.

Four different channels are available to display signals. Multi-axis channel operation can be selected.

See **Gem Drive Studio Quick Start** manual for more details.

2.7 - DIALOG TERMINAL

The dialog terminal can be launched in the **Gem Drive Studio** software or in stand-alone mode.

This terminal allows:

- Reading a parameter value on a selected axis (continuous value monitoring can also be performed).
- Writing a parameter value on a selected axis.

It is possible to read and/or write parameters on 4 different axes at the same time.

See **GemDriveStudio Quick Start** manual for more details.

Chapter 3 - Reference

REFERENCE

CiA DS-201..207	CAN Application Layer for Industrial Applications Version 1.1
CiA DS-301	Application Layer and Communication Profile Version 4.01
CiA DSP-402	Device Profile: Drive and Motion Control Version 1.1

DEFINITIONS & CONVENTIONS

CAN	Controller Area Network
CiA	CAN in Automation e.V. CAN-Bus international manufacturer and user organisation.
CAL	CAN Application Layer. The Application layer for CAN as specified by CiA.
COB	Communication Object is a CAN message. Data must be sent through a CAN network inside a COB.
COB-ID	COB-Identifier. Each CAN message has a single identifier. There are 2032 different identifiers in a CAN network.
NMT	Network Management. One of the services of the application layer. It performs initialisation, configuration and error handling in a CAN network.
PDO	Process Data Object. A CANopen message used to exchange process data.
SDO	Service Data Object. A CANopen message for parameterization.
pp	Profile Position Mode.
pv	Profile Velocity Mode.
hm	Homing Mode.
ip	Interpolated Position Mode.
tq	Profile Torque Mode.
pc	Position Control Function.
Xtrapuls	Generic name of the Infranor servo drive family with resolver and encoder feedback input.
Numerical value	Hexa is preceded by 0x, decimal otherwise
Dynamic Variable	Element of an object indicated by index and sub-index which can be mapped in a PDO. An element of an object is addressed by its index and its sub-index.

Dataflow An element of an object is qualified as dataflow (signal) if it is a variable (i.e. mappable). These variables can be of 8 bit, 16 bit or 32 bit. Depending on the using context, a dataflow must be of 16 bit or 32 bit or any size.

The dataflow can be issued from:

- An external source:
Examples : Encoder position 0x3129-0
 Analog Input 0x31F1-1 (16 bit)
 Analog Input 0x31F1-2 (32 bit)
- The CAN bus:
Example: Interpolated data 0x30C1-0 (32 bit)
- An internal signal:
Examples: Position demand value 0x6062-0 (32-bit)

3.1 - CANOPEN COMMUNICATION

3.1.1 - Communication objects

3.1.1.1 - Can Telegram

CAN TELEGRAM

SOM	COB-ID	RTR	CTRL	Data segment	CRC	ACK	EOM
-----	--------	-----	------	--------------	-----	-----	-----

SOM Start Of Message
 COB-ID COB-Identifier of 11 bits
 RTR Remote Transmission Request
 CTRL Control field
 Data up to 8 bytes
 CRC Cyclic Redundancy Check
 ACK Acknowledge
 EOM End Of Message

3.1.1.2 - Default COB-ID

The COB-ID is of 11 bits. Node-ID (bits 0 - 6) is the drive address from 1 to 127.

10	9	8	7	6	5	4	3	2	1	0
Function Code				NODE-ID						

Default COB-ID:

Broadcast objects of the pre-defined connection set:

Object	Function Code	Resulting COB-ID	Communication Parameter at Index
NMT	0000	0	-
SYNC	0001	128 (80h)	1005h, 1006h, 1007h

Peer-to-peer objects of the pre-defined connection set:


Object	Function Code	Resulting COB-ID	Communication Parameter at Index
EMERGENCY	0001	129 (81h) - 255 (FFh)	1014h
PDO1 (TX)	0011	385 (181h) - 511 (1FFh)	1800h
PDO1 (RX)	0100	513 (201h) - 639 (27Fh)	1400h
PDO2 (TX)	0101	641 (281h) - 767 (2FFh)	1801h
PDO2 (RX)	0110	769 (301h) - 895 (37Fh)	1401h
PDO3 (TX)	0111	897 (381h) - 1023 (3FFh)	1802h
PDO3 (RX)	1000	1025 (401h) - 1151 (47Fh)	1402h
PDO4 (TX)	1001	1153 (481h) - 1279 (4FFh)	1803h

PDO4 (RX)	1010	1281 (501h) - 1407 (57Fh)	1403h
SDO (TX)	1011	1409 (581h) - 1535 (5FFh)	1200h
SDO (RX)	1100	1537 (601h) - 1663 (67Fh)	1200h

TX = Transmit from drive to master
 RX = Receive by drive from master

3.1.1.3 - Network Management Objects

NMT Protocols




NMT Protocol	Command Specifier CS	Remarks
Start Remote Node	1	Change to NMT Operational state
Stop Remote Node	2	Change to NMT Stop state
Enter Pre-Operational	128	
Reset Node	129	
Reset Communication	130	

Node-ID: The Node-ID indicates the address of the drive. If Node_ID = 0, the protocol addresses all NMT slaves.

3.1.1.4 - Synchronisation Object

The SYNC object is a broadcast message sent by the master. This message provides a network clock. The period is specified by the communication cycle period (object 0x1006). The Xtrapuls servo-drives use this SYNC message to synchronize their local clock.

At least 180 ms are necessary for the servo-drive to start the synchronisation.



COB-ID Sync Message

Index	0x1005
Name	COB-ID Sync Message
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0x00000080

This object defines the COB-ID of the synchronisation object (SYNC).

29-bit ID is not supported.

Bit number	Value	Meaning
31 (MSB)		
30	0	Device does not generate SYNC message
	1	Device generates SYNC message
29	0	11-bit ID (CAN 2.0 A)
28-11	0	
10-0 (LSB)	x	bits 10-0 of SYNC COB-ID

Communication Cycle Period

Index	0x1006
Name	Communication Cycle Period
Object Code	VAR
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	µs
Value Range	0..150000 (only the values multiples of 500 are supported)
Default Value	10000

This object defines the communication cycle. This period is also used for the synchronisation in interpolated position mode. When the value of this object is reset at 0, the synchronisation is no more operative.

Sync Control

A PLL allows the internal cycle to be synchronized on SYNC message.

This object allows adjusting the PLL parameters.

Index	0x2006
Name	Sync control
Object Code	ARRAY
Number of Elements	4

Value Description

Sub Index	1
Description	Sync Phase defines the phase shift between local clock and SYNC
Data Type	Integer16
Object Class	all
Access	rw
PDO Mapping	No
Unit	µs
Default value	0

Sub Index	2
Description	Adjustment threshold. defines the limit to be applied to the adjustment.
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	µs
Default value	20

Sub Index	3
Description	Adjustment value
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	µs
Default value	2

Sub Index	4
Description	Sync Error Limit defines the limit at which the Sync error is triggered: $ \text{SyncPeriod} - [0x1006-0] < \text{SyncErrorLimit}$
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	µs
Default value	500

Sub Index	5
Description	Sync Filter applies a filter on Sync period measurement
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Value	0 disabled 1..4
Default value	0

3.1.1.5 - Process Data Objects (PDO)

PDOs are unconfirmed messages used for real-time data exchange.
PDOs sent by the master are RPDOs and PDOs sent by the drive are TPDOs.

Data in each PDO are defined by a list of objects (PDO mapping).

There are 4 PDOs: TPDO1, RPDO1, TPDO2, RPDO2, TPDO3, RPDO3, TPDO4 and RPDO4.

Each PDO is defined by:

PDO communication parameters with:
object 0x1400, 0x1401, 0x1402, 0x1403 for RPDOs
object 0x1800, 0x1801, 0x1802, 0x1803 for TPDOs

PDO mapping with:
object 0x1600, 0x1601, 0x1602, 0x1603 for RPDOs
object 0x1A00, 0x1A01, 0x1A02, 0x1A03 for TPDOs

Communication parameters

The communication parameters are:

- PDO COB-ID,
- Transmission type

The distribution of COB-ID is defined by default.

The modification of COB-ID of PDO can be made in *NMT Pre-Operational State*; the new COB-ID will take effect when the NMT state machine switches to *Operation State*.

The modification must not be taken in *NMT Operational State*, otherwise a *Reset_Communication* will be necessary before the new COB-ID takes effect.

Transmission type supported by the Xtrapuls servo drive:

Transmission type	PDO transmission				
	cyclic	acyclic	synchronous	asynchronous	RTR only
1	TPDO1 TPDO2 TPDO3 TPDO4		TPDO1 TPDO2 TPDO3 TPDO4		
2-240					
253					TPDO1 TPDO2 TPDO3 TPDO4
254					
255				TPDO1 TPDO2 TPDO3 TPDO4	

- Transmission types 1 - 240 are synchronous transmissions with regard to the SYNC messages. A value between 1 and 240 means that the PDO is synchronously and cyclically transferred. The transmission type indicates the numbers of SYNC which are necessary to trigger PDO transmissions.
- Transmission type 253 means that the PDO is only transmitted on remote transmission request.
- Transmission type 255 is event trigger: The PDO will be transmitted when the first object (must be 16-bit) mapped in PDO has changed.

PDO transmission modes:

- *Synchronous*: the message is transmitted in synchronisation with the SYNC message. A synchronous message must be transmitted within a pre-defined time-window immediately after the SYNC message.
- *Asynchronous*: the message is sent independently of the SYNC message.

Triggering modes:

- *Event_Driven*:

Message transmission by reception of SYNC.

Message transmission by specific event.

- *Remotely requested*: the transmission of an asynchronous PDO is initiated at reception of a remote request by any other device.

Example of multiplexed data:

	MSB			LSB
TPDO Cob-ID 0x501	<i>Data_Ax4</i> (16bit)	<i>Data_Ax3</i> (16bit)	<i>Data_Ax2</i> (16bit)	<i>Data_Ax1</i> (16bit)

This PDO is transmitted with COB-ID 0x501 and contains 16bits x 4 of data

Object	Value
RPDO1 COB-ID (object 1400-1)	0x501
Number of mapped objects (object 1600-0)	0x1
1 st Mapped Object (object 1600-1)	0x60C10110

In drive 1, "*Data_Ax1*" will be written in object 60C1-1

Object	Value
RPDO1 COB-ID (object 1400-1)	0x501
Number of mapped objects (object 1600-0)	0x2
1 st Mapped Object (object 1600-1)	0x00060010 (dummy)
2 nd Mapped Object (object 1600-2)	0x60C10110

In drive 2, "*Data_Ax2*" will be written in object 60C1-1

Object	Value
RPDO1 COB-ID (object 1400-1)	0x501
Number of mapped objects (object 1600-0)	0x3
1 st Mapped Object (object 1600-1)	0x00060010 (dummy)
2 nd Mapped Object (object 1600-2)	0x00060010 (dummy)
3 rd Mapped Object (object 1600-3)	0x60C10110

In drive 3, "*Data_Ax3*" will be written in object 60C1-1

Object	Value
RPDO1 COB-ID (object 1400-1)	0x501
Number of mapped objects (object 1600-0)	0x4
1 st Mapped Object (object 1600-1)	0x00060010 (dummy)
2 nd Mapped Object (object 1600-2)	0x00060010 (dummy)
3 rd Mapped Object (object 1600-2)	0x60FF0010
4 th Mapped Object (object 1600-4)	0x60C10110

In drive 4, "*Data_Ax4*" will be written in object 60C1-1 and "*Data_Ax3*" in object 60FF-0

Receive PDO Communication Parameter

Object 0x1400: 1st Receive PDO Communication Parameter

Index	0x1400
Name	1st Receive PDO Communication Parameter (RPDO1)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x200 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	255

Object 0x1401: 2nd Receive PDO Communication Parameter

Index	0x1401
Name	2nd Receive PDO Communication Parameter (RPDO2)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x300 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	255

Object 0x1402: 3rd Receive PDO Communication Parameter

Index	0x1402
Name	3rd Receive PDO Communication Parameter (RPDO3)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x400 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Object 0x1403: 4th Receive PDO Communication Parameter

Index	0x1403
Name	4th Receive PDO Communication Parameter (RPDO4)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x500 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	0

Receive PDO Mapping**Object 0x1600: 1st Receive PDO Mapping**

Index	0x1600
Name	1st Receive PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x60400010 (control word)

Object 0x1601: 2nd Receive PDO Mapping

Index	0x1601
Name	2nd Receive PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x60FF0020 (target velocity)

Object 0x1602: 3rd Receive PDO Mapping

Index	0x1602
Name	3rd Receive PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x60C10120 (Interpolated data record)

Object 0x1603: 4th Receive PDO Mapping

Index	0x1603
Name	4th Receive PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	0

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0

Transmit PDO Parameter**Object 0x1800: 1st Transmit PDO Parameter**

Index	0x1800
Name	1st Transmit PDO Communication Parameter (TPDO1)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x180 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	253

Object 0x1801: 2nd Transmit PDO Parameter

Index	0x1801
Name	2nd Transmit PDO Communication Parameter (TPDO2)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x280 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	253

Object 0x1802: 3rd Transmit PDO Parameter

Index	0x1802
Name	3rd Transmit PDO Communication Parameter (TPDO3)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x380 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Object 0x1803: 4th Transmit PDO Parameter

Index	0x1803
Name	4th Transmit PDO Communication Parameter (TPDO4)
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	COB-ID
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x480 + Node-ID

Sub Index	2
Description	Transmission Type
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	0

Transmit PDO Mapping

Object 0x1A00: 1st Transmit PDO Mapping

Index	0x1A00
Name	1st Transmit PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x60410010 (status word)

Object 0x1A01: 2nd Transmit PDO Mapping

Index	0x1A01
Name	2nd Transmit PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x606C0020 (velocity value)

Object 0x1A02: 3rd Transmit PDO Mapping

Index	0x1A02
Name	3rd Transmit PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	1

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x60640020 (Actual position value)

Object 0x1A03: 4th Transmit PDO Mapping

Index	0x1A03
Name	4th Transmit PDO Mapping
Object Code	RECORD
Number of Elements	0..4

Value Description

Sub Index	0
Description	number of mapped objects
Data Type	Unsigned8
Access	rw
PDO Mapping	No
Default Value	0

Sub Index	1
Description	1st mapped object
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0


3.1.1.6 - Service Data Objects (SDO)

The SDO is a communication channel with 2 basic characteristics:

- Client/Server relationship,
- Object Dictionary.

Client/Server:

This is a relationship between a single client and a single server (Servo Drive). A client issues a request (upload/download) thus triggering the server to perform a certain task. After finishing the task, the server answers the request.




Object Dictionary:

All objects (variables, constants, records...) of the server are defined as a list of objects where each element is appointed by an index and a sub-index. This object list is called object dictionary. This object dictionary allows the client accessing all objects of the server. The Servo Drive object dictionary consists of 2 parts: the communication profile (DS-301) for the objects related to the CAN communication and the device profile (DSP-402) for objects related to the drive functionality.

For more information about the SDO protocol, please report to the CiA DS-301 version 4.01 specification.

SDO Communication between drives



The **Xtrapuls** drive supports Node ID setting by GemDriveStudio software: menu “Tools”, sub menu “Node ID setting”. Node ID value must be unique for each drive connected on the fieldbus. Node ID range is from 1 to 63.

SDO message for node ID from 64 to 127 are used for communication between drives. The **Xtrapuls** drive re-directs the SDO message from RS-232 to CANbus via the PC.

Example: 3 drives with Node ID 1, 2 and 3.

direct SDO messages: cobID = 0x601/0x581, 0x602/0x582 and 0x603/0x583

re-direct SDO messages: cobID = 0x641/0x5C1, 0x642/0x5C2 and 0x643/0x5C3

This allows the PC communicating with any drive only via one RS-232 connection (example of the red line in the diagram above).

With an **Xtrapuls** drive with node ID = n, there must not be another device in the CANopen network with node ID = n+64, to avoid conflict with the re-direction SDO message of the **Xtrapuls** drive.

3.1.1.7 - Emergency Objects

Byte	0	1	2	3	4	5	6	7
Content	Emergency Error Code		Error register (object 1001h)	Manufacturer Specific Error Field				
				Error Code				

See object 0x3022 for the Error Code.

EMCY message behaviour

Index	0x205F
Name	EMCY message Behaviour
Object Code	VAR
Data Type	Unsigned16
Object Class	All
Access	rw
PDO Mapping	No
Default Value	1

This object defines the behaviour of the EMCY message.

Value	Description
0	EMCY message will not be sent
1	EMCY message will be sent when an error occurs
2	EMCY message will be sent when an error occurs or an error reset (error code = 0) The last case is not applicable for EtherCAT® (EMCY with error code = 0).

3.1.1.8 - Node Guarding

Network error behaviour

Index	0x205E
Name	Network Error Behaviour
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0


This object defines the drive behaviour when a Node guarding error occurs.

Value	Description
0	No Operation
1	Drive Error
2	Goes into Bus Stop state

3.1.2 - Network Initialisation

3.1.2.1 - NMT State Machine

The NMT state machine defines the communication status.



(1)	At Power on, the initialisation state is automatically entered
(2)	Once the Initialisation over, Pre-Operational is automatically entered
(3), (6)	Start_Remote_Node indication
(4), (7)	Enter_Pre-Operational_State indication
(5), (8)	Stop_Remote_Node indication
(9), (10), (11)	Reset_Node indication
(12), (13), (14)	Reset_Communication indication

Minimum Boot-Up consists of one CAN telegram: a broadcast Start_Remote_Note message.

NMT reset

NMT_Reset_Comm:

The NMT_Reset_Comm restores communication parameters (default CobIDs, PDO mapping...) to the power-on values.

The NMT_Reset_Node:

Depending on object 0x205D, the NMT_Reset_Node can re-load the drive parameters file. An NMT_Reset_Comm is then executed.

NMT reset configuration

Index	0x205D
Name	NMT Reset configuration
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This object defines the reset behaviour of the drive.

Bit Number	Description
0..3	Value : 0 Communication Reset only 1 Communication Reset and re-load drive parameters file This operation can take some more time (several seconds) 2 Warm Reset This operation can take some more time (several seconds)
4	When loading the drive parameters (0x1011,1), the SDO response is sent 0 immediately 1 at the end of the operation
5	When saving the drive parameters (0x1010,1), the SDO response is sent 0 immediately 1 at the end of the operation

NMT Message: Start / Pre-Op Remote Nodes

Index	0x2000
Name	Start/Pre-Op Remote Nodes
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0


When writing to this object, an NMT message will be sent on the CAN bus. Depending on the written value, it allows starting or Pre-Op all nodes.

Value	Function
0	Enter Pre-Op Remote Nodes
n	Send a Start Nodes after n ms. Enter Operational mode

3.1.2.2 - Bootup Protocol

This protocol is used to signal that a NMT slave has entered the node state PRE-OPERATIONAL after the state INITIALISING. The protocol uses the same identifier as the error control protocols.

Bootup Event



One data byte is transmitted with value 0.


CANopen Bootup configuration

Index	0x2010
Name	CANopen Bootup configuration
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This object defines the bootup behaviour of the drive.

Value	Description
0	No Bootup message
1	Bootup message is sent when the drive goes into Pre-Op state

3.1.2.3 - Initialisation procedure




3.2 - DEVICE PROFILE

3.2.1 - Device Control

3.2.1.1 - Drive State Machine

The state machine describes the status and the control sequence of the drive.



Drive State

The following states of the device are possible:

- **NOT READY TO SWITCH ON**

*Low level power has been applied to the drive.
The drive is being initialized or is running self test.
A brake, if present, has to be applied in this state.
The drive function is disabled.*

- **SWITCH ON DISABLED**

*Drive initialization is complete.
The drive parameters have been set up.
Drive parameters may be changed.
High voltage may not be applied to the drive, (e.g. for safety reasons).
The drive function is disabled.*

- **READY TO SWITCH ON**
*High voltage may be applied to the drive.
 The drive parameters may be changed.
 The drive function is disabled.*
- **SWITCHED ON**
*High voltage has been applied to the drive.
 The power amplifier is ready.
 The drive parameters may be changed.
 The drive function is disabled.*
- **OPERATION ENABLE**
*No faults have been detected.
 The drive function is enabled and power is applied to the motor.
 The drive parameters may be changed.
 (This corresponds to normal operation of the drive.)*
- **QUICK STOP ACTIVE**
*The drive parameters may be changed.
 The quick stop function is being executed.
 The drive function is enabled and power is applied to the motor.*
- **FAULT REACTION ACTIVE**
*The drive parameters may be changed.
 A fault has occurred in the drive.
 The quick stop function is being executed.
 The drive function is enabled and power is applied to the motor.*
- **FAULT**
*The drive parameters may be changed.
 A fault has occurred in the drive.
 High voltage switch-on/-off depends on the application.
 The drive function is disabled.*

State Transitions

State transitions are caused by internal events in the drive or by commands from the host via the *control word*.

- **State Transition 0: START -> NOT READY TO SWITCH ON**
*Event: Reset.
 Action: The drive self-tests and/or self-initializes.*
- **State Transition 1: NOT READY TO SWITCH ON -> SWITCH ON DISABLED**
*Event: The drive has self-tested and/or initialized successfully.
 Action: Activate communication.*
- **State Transition 2: SWITCH ON DISABLED -> READY TO SWITCH ON**
*Event: 'Shutdown' command received from host.
 Action: None*
- **State Transition 3: READY TO SWITCH ON -> SWITCHED ON**
*Event: 'Switch On' command received from host.
 Action: The power section is switched on if not already on.*
- **State Transition 4: SWITCHED ON -> OPERATION ENABLE**
*Event: 'Enable Operation' command received from host.
 Action: The drive function is enabled.*
- **State Transition 5: OPERATION ENABLE -> SWITCHED ON**
*Event: 'Disable Operation' command received from host.
 Action: The drive operation will be disabled.*
- **State Transition 6: SWITCHED ON -> READY TO SWITCH ON**
*Event: 'Shutdown' command received from host.
 Action: The power section is switched off.*

- State Transition 7: READY TO SWITCH ON -> SWITCH ON DISABLED
Event: 'Quick Stop' and 'Disable Voltage' command received from host.
Action: None

- State Transition 8: OPERATION ENABLE -> READY TO SWITCH ON
Event: 'Shutdown' command received from host.
Action: The power section is switched off immediately, and the motor is free to rotate if unbraked.

- State Transition 9: OPERATION ENABLE -> SWITCH ON DISABLED
Event: 'Disable Voltage' command received from host.
Action: The power section is switched off immediately, and the motor is free to rotate if unbraked.

- State Transition 10: SWITCHED ON -> SWITCH ON DISABLED
Event: 'Disable Voltage' or 'Quick Stop' command received from host.
Action: The power section is switched off immediately, and the motor is free to rotate if unbraked.

- State Transition 11: OPERATION ENABLE -> QUICK STOP ACTIVE
Event: 'Quick Stop' command received from host.
Action: The quick stop function is executed.

- State Transition 12: QUICK STOP ACTIVE -> SWITCH ON DISABLED
Event: 'Quick Stop' is completed or 'Disable Voltage' command received from host.
This transition is possible, if the Quick-Stop-Option-Code is different from 5 (stay in the state 'Quick Stop Active').
Action: The power section is switched off.

- State Transition 13: All states -> FAULT REACTION ACTIVE
A fault has occurred in the drive.
Action: Execute appropriate fault reaction.

- State Transition 14: FAULT REACTION ACTIVE -> FAULT
Event: The fault reaction is completed.
Action: The drive function is disabled. The power section may be switched off.

- State Transition 15: FAULT -> SWITCH ON DISABLED
Event: 'Fault Reset' command received from host.
Action: A reset of the fault condition is carried out if no fault currently exists in the drive.
After leaving the state Fault the Bit 'Fault Reset' of the control word has to be cleared by the host.

- State Transition 16: QUICK STOP ACTIVE -> OPERATION ENABLE
Event: 'Enable Operation' command received from host. This transition is possible if the Quick-Stop-Option-Code is 5, 6, 7 or 8.
Action: The drive function is enabled.

Objects definition

Index	Object	Name	Type	Attr.
0x6040	VAR	Control Word	Unsigned16	rw
0x6041	VAR	Status Word	Unsigned16	ro

Control Word

Index	0x6040
Name	Control Word
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	Possible
Default Value	0000

Bit Number	Function
0	Switch On
1	Disable Voltage
2	Quick Stop
3	Enable Operation
4	Operation Mode Specific
5	Operation Mode Specific
6	Operation Mode Specific
7	Reset Fault (rising edge)
8	Halt (mode PV, PT, AS, AT)

Device control commands are triggered by the following bit patterns in the control word:

Command / Bit of the control_word	bit 7 Fault Reset	bit 3 Enable Operation	bit 2 Quick Stop	bit 1 Disable Voltage	bit 0 Switch On	Transition
Shutdown	X	X	1	1	0	2, 6, 8
Switch On	X	X	1	1	1	3
Disable Voltage	X	X	X	0	X	7, 9, 10, 12
Quick Stop	X	X	0	1	X	7, 10, 11
Disable Operation	X	0	1	1	1	5
Enable Operation	X	1	1	1	1	4, 16
Fault Reset	↑	X	X	X	X	15

Bit 4, 5, 6 are operation mode specific:

Mode	Bit 4	Bit 5	Bit 6
Profile Position Mode	new set point	change_set_immediately	0: absolute 1: relative
Homing Mode	Homing Operation Start	reserved	reserved
Interpolated Position Mode	enable ip_mode	reserved	reserved
Profile Velocity Mode	reserved	reserved	reserved

Correct sequence to enable the drive:

Seq	Control Word (0x6040)	Corresponding Status Word (0x6041)	Remarks
1	0x0000	0x0240	state "Switch On Disabled" drive is disabled
2	0x0006	0x0221	state "Ready To Switch On" drive is disabled
3	0x0007	0x0223	state "Switch On" drive is enabled
4	0x000F	0x0227	state "Operation Enable" drive is enabled

Notes:

- Some independent status bits may be set and are not represented in the table above. The mask for testing the status word is 0x026F.
- Seq 1 (control word = 0x0000) and seq 3 (control word = 0x0007) may be omitted.

- In some operation modes (interpolated position mode, servo mode...), bit 4 of the control word must also be set after seq 4 to be fully operational. When switching between the modes, it is necessary to reset bit 4 of control word before changing the mode and then set it afterwards.

Status Word

Index	0x6041
Name	Status Word
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	ro
PDO Mapping	Possible
Default Value	-

The status word indicates the current status of the drive. It is possible to define the TPDO to be transmitted at every change of the status word (Device Event transmission type).

Bit Number	Function
0	Ready to Switch On
1	Switch On
2	Operation Enabled
3	Fault
4	Voltage Enabled
5	Quick Stop
6	Switch On Disabled
7	Warning
8	
9	Remote
10	Target Reached
11	
12	Operation Mode Specific
13	Operation Mode Specific
14	
15	Manufacturer Specific: Drive Busy

Device Status Bit Meaning:

State	Bit 6 Switch On Disable	Bit 5 Quick Stop	Bit 3 Fault	Bit 2 Operation Enable	Bit 1 Switched On	Bit 0 Ready to Switch On
Not Ready to Switch On	0	X	0	0	0	0
Switch On Disabled	1	X	0	0	0	0
Ready to Switch On	0	1	0	0	0	1
Switched On	0	1	0	0	1	1
Operation Enable	0	1	0	1	1	1
Fault	0	X	1	0	0	0
Fault Reaction Active	0	X	1	1	1	1
Quick Stop Active	0	0	0	1	1	1

Bits 12, 13 are operation mode specific:

Mode	Bit 12	Bit 13
Profile Position Mode	setpoint acknowledge	Following Error
Homing Mode	Homing attained	Homing error
Interpolated Position Mode	Ip-Mode active	reserved
Profile Velocity Mode	Speed = 0	reserved

Device Control

Index	0x3440
Name	Device Control
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	Possible
Default Value	0000

The device control allows activating drive specific functions.

Bit Number	Function
0	AOK output chaining: This bit activation allows deactivating the drive AOK output regardless from the drive fault status. This bit can be connected to a drive Inx input for the AOK signal chaining when many XtrapulsEasy drives are supplied by the same power relay. In this case, the Inx input polarity must be reversed.
1	Soft-Start activation: This bit activation enables manually the soft start system at the drive power supply switch-on. It is used when the power supply switch-off duration is shorter than the DC bus voltage decreasing time below the "Undervoltage threshold" value. In this case, the manual soft start activation allows limiting the drive inrush current that can damage the mains circuit breaker (external to the drive). When the DC bus voltage decreases below the "Undervoltage threshold" value, the soft start system is automatically activated. So, the manual activation is not required.
Others	Reserved

Device Status

Index	0x3441
Name	Device Status
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	ro
PDO Mapping	Possible
Default Value	-

The device status indicates the current status of drive specific functions.

Bit Number	Function
0	AOK state
1	Soft-Start activated (see 0x3440,0)
2..5	Reserved
6	Reserved
7	Reserved
8	Reserved
9..15	Reserved

3.2.1.2 - Error & Warning

3.2.1.2.1 - Error

Error:

Errors are displayed in object 0x3022,1 (32-bit) and 0x3022,2 (32-bit), each bit in this object corresponds to one error.

Error bit in status (bit 3) is set as well.

An emergency message is sent with the last error code (error code is error bit number+1).

The same bit in objects 0x3025,1 and 0x3025,2 allows the inhibition of the corresponding error in 0x3022,1 and 0x3022,2.

The same bit in objects 0x3025,3 and 0x3025,4 allows triggering a stop 2 when the corresponding error in 0x3022,1 and 0x3022,2 occurs.

The same bit in objects 0x3025,5 and 0x3025,6 allows triggering a stop 3 when the corresponding error in 0x3022,1 and 0x3022,2 occurs.

An error can be cleared by "Reset Fault" bit in control word (0x6040).

Error control:

Object 0x3025 allows:

- the inhibition of some errors
- or triggering a stop 2 or stop 3 when the corresponding error occurs
- or selecting the errors not considered for the AOK signal deactivation.

Index	Object	Name	Type	Attr.
0x3022	ARRAY	Error		ro
0x3025	ARRAY	Error Control		rw

Index	0x3022
Name	Error word
Object Code	ARRAY
Number of Elements	3

Value Description

This object contains two 32-bit words in which one bit is assigned to a different error.

The Error code is the value which will be sent as an emergency message (EMCY).

Sub Index	1
Description	Error monitoring
Data Type	Unsigned32
Object Class	all
Access	ro
PDO Mapping	No
Value	See below
Default value	No

Bit	Value	Error Code	Protection	Troubleshooting
0	0x00000001	1	Hardware System 2 Error	<ul style="list-style-type: none"> - Check that the DNC/PLC-amplifier-motor ground connections and shield answer the Installation manual requirements. - Check the application EMC disturbances level.
1	0x00000002	2	24 Volt Error	<ul style="list-style-type: none"> - Check that the logic supply voltage value is within the specified range. - Check the logic supply voltage waveform (ripple value, overvoltage spikes, undervoltage spikes, ...)
2	0x00000004	3	Undervolt (temporized)	<ul style="list-style-type: none"> - Check that the power supply is actually on.
3	0x00000008	4	Braking system error	<ul style="list-style-type: none"> - Check the presence of either the internal resistor jumper (XtrapulsPac) or the external resistor (XtrapulsPac and XtrapulsGem) - Check that the external resistor is not broken (open circuit) <p>If the error cannot be reset, the braking system is out of order (transistor in short-circuit)</p>
4	0x00000010	5	Safety channel 2 Error	<ul style="list-style-type: none"> - Check the correct STO2 input state with regard to the STO1 input state <p>If the STO fault is released, the drive must be turned off in order to cancel the fault.</p>
5	0x00000020	6	Overvoltage	<p>If the failure occurs when starting the amplifier:</p> <ul style="list-style-type: none"> - Check the AC supply voltage value. <p>If the failure occurs during the operation:</p> <ul style="list-style-type: none"> - Check the DC bus voltage during the deceleration phases. - Check the sizing of the braking resistor with regard to the motor deceleration phases.
6	0x00000040	7	Internal Communication 2 Error	<ul style="list-style-type: none"> - Check that the DNC/PLC-amplifier-motor ground connections and shield answer the Installation manual requirements. - Check the application EMC disturbances level.
7	0x00000080	8	IGBT module	<ul style="list-style-type: none"> - Check for no short-circuit in the motor wiring and at the motor terminals. - Check for no short-circuit between one motor phase and the ground. - Check the amplifier Rated current adjustment with regard to the allowed value in the amplifier specifications. - Check that the amplifier max. temperature specifications are fulfilled. - Check that the amplifier fan is operating correctly.
8	0x00000100	9	Main Phase Error	
9	0x00000200	10	Mains phase loss	
10	0x00000400	11	Power Module over-temperature	<ul style="list-style-type: none"> - Check the amplifier Rated current adjustment with regard to the allowed value in the amplifier specifications. - Check that the amplifier max. temperature specifications are fulfilled. - Check that the amplifier fan is operating correctly.
11				
12	0x00001000	13	Fan	<ul style="list-style-type: none"> - Available only for some drive models - Check that the fan blades are not blocked by a foreign body - Check that the fan rotor is not locked
13				
14				
15				
16	0x00010000	17	Current measurement offset	<ul style="list-style-type: none"> - Check that the motor is not driven by the mechanical load <p>If the error cannot be reset, the amplifier current sensors are out of order (wrong current measurement)</p>
17	0x00020000	18	Overcurrent	<ul style="list-style-type: none"> - Check the current loop adjustment regarding the motor inductance.

18	0x00040000	19	Encoder 1 counting error HES counting error	<p>For operation with encoder feedback:</p> <ul style="list-style-type: none"> - Check that the encoder max. pulse frequency at the max. motor speed fulfills the encoder specification. - Check that the connections between the encoder and the amplifier are complying with the shield wiring recommendations. <p><u>Remark:</u> In the incremental encoder configuration without HES, the motor Phasing procedure must be executed again after a Counting fault release.</p> <p>For operation with HES only feedback:</p> <ul style="list-style-type: none"> - Check the correct wiring of the HES signals - Check the correct supply of the HES devices - Check the value of the parameter Motor Hes error threshold. If necessary, increase the value of this parameter.
19	0x00080000	20	Resolver tracking error	<p>If the failure occurs when starting the amplifier:</p> <ul style="list-style-type: none"> - Check for the correct resolver type with regard to the amplifier specifications. <p>If the failure occurs during the operation:</p> <ul style="list-style-type: none"> - Check that the connections between the resolver and the amplifier are complying with the shield wiring recommendations.
20	0x00100000	21	Resolver (cable interrupted)	<ul style="list-style-type: none"> - Check the resolver connection on the amplifier connector according to the connector descriptions. - Check for the correct resolver type with regard to the amplifier specifications. - Check the connections between resolver and amplifier (cable wiring).
21	0x00200000	22	Encoder 1 (cable interrupted)	<ul style="list-style-type: none"> - Check the encoder supply connection on the amplifier connector. - Check the encoder A channel and B channel connections on the amplifier connector. <p><u>Remark:</u> In the Incremental encoder configuration without HES, the motor Phasing procedure must be executed again after an Encoder fault release.</p>
22	0x00400000	23	Encoder 1 (Z marker)	<ul style="list-style-type: none"> - Check the marker pulse connection on the amplifier connector. If the motor encoder is not providing a marker pulse channel, the amplifier counting protection must be disabled by setting at 0 the Zero mark pitch parameter. - Check that the Motor encoder resolution and the Zero mark pitch parameter values are correct. <p><u>Remark:</u> In the incremental encoder configuration without HES, the motor Phasing procedure must be executed again after a Counting fault release.</p>
23	0x00800000	24	Encoder 2 link	<ul style="list-style-type: none"> - Check the encoder connection on the amplifier connector.
24	0x01000000	25	Sensorless error	<ul style="list-style-type: none"> - Check the value of the parameter Motor Emf error threshold. Its value must be greater than the sensorless parameter Low speed threshold value. - Check the sensorless parameter Motor emf constant value is correct.
25	0x02000000	26	Ambient Temperature	<ul style="list-style-type: none"> - Check that the amplifier operating temperature limit specification is fulfilled. - Check that the amplifier cooling system is operating correctly. - Check the amplifier Rated current adjustment with regard to the allowed value in the amplifier specifications.
26	0x04000000	27	Motor Brake	
27	0x08000000	28	Power Stage Controller Error	<ul style="list-style-type: none"> - Generic default for the amplifier power stage
28	0x10000000	29	Manufacturer parameters error	<ul style="list-style-type: none"> - Switch off and on again the 24 V logic supply <p>If the error cannot be reset, the amplifier is out of order.</p>
29	0x20000000	30	Internal Communication 1 error	<ul style="list-style-type: none"> - Check that the DNC/PLC-amplifier-motor ground connections and shield answer the Install manual requirements. - Check the application EMC disturbances level.
30	0x40000000	31	Configuration error	
31	0x80000000	32	System error	<ul style="list-style-type: none"> - Switch off and on again the 24 V logic supply <p>If the error cannot be reset, the amplifier is out of order.</p>

Sub Index	2
Description	Error monitoring
Data Type	Unsigned32
Object Class	all
Access	ro
PDO Mapping	No
Value	See below
Default value	No

Bit	Value	Error Code	Protection	Troubleshooting
0				
1	0x00000002	34	Speed following error	<ul style="list-style-type: none"> - Check that the mechanical load is adjusted to motor and amplifier ratings. - Check that the axis is not on a mechanical limit. - Check the motor voltage limitation regarding the required max speed set point. - Check the accelerations/decelerations values. - Check the speed loop adjustment. - Check that the value of the parameter Speed following error threshold is complying with the motion cycle. If necessary, increase the value of this parameter.
2	0x00000004	35	Position following error	<ul style="list-style-type: none"> - Check that the mechanical load is adjusted to motor and amplifier ratings. - Check that the axis is not on a mechanical limit. - Check the motor voltage limitation regarding the required max speed set point. - Check the accelerations/decelerations values. - Check the position loop adjustment. - Check that the value of the parameter Following error threshold is complying with the motion cycle. If necessary, increase the value of this parameter.
3				
4	0x00000010	37	Motor Temperature error	<p>If the failure occurs when starting the amplifier:</p> <ul style="list-style-type: none"> - Check the selected thermal sensor type (NTC or PTC). - Check the connection between the thermal sensor and the amplifier connector. <p>If the failure occurs during the operation:</p> <ul style="list-style-type: none"> - Check the motor temperature and look for the reason of this overheating (mechanical shaft overload, duty cycle too high, motor type too small with regard to the machine cycle...).
5	0x00000020	38	I ² t error	Check the amplifier current cycle with regard to the Rated current parameter value.
6	0x00000040	39	System Parameters Error	
7	0x00000080	40	Busy/Operation Timeout	
8	0x00000100	41	Calibration parameters file error	<p>If the firmware has been downgraded, reload the correct firmware version.</p> <p>If the error cannot be reset after the amplifier off and on sequence it is out of order.</p>
9	0x00000200	42	Drive parameters file error	<p>If the firmware has been upgraded, execute the procedure "save parameter to Flash memory", the new parameters will be saved with their default value in the new DRIVEPAR.TXT file.</p> <p>If the firmware has been downgraded, the execution of the procedure "save parameter to Flash memory" will definitely lose some parameters in the new DRIVEPAR.TXT file. In this case, reload the correct firmware version.</p>
10	0x00000400	43	User parameters or template file error	Edit and check the "User parameter file". Some objects are not compatible with the amplifier firmware version.
11	0x00000800	44	Sequence file error	Check the Sequence file. Some parameters are not compatible with the amplifier firmware version.
12	0x00001000	45	Cam file error	
13	0x00002000	46	Extension Error or Fieldbus watchdog error	
14	0x00004000	47	Extension Error or Fieldbus hardware error	
15	0x00008000	48	Extension Error or Fieldbus hardware error	

16	0x00010000	49	Fieldbus SYNC cycle error	<ul style="list-style-type: none"> - Check fieldbus cycle period (object 0x1006) - Check fieldbus SYNC signal timing: if great jitter (\geqhalf-period) or period accuracy is not within the tolerance ($\geq 0.4\%$).
17	0x00020000	50	Fieldbus IP reference underflow/overflow	<ul style="list-style-type: none"> - Check if IP reference (0x60C1,1) is mapped in a RPDO - If yes, check if this RPDO is sent every bus cycle - To avoid a mix-up, this RPDO must precede the SYNC signal at least of 100 μs
18	0x00040000	51	Fieldbus guarding error	For CANopen: Node guarding error or Heartbeat error.
19				
20	0x00100000	53	SD card error	See details in the SD card chapter.
21	0x00200000	54	File Erase/Write Error	Renew the file transfer.
22	0x00400000	55	Watchdog Error	
23	0x00800000	56	Safety channel 1 Error	<ul style="list-style-type: none"> - Check the correct STO1 input state regarding STO2 input state If the STO fault is released, the drive must be turned off in order to cancel the fault.
24	0x01000000	57	User Program Error	
25	0x02000000	58	CAN Extension Module communication lost or not found	
26	0x04000000	59	Encoder 2 Absolute Error	
27	0x08000000	60	Stop Operation failed or speed/position monitoring failed.	<ul style="list-style-type: none"> - Check stop/monitoring parameters.
28	0x10000000	61	Encoder 1 Commutation channel / Incremental channel Error	<p>For the Incremental encoder & HES configuration:</p> <ul style="list-style-type: none"> - Check for the correct HES supply voltage value. - Check that the HES are correctly wired on the amplifier connector. - Check the parameter Reverse HES track and toggle it if not correct. - Check for the correct value of the parameter Motor encoder resolution. - Check that the HES-amplifier-motor ground connections and shield answer requirements contained in the Installation manual. <p>For the Absolute encoder (Hiperface®) configuration:</p> <ul style="list-style-type: none"> - Check the parameter Reverse incremental track and toggle it if not correct. - Check that the SinCos channels are correctly wired on the amplifier connector. - Check that the Data communication channel is correctly wired on the amplifier connector. - Check that the encoder-amplifier-motor ground connections and shield answer the requirements contained in the Installation manual. <p>For the SinCos encoder with CD tracks configuration:</p> <ul style="list-style-type: none"> - Check for the correct SinCos encoder supply voltage value. - Check that the encoder CD channels are correctly wired on the amplifier connector. - Check the parameter Reverse CD track and toggle it if not correct. - Check that the parameter Motor encoder resolution value is correct. - Check for the correct encoder C and D channels signal waveforms. - Check that the encoder-amplifier-motor ground connections and shield answer the requirements contained in the Installation manual.
29	0x20000000	62	Encoder 1 Absolute channel Error	<ul style="list-style-type: none"> - Check for the correct encoder supply voltage value. - Check that the Data communication channel is correctly wired on the amplifier connector. - Check that the encoder-amplifier-motor ground connections and shield answer the requirements contained in the Installation manual.

30	0x40000000	63	User Program execution error	
31	0x80000000	64	Procedure error (Autotuning, autophasing...)	<p>- If the Procedure fault is continuously displayed after the execution of the AUTO-PHASING function, the procedure has failed because of an external cause and the calculated parameters are wrong. Check that the limit switch inputs are not active. Then check that the motor is unloaded and the shaft movement free during the procedure.</p> <p>- If the Procedure fault is continuously displayed after the execution of the AUTO-TUNING function, the procedure has failed because of an external cause and the calculated parameters are wrong. Check that the limit switch inputs are not active. Then check that the motor shaft is free during the procedure.</p>

Error Control

Index	0x3025
Name	Error control
Object Code	ARRAY
Number of Elements	8

Value Description

Sub Index	1
Description	Error mask 1
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-1
Default value	No

Sub Index	2
Description	Error mask 2
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-2
Default value	No

These 2 elements (0x3025,1 and 0x3025,2) allow the inhibition of the corresponding error.

Sub Index	3
Description	Error Stop 2 mask 1
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-1
Default value	No

Sub Index	4
Description	Error Stop 2 mask 2
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-2
Default value	No

These 2 elements (0x3025,3 and 0x3025,4) allow triggering a stop 2 when the corresponding error occurs.

Sub Index	5
Description	Error Stop 3 mask 1
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-1
Default value	No

Sub Index	6
Description	Error Stop 3 mask 2
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-2
Default value	No

These 2 elements (0x3025,5 and 0x3025,6) allow triggering a stop 3 when the corresponding error occurs.

Stop On Error operation

Drive parameters 0x3025,3 and 0x3025,4 (Error Stop 2 mask) allow selecting a Stop 2 behaviour (Slow down ramp) for a given drive fault when this fault occurs.

Drive parameters 0x3025,5 and 0x3025,6 (Error Stop 3 mask) allow selecting a Stop 3 behaviour (Slow down in current limitation) for a given drive fault when this fault occurs.

On a given fault occurrence, if the corresponding bit is equal to 0 in both “Error Stop 1 mask” and “Error Stop 3 mask” parameters, a Stop 0 is executed (power stage switched off and motor brake activated). This is the default drive configuration for the Stop on error functionality.

The Stop 2 and Stop 3 selections are not compatible with any fault occurrence situation.

The conditions for a possible Stop 3 operation are listed below:

- Motor power control is fully operating,
- Motor position feedback signal is not corrupted.

The Stop 2 selection is more restrictive than Stop 3 because the slow-down ramp requires a correct motion control chaining when the fault occurs. The conditions for a possible Stop 2 operation are listed below:

- Motor power control is fully operating,
- Motor position feedback signal is not corrupted,
- Position and speed set point are not corrupted.

The Stop 2 or Stop 3 selection requires a careful failure case analysis. The drive operating mode, the application context and the machine safety requirements must all be considered.

For example, in the Interpolated Position mode, if a communication error occurs, the drive internal position set point is corrupted and can cause a wrong slow-down ramp chaining. This situation may result in an uncontrolled motor movement. But if the drive is operating in Sequence mode, the drive position set point is not concerned by the fieldbus communication and the Stop 1 selection is then possible.

If an exhaustive failure case analysis in the application context cannot be carried out, Stop 0 must be selected.



CAUTION !

A wrong “Stop on error” selection may cause uncontrolled motor movements that may be dangerous for operator and machine. It is the user's responsibility to check that a Stop 0 or Stop 2 or Stop 3 selection is compatible with his application.

Most faults are not compatible with the Stop 3 or Stop 2 selections. The possible “Stop on error” selection regarding the drive faults is listed in the chart below. When Stop 2 and Stop 3 are both compatible, the Stop 3 selection must be preferred.

Error Code	Protection	Possible Stop on error selection	Remarks
34	Velocity following error	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
35	Position following error	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
36	Software position limit	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
37	Motor Temperature error	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
38	I ² t error	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
46	Extension Error or Fieldbus watchdog error	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
49	Fieldbus SYNC cycle error	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
50	Fieldbus IP reference underflow/overflow	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
51	Fieldbus guarding error	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
58	CAN Extension Module communication lost or not found	Stop 0 or Stop 2 or Stop 3	Stop 2 selection requires a careful fault occurrence analysis
Other		Stop 0 only	

Important note: When a Stop 2 or Stop 3 is executed due to a fault occurrence, a second fault occurrence with Stop 2 or Stop 3 selection cannot be considered.

Sub Index	7
Description	AOK mask 1
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-1
Default value	0x0000 0004 (UnderVoltage)

Sub Index	8
Description	AOK mask 2
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Value	See 0x3022-2
Default value	0x0000 0000

These 2 elements (0x3025,7 and 0x3025,8) allow selecting the errors not considered for the AOK signal deactivation. Errors with the higher criticism regarding fire risk (power stage, braking system) cannot be masked.

Xtrapuls™ drive Error Codes and DS-402 Error Codes

Infranor code	Description (Gem Drive Studio) Object: 0x3023,4	DSP402 code	Description (CANopen DSP-402) Object: 0x603F,0
0	No Error	0x0000	Error Reset or No Error
1	Hardware System 2 Error	0x5080	Device Hardware
2	24 Volt Error	0x5112	Supply Low Voltage 24V
3	Undervolt.	0x3220	DC link undervoltage
4	Braking system error	0x7110	Brake Chopper
5	Safety channel 2 Error	0x9082	External Error
6	Overvoltage	0x3210	DC link overvoltage
7	Internal Communication 2 Error	0x6182	Internal Software
8	IGBT module	0x2230	Short circuit/Earth leakage (device internal)
9	reserved	0x3130	
10	reserved	0x3130	
11	Power Module over-temperature	0x4210	Excess Temperature Device
12	Power Module over-temperature (not for all the Xtrapuls range)	0x4210	Excess Temperature Device
13	Fan failure (not for all the Xtrapuls range)	0x5090	Device Hardware
14	reserved	0x1000	
15	reserved	0x1000	
16	reserved	0x1000	
17	Current measurement offset	0x5210	Control: Measurement circuit
18	Overcurrent	0x2310	Continuous over current
19	Encoder counting error	0x7305	Incremental sensor 1 fault
20	Resolver tracking error	0x7303	Resolver 1 fault
21	Resolver (cable interrupted)	0x7303	Resolver 1 fault
22	Encoder (cable interrupted)	0x7305	Incremental sensor 1 fault
23	Encoder (Z marker)	0x7305	Incremental sensor 1 fault
24	reserved	0x1000	
25	reserved	0x1000	
26	reserved	0x1000	
27	Motor Brake Error (not for all the Xtrapuls range)	0x7120	Motor
28	Power Stage Controller Error	0xFF80	Manufacturer specific
29	Manufacturer parameters error	0x50A1	Device Hardware
30	Internal Communication 1 error	0x6181	Internal Software
31	Configuration error	0x6320	Parameter Error
32	System error	0x50A0	Device Hardware
33	reserved	0x8300	Torque Control
34	Velocity Speed following error	0x8400	Velocity Speed Controller
35	Position following error	0x8611	Following Error
36	Software Position Limit	0x8680	Positioning Controller
37	Motor Temperature error	0x4290	Device Temperature
38	I ² t error	0x2350	Load level fault (I ² t, thermal state)
39	System Parameters Error	0x6190	Internal Software
40	Busy	0xFFA0	Manufacturer specific
41	Calibration parameters file error	0x6320	Parameter Error
42	Drive parameters file error	0x6320	Parameter Error
43	User parameters file error	0x6320	Parameter Error
44	Sequence file error	0x6320	Parameter Error
45	Cam file error (not for all the Xtrapuls range)	0x6320	Parameter Error
46	Extension Error or Fieldbus watchdog error	0x8181	Communication
47	Extension Error or Fieldbus hardware error	0x50B2	Device Hardware
48	Extension Error or Fieldbus hardware error	0x50B3	Device Hardware
49	Fieldbus SYNC cycle error	0x8780	Sync Controller
50	Fieldbus IP reference underflow/overflow	0x8782	Sync Controller
51	Fieldbus guarding error	0x8130	Life Guard Error or Heartbeat Error
52	reserved	0x1000	

53	SD card error (not for all the Xtrapuls range)	0x7600	Data Storage (external)
54	File Erase/Write Error	0x6320	Parameter Error
55	Watchdog error	0x5220	Control: Computing circuit
56	Safety channel 1 (STO) Error	0x9081	External Error
57	User Code Error	0x6282	User Software
58	CAN Extension Module communication lost or not found	0x7580	Communication
59	reserved	0x1000	
60	Stop Operation failed or speed/position monitoring failed	0xFF10	Manufacturer specific
61	Encoder: Commutation channel / Incremental channel error	0x7305	Incremental sensor 1 fault
62	Encoder: Absolute channel error	0x7305	Incremental sensor 1 fault
63	User Program Error (not for all the Xtrapuls range)	0x6280	User Software
64	Procedure error (Auto-tuning, auto-phasing...)	0xFFA2	Manufacturer specific

3.2.1.2.2 - Warning

Warning:

Warning is displayed in object 0x3024,0 (32-bit).

Warning bit in status (bit 7) is also set.

Warning cannot be cleared by the user, it will automatically be cleared when the origin of the warning is discarded.

Warning Code

Index	0x3024
Name	Warning Code
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	ro
PDO Mapping	Possible
Default Value	0

Bit	Value	Warning Code	Function
0	0x00000001	1	STO active
8	0x00000100	9	TBC: Cogging Torque
9	0x00000200	10	Mains phase loss
10	0x00000400	11	IGBT module temperature
11			
12	0x00001000	13	Fan
13	0x00002000	14	Daughter board/Plugin software incompatible
14	0x00004000	15	Daughter board/Plugin hardware not ready
15	0x00008000	16	Daughter board/Plugin software not ready
16	0x00010000	17	Limit Switch
17	0x00020000	18	Ambient temperature
18	0x00040000	19	I ² t
19	0x00080000	20	Undervoltage
20	0x00100000	21	SoftStart forced
21	0x00200000	22	Motor temperature
22			
23			
24	0x01000000	25	Position limit
25	0x02000000	26	CAN Extension Module communication lost or not found
26	0x04000000	27	Encoder 2 multi-turn absolute init/overflow
27			
28	0x10000000	29	Encoder 1 multi-turn absolute init/overflow
29	0x20000000	30	Cannot read/write to encoder
30	0x40000000	31	Motor phasing Init not ok
31			

3.2.1.2.3 - I²t Protection

I²t Function

Index	0x3404
Name	I ² t Function
Object Code	RECORD
Number of Elements	

Value Description

Sub Index	1
Description	I ² t Mode
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value Range	0 Limiting 1 Fusing
Default Value	

Sub Index	2
Description	I ² t signal
Data Type	Unsigned16
Access	ro
PDO Mapping	No
Default Value	No

The motor RMS current value in Amps is calculated according to the following formula:
 RMS motor current (A) = Amplifier current rating (A) x [value(0x3404-2) x 5000 / 16384]^{1/2} / 100

Sub Index	3
Description	Continuous measurement of the current
Data Type	Unsigned16
Access	ro
PDO Mapping	No
Unit	0x7FFF = drive max. current (0x6510)
Default Value	No

3.2.1.2.4 - Braking resistor Protection

Braking resistor duty cycle limit

Index	0x33B0
Name	Braking resistor duty cycle limit
Description	This parameter allows the protection of the braking resistor against overheating and failure.
Object Code	ARRAY
Number of Elements	2


Value Description

Sub Index	1
Name	Braking system operation
Value Range	0 = External braking resistor 1 = Internal braking resistor
Default Value	0 : operation only with an external braking resistor


Sub Index	2
Name	Duty cycle limit
Description	The braking resistor duty cycle limit parameter allows limiting the external braking resistor average power in order to protect it against overheating and failure. This parameter value is calculated according to the braking resistor specifications as described below: Duty cycle limit = Braking resistor rated power (W) x Braking resistor ohmic value (Ohms) / Braking on threshold (V) / Braking on threshold (V)
Data Type	Unsigned16
Object Class	All
Access	rw
PDO Mapping	No
Value Range	0-70
Unit	%
Default Value	70

3.2.1.3 - Stop Operation


Stop 1 - stop on speed ramp: the motor is slowed down in position loop with a slow down ramp. The initial speed is defined with the reference speed.



Stop 2 - stop on speed ramp: the motor is slowed down in speed loop with a quick stop speed ramp. The initial speed is defined with the current motor speed.



Stop 3 - stop on current limit: the motor is slowed down in velocity loop with a current limitation.



Stop option code	Action
0	Disable drive
1	Stopped on Slow down speed ramp and disabled
2	Stopped on Quick Stop speed ramp and disabled
3	Stopped on current limit and disabled
5	Stopped on Slow down speed ramp and stay in Quick Stop state
6	Stopped on Quick Stop speed ramp and stay in Quick Stop state
7	Stopped on current limit and stay in Quick Stop state

When a transition of the state machine occurs, a stop can be performed. These transitions are:

- Quick Stop (transition 11)
- Disable Operation (transition 5)
- Shut down (transition 8)

Each transition can have different ways to stop, respectively defined in objects 0x605A, 0x605C and 0x605B.

Hardware limit switches stop with slow down speed ramp (with parameter in 0x3300,1)

The Inhibit input internally connected to the IN4 physical input used for STO disables the drive.

Stop on current limit uses the current limit value defined in object 0x3301,1

Stop on slow down speed ramp uses the speed ramp defined in object 0x3300,1

Stop on quick stop speed ramp uses the speed ramp defined in object 0x6085,0

Object definitions

Index	Object	Name	Type	Attr.
0x605A	VAR	Quick Stop Option Code	Integer16	rw
0x605B	VAR	Shut down Option Code	Integer16	rw
0x605C	VAR	Disable Operation Option Code	Integer16	rw
0x305A	VAR	Inhibit Option Code	Integer16	rw
0x3300	ARRAY	Slow down ramp	Unsigned32	rw
0x6085	VAR	Quick Stop ramp	Unsigned32	rw
0x3301	ARRAY	Stop Current Limit	Integer16	rw
0x3302	ARRAY	Stop Time Limit	Unsigned16	rw
0x3304	VAR	Amplifier Reaction Time	Unsigned16	rw
0x3305	VAR	Motor Brake Reaction Time	Unsigned16	rw

Quick Stop Option Code

Index	0x605A
Name	Quick Stop Option Code
Object Code	VAR
Data Type	integer16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	1

This object defines the stop behaviour when a QUICK_STOP command is executed (see Drive State Machine transition 11).

Quick stop option code	Action
0	Disable drive
1	Stopped on Slow down speed ramp and disabled
2	Stopped on Quick Stop speed ramp and disabled
3	Stopped on current limit and disabled
5	Stopped on Slow down speed ramp and stay in Quick Stop state
6	Stopped on Quick Stop speed ramp and stay in Quick Stop state
7	Stopped on current limit and disabled and stay in Quick Stop state

Shut Down Option Code

Index	0x605B
Name	Shut Down Option Code
Object Code	VAR
Data Type	integer16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This object defines the stop behaviour when a SHUTDOWN command is executed (see Drive State Machine transition 8).

Shut down option code	Action
0	Disable operation
1	Stopped on Slow down speed ramp
2	Stopped on Quick Stop speed ramp
3	Stopped on current limit

Disable Operation Option Code

Index	0x605C
Name	Disable Operation Option Code
Object Code	VAR
Data Type	integer16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	1

This object defines the stop behaviour when a DISABLE_OPERATION command is executed (see Drive State Machine transition 5).

Disable operation option code	Action
0	Disable operation
1	Stopped on Slow down speed ramp
2	Stopped on Quick Stop speed ramp
3	Stopped on current limit

Inhibit Option Code

Index	0x305A
Name	Inhibit Option Code
Object Code	VAR
Data Type	integer16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	1

This object concerns the stop behaviour when the Inhibit logic input is activated (see Digital Inputs 0x60FD).

Inhibit option code	Action
0	Disable drive
1	Stopped on Slow down speed ramp and disabled
2	Stopped on Quick Stop speed ramp and disabled
3	Stopped on current limit and disabled

The Inhibit input is internally connected to the IN4 physical input used for the drive STO function. So, the Inhibit activation immediately disables the drive regardless from the 0x305A parameter value.

However, when the IN4 input is used for the drive Enable / Disable operation, the “Stopped on current limit and disabled” action must be selected. The parameter Stop Time Limit 2 (0x3302,2) value must be greater than the motor freewheeling stop time in order to avoid the “Stop operation” fault to be released.

Slow Down Ramp

Index	0x3300
Name	Slow Down Ramp
Object Code	ARRAY
Number of Elements	2

These parameters define the slow down deceleration with a stop executed with stop option code = 1 or 5 (Stopped on Slow down ramp).

Value Description

Sub Index	1
Description	Slow Down Ramp 1
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	Acceleration unit
Default Value	

Sub Index	2
Description	Slow Down Ramp 2 reserved for future use.
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	Acceleration unit
Default Value	

Quick Stop Ramp

Index	0x6085
Name	Quick Stop Ramp
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	Acceleration unit
Default Value	0x00200000

This object defines the deceleration for a quick stop with Quick Stop Option Code = 2 or 6 (Stopped on Quick Stop ramp).

Stop Current Limit

Index	0x3301
Name	Stop Current Limit
Object Code	ARRAY
Number of Elements	2

Value Description

Sub Index	1
Description	Stop Current Limit 1 This parameter defines the current limit when a stop on current limit is performed.
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	per thousand of rated current
Value Range	100..6000
Default Value	1000

This parameter is used with a Quick Stop with Quick Stop Option Code = 3 or 7 (Stopped on current). This parameter is also applied with a stop at limit switches.

Sub Index	2
Description	Stop Current Limit 2
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	per thousand of rated current
Value Range	100..6000
Default Value	1000

This parameter is reserved for future use.

Stop Time Limit

Index	0x3302
Name	Stop Time Limit
Object Code	ARRAY
Number of Elements	2

These parameters define the time limit for a stop operation.

When a stop on current limit is executed, the end of the stop may not be correctly detected if the axis is oscillating. The time stop limit allows limiting the execution time of the stop operation.

Value Description

Sub Index	1
Description	Stop Time Limit 1 Time limit for all stop operations with ramp.
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0..65000
Default Value	1000

Sub Index	2
Description	Stop Time Limit 2 Time limit for all stop operations with current limit.
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0..65000
Default Value	1000

3.2.2 - Drive Parameters

3.2.2.1 - Motor parameters

The motor parameters are stored in object 0x6410
These values are the parameters given in the motor manufacturer's catalogue.

The motor control parameters
number of pole pairs (0x6410-14),
motor phase (0x6410-15),
motor offset (0x6410-16)

will be respectively copied in objects 0x3410-1, 0x3410-2 and 0x3410-3.

Object 0x3410 can be possibly modified and will be used for the motor control (i.e. if the resolver wiring or adjustment is not correct).

The auto-phasing procedure will calculate these parameters of object 0x3410.

The motor inductance parameter of the catalogue (0x6410-13) will be copied in object 0x340F-0 and will be used for calculating the current loop gains (0x60F6).

Object 0x340F-0 can be possibly modified before calculating the gains if inductances are serially mounted with the motor.

The Maximum Motor Speed (0x6410-7) parameter of the catalogue will clip the motor speed peaks in 0x6080.

Index	0x6410
Name	Motor Data
Object Code	RECORD
Object Class	all
Number of Elements	19

This object defines the manufacturer's motor data.

Value Description

Sub Index	1
Description	Motor Manufacturer Name
Data Type	String
Access	rw
PDO Mapping	No
Value	Maximum 30 characters

Sub Index	2
Description	Motor Model Name
Data Type	String
Access	rw
PDO Mapping	No
Value	Maximum 30 characters

Sub Index	3
Description	Motor Code Special code or personalisation code.
Data Type	String
Access	rw
PDO Mapping	No
Value	Maximum 30 characters

Sub Index	4
Description	Catalog Date Code
Data Type	Unsigned16
Access	rw
Object Class	all
PDO Mapping	No

The structure of the entries is the following:

MSB			LSB
Year (7-bit)	Month (4-bit)	Date (5-bit)	

Year is relative to 1984.

Sub Index	5
Description	Modification Date Code
Data Type	Unsigned16
Access	rw
PDO Mapping	No

Sub Index	6
Description	Motor Type
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	

Bits	Description
0..7	Axis Type 0 Rotating 1 Linear
8..15	Motor Type 0 Brushless motor 4 Induction motor 8 DC motor

The motor type will be copied in 0x6402,0

Sub Index	7
Description	Motor Max Speed
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	rpm

When writing to this parameter, its value will also be written to 0x6080,0.

Sub Index	8
Description	Motor Rated Speed
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	rpm

Sub Index	9
Description	Motor Stall Current
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	mA

The value written in this object can consequently modify the value of 0x6075

Sub Index	10
Description	Motor Peak Current
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	mA

The value written in this object can consequently modify the value of 0x6073

Sub Index	11
Description	Torque Constant (Kt)
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Unit	0.001Nm/A

Sub Index	12
Description	Inertia
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Unit	0.001gm ²

Sub Index	13
Description	Inductance
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Unit	0.1mH

When writing to this parameter, its value will also be written to 0x340F,0

Sub Index	14
Description	Number of motor pole pairs
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	1..24

When writing to this parameter, its value will also be written to 0x3410,1

Sub Index	15
Description	Motor Phase
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	0x5555 or 0xAAAA (corresponding to 240° or 120°)

When writing to this parameter, its value will also be written to 0x3410,2

Sub Index	16
Description	Motor Sensor Offset
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	

When writing to this parameter, its value will also be written to 0x3410,3

Sub Index	17
Description	Motor Temperature Probe
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	

Sub Index	18
Description	Motor Temperature Warning Threshold
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	

Sub Index	19
Description	Motor Temperature Error Threshold
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	

Index	0x3410
Name	Motor Control Parameters
Object Code	ARRAY
Object Class	all
Number of Elements	3

This object defines the parameters which control the motor.

Value Description

Sub Index	1
Description	Number of motor pole pairs
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	1..24

Sub Index	2
Description	Motor Phase
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	0x5555 (240°) 0xAAAA (120°)

Sub Index	3
Description	Motor Offset
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Value	

Auto-phasing procedure

Index	0x3413
Name	Start Auto-phasing procedure
Object Code	
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No

In order to avoid running the auto-phasing procedure by mistake, the auto-phasing is only executed when a specific signature is written to this sub-index. The signature is 'apha'.
Signature = 0x61687061

Writing 0 to this object when auto-phasing is running will abort the procedure.

When reading, this object returns the operation status:

Read Value	Meaning
0	Procedure never executed
1	Cannot execute
2	Procedure running
3	Procedure aborted by user
4	Procedure stopped on error
>= 5	Procedure performed

When running, the BUSY bit of status word (0x6041) is set.

The auto-phasing procedure calculates these parameters:
number of pole pairs 0x3410,1
motor phase 0x3410,2
motor offset 0x3410,3

Motor phasing procedure

Index	0x3414
Name	Start Motor phasing procedure
Object Code	
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No

In order to avoid running the motor phasing procedure by mistake, the motor phasing is only executed when a specific signature is written to this sub-index. The signature is 'mcal'.
Signature = 0x6C61636D

Writing 0 to this object when motor phasing is running will abort the procedure.

When reading, this object returns the operation status:


Read Value	Meaning
0	Procedure not executed
1	Cannot execute
2	Procedure running
3	Procedure aborted by user
4	Procedure stopped on error
>= 5	Procedure performed

When running, the BUSY bit of status word (0x6041) is set.

The motor phasing procedure calculates these parameters: motor offset 0x3410,3

3.2.2.2 - Motor Brake

Servo On/Off Timing Diagram



T_brake: Motor Brake Reaction Time

T_drive: Drive Reaction Time

Index	Object	Name	Type	Attr.
0x3304	VAR	Amplifier Reaction Time	Unsigned16	rw
0x3305	VAR	Motor Brake Reaction Time	Unsigned16	rw

Note 1: The motor brake control is automatic with Switch On/Off by the control_word. To disable the motor brake control, it is necessary to set at 1 bit 0 of object 60FE sub-index 2 (digital output bitmask). The motor brake is then manually controlled by bit 0 of object 60FE sub-index 1.

Note 2: When IN4 input is used for the drive Enable / Disable operation, T_brake delay is not operating on drive disabled.

Drive Reaction Time

Index	0x3304
Name	Drive Reaction Time
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0..65535
Default Value	x

This parameter defines the reaction time of the drive when enabled / disabled.

Motor Brake Reaction Time

Index	0x3305
Name	Motor Brake Reaction Time
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0..65535
Default Value	0

This parameter defines the reaction time of the motor brake.

3.2.2.3 - Motor current limits & Current Loop

The parameters defining the current limitation to be applied to the motor are the following:

- Motor Max. Current 0x6073
- Motor Rated Current 0x6075

The motor parameters **Motor Peak Current** (0x6410-10) and **Motor stall Current** (0x6410-9) will be used for calculating the internal limitations of the drive according to the drive maximum and rated currents (0x6510). The values of the drive internal limitations can be displayed by object 0x30F4.

The current loop gains are accessible in object 0x60F6.

Object 0x3411 allows:

- calculating the current loop gains according to the motor parameters and the drive specifications:

Parameters:

- Inductance (0x340F)
- Drive Max. current (0x6510-1)

Results:

- Current Loop Gains (0x60F6)

Object 0x3412 allows:

- calculating the drive current limitations according to the motor and drive currents (0x6510):

Parameters:

- Motor Peak current (0x6410-10)
- Motor Stall current (0x6410-9)
- Drive Max current (0x6510-1)
- Drive Rated current (0x6510-2)

Results:

- Motor Max current (0x6073-0)
- Motor Rated current (0x6075-0)

The input parameters must be previously defined.

Manufacturer Drive Data

Index	0x6510
Name	Manufacturer Drive Data
Object Code	ARRAY
Number of Elements	5

This object indicates the peak current and the rated current supported by the power module.

Value Description

Sub Index	1
Description	Drive Max. Current gives the drive rating
Data Type	Unsigned32
Access	ro
PDO Mapping	No
Unit	mA

Sub Index	2
Description	Drive Rated Current gives the drive rated current
Data Type	Unsigned32
Access	ro
PDO Mapping	No
Unit	mA

Sub Index	3
Description	Drive Voltage gives the drive voltage (AC value)
Data Type	Unsigned16
Access	ro
PDO Mapping	No
Unit	V

Sub Index	4
Description	Drive Operating Voltage Defines the drive operating voltage (AC value)
Data Type	Unsigned16
Access	rw
Backup	drive's parameter file
PDO Mapping	No
Unit	V
Value	Possible values: 400, 230, 48, 34 or 17 And must be less than or equal to Drive Voltage (0x6510-3)

Sub Index	5
Description	Power Supply Voltage Threshold Defines the Undervoltage error level.
Data Type	Unsigned16
Access	Rw
Backup	drive parameter file
PDO Mapping	No
Unit	V
Range	See below
Default value	See below

Drive Voltage = 400 Vac

Drive Operating Voltage	Undervoltage min value	Undervoltage max value	Undervoltage default value
400 Vac	40	210	210
230 Vac	20	100	100
48 Vac	10	50	30
34 Vac	10	40	20
17 Vac	10	20	17

Drive Voltage = 230 Vac

Drive Operating Voltage	Undervoltage min value	Undervoltage max value	Undervoltage default value
230 Vac	20	100	100
48 Vac	10	50	30
34 Vac	10	40	20
17 Vac	10	20	17

Index	0x3411
Name	Current Loop Calculation
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

When the motor inductance (0x6410) and drive current (0x6510) are correct, this object allows calculating the current loop parameters.

In order to avoid running this operation by mistake, the user must write a specific signature to this object to make the calculation.

The signature is 'calc'.

Signature = 0x636C6163

The parameters calculated are in object 0x60F6.

This procedure also calculates the current limit values (0x6073 and 0x6075)

Index	0x3412
Name	Current Limitation Calculation
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

Signature = 0x636C6163

This procedure calculates the current limit values (0x6073 and 0x6075)

Index	0x6073
Name	Motor Max. current
Object Code	VAR
Data Type	Integer16
Object Class	all
Access	rw
PDO Mapping	No
Unit	per thousand of rated current (0x6075)
Value Range	
Default Value	

This object defines the maximum current the drive can supply the motor with.

Index	0x6075
Name	Motor Rated Current
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	rw
PDO Mapping	No
Unit	mA
Value Range	
Default Value	

This object defines the maximum current the drive can supply the motor with.

Current Loop Parameters

This object defines the parameters of the current loops.

Index	0x60F6
Name	Current Loop Parameter Set
Object Code	RECORD
Number of Elements	5

Value Description

Sub Index	1
Description	Regulator Type
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	0

Sub Index	2
Description	q-Loop Proportional Gain
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	

Sub Index	3
Description	q-Loop Integral Gain
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	

Sub Index	4
Description	d-Loop Proportional Gain
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Value Range	0..65535
Default Value	

Sub Index	5
Description	d-Loop Integral Gain
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	

Index	0x60B2
Name	Torque Offset This object allows adding an offset to the current command.
Object Code	VAR
Data Type	Integer16
Object Class	all
Access	rw
PDO Mapping	Yes
Unit	per thousand of rated current (0x6075)
Default Value	0
Remark	This offset is continuously active when the drive is enabled.

Index	0x30B3
Name	Torque Offset 2 This object allows adding an offset to the current command after the drive current limitation.
Object Code	VAR
Data Type	Integer16
Object Class	all
Access	rw
PDO Mapping	Yes
Unit	per thousand of rated current (0x6075)
Default Value	0
Remark	Caution: the dynamic current limitation (0x30D1) is not considered with this current offset. This offset is continuously active when the drive is enabled.

The "Current Actual Value" gives the value of the DC current in the drive. This signal is filtered by a low-pass filter (0x3078)

Index	0x6078
Name	Current Actual Value
Object Code	VAR
Data Type	Integer16
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	per thousand of motor rated current (0x6075)
Value Range	-
Default Value	-

Low-pass filter on “Current Actual Value” (0x6078)

Index	0x3078
Name	Current measurement filter
Object Code	VAR
Data Type	Integer16
Object Class	all
Access	rw
PDO Mapping	No
Unit	Hz
Default Value	1000

Undervoltage Warning Threshold

Index	0x3079
Description	Power Supply Voltage Threshold Defines the undervoltage warning level on the DC bus.
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
Backup	drive parameter file
PDO Mapping	No
Unit	mV
Default Value	0
Remark	When this parameter value is 0, the “Undervoltage” bit is not controlled (reset to 0) in object 0X3024 (drive warning).

When the DC bus voltage value drops below this parameter value, the “Undervoltage” bit is activated in object 0X3024 (drive warning).

3.2.2.4 - Dynamic current limits

The current applied to the motor is dynamically limited by the value of a defined object. By default, object 0x30D1 is used to limit the motor current (defined in 0x30DA).

The default value of object 0x30D1 is 0x3FFF and corresponds to the maximum current set by the user (0x6073).

Dynamic Current Limit Input Source

Index	0x30DA
Name	Dynamic Current Limit Input Source
Description	Index/sub-index of input data
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0x30D10000
Value	See below

This object allows connecting any dataflow as the source of the Dynamic Current Limit.

By default the object 0x30D1 is used as Dynamic Current Limit signal.

The structure of the entries is the following:

MSB	LSB
Index (16-bit)	Sub-index (8-bit) 0

Current Limit

Index	0x30D1
Name	Current Limit
Description	This object allows limiting the current dynamically applied to the motor. Changes on this object will be continuously effective.
Data Type	integer16
Object Class	all
Access	rw
PDO Mapping	Yes
Default Value	0x3FFF
Value	0-0x3FFF 0x3FFF corresponds to the maximum value setting (0x6073) for maximum current in the motor

Dynamic Current Limit Configuration

Index	0x30D2								
Name	Dynamic Current Limit Configuration								
Description	This object allows defining the effect of Dynamic Current Limit signal.								
Data Type	Unsigned16								
Object Class	all								
Access	rw								
PDO Mapping	No								
Default Value	0								
Value	<table border="0"> <tr> <td>bit</td> <td>description</td> </tr> <tr> <td>0</td> <td>0 normal effect of the Dynamic Current Limit signal: 0 current is limited at 0 0x3FFF corresponds to the maximum current (0x6073)</td> </tr> <tr> <td>1</td> <td>reverse effect of the Dynamic Current Limit signal 0x3FFF current is limited at 0 0 corresponds to the maximum current (0x6073)</td> </tr> <tr> <td>1..15</td> <td>reserved</td> </tr> </table>	bit	description	0	0 normal effect of the Dynamic Current Limit signal: 0 current is limited at 0 0x3FFF corresponds to the maximum current (0x6073)	1	reverse effect of the Dynamic Current Limit signal 0x3FFF current is limited at 0 0 corresponds to the maximum current (0x6073)	1..15	reserved
bit	description								
0	0 normal effect of the Dynamic Current Limit signal: 0 current is limited at 0 0x3FFF corresponds to the maximum current (0x6073)								
1	reverse effect of the Dynamic Current Limit signal 0x3FFF current is limited at 0 0 corresponds to the maximum current (0x6073)								
1..15	reserved								

Current Monitor

Index	0x30D4
Name	Current monitor
Object Code	VAR
Data Type	Integer16
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	% of drive max. current (0x6510) (0x3FFF = 100% I _{max})
Value Range	-
Default Value	-

3.2.2.5 - Motor temperature probe

Index	0x3324
Name	Motor temperature probe configuration
Object Code	RECORD
Object Class	all
Number of Elements	5

This object defines the Motor temperature probe configuration.

Value Description

Sub Index	1
Description	Motor temperature type
Data Type	Integer16
Access	rw
PDO Mapping	No
Value	0 No motor temperature probe. -1 NTC probe. 1 PTC probe. 2 Digital interface probe.

Sub Index	2
Description	Motor temperature warning threshold for NTC or PTC probe.
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	Ω (ohm)
Default value	2400

This parameter defines the threshold of the equivalent resistor corresponding to the temperature at which a warning will be notified.

Sub Index	3
Description	Motor temperature error threshold for NTC or PTC probe.
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	Ω (ohm)
Default value	2400

This parameter defines the threshold of the equivalent resistor corresponding to the temperature at which an error will be triggered.

Sub Index	4
Description	Motor temperature warning threshold for digital interface probe.
Data Type	Integer16
Access	rw
PDO Mapping	No
Unit	Degree (celcius)
Default value	100

This parameter defines the threshold of the temperature at which a warning will be notified.

Sub Index	5
Description	Motor temperature error threshold for digital interface probe.
Data Type	Integer16
Access	Rw
PDO Mapping	No
Unit	Degree (celcius)
Default value	100

This parameter defines the threshold of the temperature at which an error will be triggered.

Index	0x3323
Name	Motor temperature probe monitoring
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	ro
Unit	Ω (ohm)
PDO Mapping	No

The returned value gives an image of the equivalent resistance (in Ω).

Depending on hardware configuration, the motor temperature monitoring is given by this object (equivalent resistance value) or by object 0x3325.

3.2.2.6 - IGBT temperature

IGBT module temperature value

Index	0x3328
Name	IGBT module temperature information
Object Code	VAR
Data Type	Integer 16
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	°C

3.2.2.7 - Sensors

The **XtrapulsEasy** drive can operate with 2 different position sensor types: Resolver or Encoder.

Each sensor can be selected as motor feedback or position feedback. Sensorless control can also be selected for the motor feedback.

Index	Object	Name	Type	Attr.
0x306A	VAR	Position Feedback Sensor Select	Unsigned16	rw
0x3070	VAR	Motor Feedback Sensor Select	Unsigned16	rw

Position Feedback Sensor Select

Index	0x306A
Name	Position Feedback Sensor Select
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This object defines the feedback sensor which will be used to close the position loop. Depending on drive model, not all feedback is supported.

Value	Function
0	Resolver Feedback
1	Encoder Feedback
2	Encoder 2 Feedback
4	Analogue Feedback

When motor feedback and position feedback are different (sensorless for motor feedback and encoder for position feedback, for example), both sensors must count in the same direction.

Motor Feedback Sensor Select

Index	0x3070
Name	Motor Feedback Sensor Select
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

The motor feedback sensor is used to close the servo motor torque and speed control loops. The servo motor position loop can be closed by the motor feedback sensor or with the secondary sensor (see object 0x306A). Depending on drive model, not all feedback is supported.

Value	Function
0	Resolver Feedback
1	Encoder Feedback
2	Encoder 2 Feedback
5	Sensorless control

3.2.2.7.1 - Resolver

Resolver Parameters

Index	Sub	Name	Description	Type	Attribute
0x3100		Resolver	Resolver monitoring		
	1	Res_Sin		Integer16	ro
	2	Res_Cos		Integer16	ro
	3	Res_Amp2		Unsigned16	ro
	4	Res_Mod	Resolver value for one motor revolution. (absolute single-turn) one revolution -> 16-bit	Unsigned16	ro
	5	Res_Amp		Unsigned16	ro
0x3101		Res_Setp	Resolver Setup		
	1	Res_Type			rw
	2	Res_Cfg			rw
	3	Res_Zsh			rw
	4	Res_Zsz			rw
	5	Res_NP			rw
0x3102		Res_Err	Resolver Error control		
	1	Res_Thrs		Unsigned16	rw
	2	Res_Lim		Unsigned16	rw
	3	Res_AmpF		Unsigned16	rw
	4	Res_Rdc		Unsigned32	rw
	5	Res_Filt		Unsigned16	rw
0x3104		Res_Cal	Resolver Calibration procedure		
0x3105		Res_CalV	Resolver Calibration parameters		
0x3107	0	Res_TopZ	Resolver Virtual Top Z	Unsigned16	ro
0x3108	0	Res_ofs	Resolver Offset (user position unit)	Integer32	rw
0x3109	0	Res_pos	Resolver Position (user position unit)	Integer32	ro
0x310A	0	Res_vel	Resolver Velocity (user velocity unit)	Integer32	ro
0x310C	0	Res_raw	Resolver raw position	Integer32	ro

Resolver Setup

Index	0x3101
Name	Resolver Setup
Object Code	RECORD
Number of Elements	6

Value Description

Sub Index	1
Description	Resolver Type
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

Bit Number	Description
0	1 Enabled 0 Disabled
1, 2	reserved
3	1 SinCos Track
4, 5	reserved
6	1 Absolute Single-turn
7..15	reserved

For a resolver, the setting value is 0x41
 For a SinCos track encoder, the setting is 0x49

Sub Index	2
Description	Resolver Configuration
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

Bit Number	Description
0	0 Normal direction 1 Reverse direction

Sub Index	3
Description	Resolver Virtual Top Z shift
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This parameter defines the offset between marker Z of the encoder and the virtual marker Z.
 The value is given in encoder increments (4096 increments / revolution).

Sub Index	4
Description	Resolver Virtual Top Z size
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This parameter defines the width of the virtual marker Z.
 The value is given in encoder increments (4096 increments / revolution).

The virtual marker Z is working with polling technique, the width of the virtual marker Z allows increasing the marker Z size in order to avoid a missing of the marker Z.

The status of the virtual marker Z can be read by object 0x3027

Sub Index	5
Description	Resolver Pole pairs reserved for future use
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	1

Resolver Position Offset

Index	0x3108
Name	Resolver Position Offset
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	rw
PDO Mapping	Yes
Unit	User Position Unit
Value Range	$(-2^{31})..(2^{31}-1)$
Default Value	0

Resolver Position

Index	0x3109
Name	Resolver Position
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	User Position Unit
Value Range	$(-2^{31})..(2^{31}-1)$
Default Value	-

This object monitors the resolver position:

$$\text{Resolver_Position} = \text{Resolver_Internal_Position} + \text{Resolver_Position_Offset}$$

Resolver_Position (0x3109) in user position unit is the position given by the resolver. If the position loop feedback is resolver, and the modulo function (Position Limit) is not activated, then the resolver position is the same as 0x6064.

Resolver_Internal_Position in user position unit is the resolver position value related to the initial position at power on.

Resolver_Position_Offset (0x3108) defines an offset between user position (0x3109) and internal resolver position. If the position loop feedback is resolver, this offset will be calculated by the homing procedure. At power on Resolver_Position_Offset is 0.

3.2.2.7.2 - Encoder

Encoder support types:

- TTL Incremental Encoder
- TTL Incremental Encoder + Hall Effect Sensor
- Hall Effect Sensor only

Encoder Parameters

Index	Sub	Name	Description	Type	Attribute
0x3120		Encoder1	Encoder 1		
	1	Enc1Sin		Integer16	ro
	2	Enc1Cos		Integer16	ro
	3	Enc1Amp2		Integer16	ro
	4	Enc1Mod	Encoder value for one motor revolution. one revolution -> 16-bit	Unsigned16	ro
	5	Enc1Amp		Integer16	ro
0x3121		Enc1Setp	Encoder 1 Setup		
	1	Enc1Type	Encoder 1 Type	Unsigned16	rw
	2	Enc1Cfg	Encoder 1 Configuration	Unsigned16	rw
	3	Enc1Zsh	Encoder 1 Virtual Top Z Shift	Unsigned16	rw
	4	Enc1Zsz	Encoder 1 Virtual Top Z Size	Unsigned16	rw
0x3122		Enc1Err	Encoder 1 Error Control		
	1	Enc1Cnt	-	Unsigned32	rw
	2	Enc1Thrs	-	Unsigned16	rw
	3	Enc1Lim	-	Unsigned16	rw
	4	Enc1Zlim	-	Unsigned16	rw
	5	Enc1Clim	-	Unsigned16	rw
	6	Enc1Vlim	-	Unsigned32	rw
0x3124		Enc1CalP	Encoder 1 Calibration		
0x3127	0	Enc1TopZ	Encoder 1 Virtual Top Z	Unsigned16	ro
0x3128	0	Enc1ofs	Encoder 1 Offset (user position unit)	Integer32	rw
0x3129	0	Enc1pos	Encoder 1 Position (user position unit)	Integer32	ro
0x312A	0	Enc1vel	Encoder 1 Velocity (user velocity unit)	Integer32	ro
0x312B		Enc1Ref	Encoder 1 Zero Reset		
	1	Enc1RefP	-	Unsigned32	rw
	2	Enc1RstP	Encoder 1 Reset Position	Unsigned32	rw
	3	Enc1Rst0	Encoder 1 Reset offset (Low32)	Unsigned32	rw
	4	Enc1Rst1	Encoder 1 Reset offset (High32)	Unsigned32	rw
0x312C	0	Enc1raw	Encoder 1 Raw Position	Integer32	ro
0x318D					
	1	Enc1Max0	Encoder 1 Max Value (Low32)	Unsigned32	ro
	2	Enc1Max1	Encoder 1 Max Value (High32)	Unsigned32	ro
	3	Enc1Abs0	Encoder 1 Current Value (Low32)	Unsigned32	ro
	4	Enc1Abs1	Encoder 1 Current Value (High32)	Unsigned32	ro
0x3130	0	Enc1mpos	Encoder 1 position value	Integer32	ro

Encoder Setup

Index	0x3121
Name	Encoder Setup
Object Code	RECORD
Number of Elements	6

Value Description

Sub Index	1
Description	Encoder Type
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	

Bit Number	Description
0	1 Enabled 0
1	1 TTL Encoder 0
2	1 Sin/Cos Encoder 0
3	1 Encoder with CD track 0
4	1 HES 0
5	0 HAL 60° 1 HAL 120°
6	Absolute Single-turn
7	Absolute Multi-turn
8	Reverse Incremental track / Absolute track
12-15	Communication Protocol 1 Hiperface® with sin/cos track 2 EnDat® 2.1 with sin/cos track

Sub Index	2
Description	Encoder Configuration
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	

Bit Number	Description
0	0 Normal direction 1 Reverse direction

Sub Index	3
Description	Encoder Virtual Top Z shift
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This parameter defines the offset between marker Z of the encoder and the virtual marker Z. The value is given in encoder increments (encoder resolution x 4)

Sub Index	4
Description	Encoder Virtual Top Z size
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This parameter defines the width of the virtual marker Z.
The value is given in encoder increments (encoder resolution x 4).

The virtual marker Z is working with polling technique, the width of the virtual marker Z allows increasing the marker Z size in order to avoid the missing of the marker Z.

The status of the virtual marker Z can be read by object 0x3127.

Sub Index	5
Description	Encoder Resolution x 4
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Default Value	

This parameter defines the resolution (period) of the encoder x 4.

Encoder Position Offset

Index	0x3128
Name	Encoder Position Offset
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	rw
PDO Mapping	Yes
Unit	User Position Unit
Value Range	$(-2^{31})..(2^{31}-1)$
Default Value	0

Encoder Position

Index	0x3129
Name	Encoder Position
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	User Position Unit
Value Range	$(-2^{31})..(2^{31}-1)$
Default Value	-

This object monitors the encoder position:

$$\text{Encoder_Position} = \text{Encoder_Internal_Position} + \text{Encoder_Position_Offset}$$

Encoder _Position (0x3129) in user position unit is the position given by the encoder. If the position loop feedback is encoder and modulo function (Position Limit) is not activated, then the encoder position is the same as 0x6064.

Encoder_Internal_Position in user position unit, is the encoder position value related to the initial position at power on.

Encoder_Position_Offset (0x3128) defines an offset between user position (0x3129) and internal encoder position. If the position loop feedback is encoder, this offset will be calculated by the homing procedure. At power on, Encoder_Position_Offset is 0.

If the encoder is absolute multi-turn, the Encoder_Position_Offset is saved in the drive parameter file, and is restored at power on.

3.2.2.7.3 - TTL Encoder

An incremental TTL encoder can be connected to Xtrapuls drives as motor and position feedback or only as position feedback (in case of sensorless motor control).

Motor Feedback:

Incremental TTL encoder is not absolute for motor commutation, so:

- In a first time, an auto-phasing must be performed to define the motor pole pair number, motor phase order, and encoder offset.
- Each time the drive is restarted with 24 V, a motor-phasing must be performed before the motor can be controlled.

Note:

- Motor-phasing applies torque and moves the motor
- Power supply must be on
- Please check that the motor is at standstill and its movement over one revolution dangerous neither for the operator nor for the machine.
- Motor-phasing does not work with vertical axis or axis with driving load.

Position Feedback:

If the encoder is used as a position feedback only (in case of sensorless motor control) then the encoder resolution defined in object 0x608F must be the encoder counts for one motor revolution.

3.2.2.7.4 - Hall Effect Sensor

Motor Feedback with TTL incremental encoder + HES:

The Hall effect sensors (HES) can be used with a TTL incremental encoder to avoid the motor-phasing operation each time the 24 V supply is switched on.

The Hall effect sensor parameters (0x313E) are calculated with the auto-phasing procedure.

Index	Object	Name	Type	Attr.
0x313E	VAR	HES configuration	Unsigned16	rw

Parameters depending also on the Hall effect sensor are:

- Motor phase order: 0x3410,2
- Sensor offset: 0x3410,3

Motor Feedback with HES only:

The HES can also be used without a TTL incremental encoder. However, in this case the position resolution is low, so the dynamic performances are reduced

- Enter first the motor pole pair number 0x3410,1 according to the motor catalogue.
- Execute then an auto-phasing procedure to identify, HES configuration, motor phase order, and sensor offset.

Remark: the motor pole pair number 0x3410,1 cannot be identified by the auto-phasing procedure.

Because of the low HES position resolution (number of inc per revolution = 6 x number of motor pole pair), it is difficult to close the speed and position loops at low speed and at standstill. In order to overcome this problem, the **XtrapulsEasy** drive can be switched in sensorless frequency control (SFC) below a programmable speed threshold. At standstill, the motor current can be reduced after a programmable delay.

The SFC operation parameters with HES only feedback can be adjusted with the object 0x313D.

Index	Object	Name	Type	Attr.
0x313D	VAR	HES control	RECORD	rw

Hall Effect Sensor configuration

Index	0x313E
Name	Encoder HES configuration
Description	Encoder Type
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Saved	Yes
Default Value	0

Value Description

Bit Number	Description
0-2	HES initial state
3	Direction
4	Type: 0 60° 1 120°

Manual Configuration for an incremental encoder + HES:

- 0x3121,1 = 0x0013 ; incremental TTL encoder + HES
- 0x313E,0 = HES config
- 0x3410,1 = pole pairs
- 0x3410,2 = phase order
- 0x3410,3 = sensor offset (mechanic)

HES control

Index	0x313D
Name	HES only control
Object Code	RECORD
Number of Elements	7

Value Description

Sub Index	1 and 2
Description	Reserved
PDO Mapping	No

Sub Index	3
Description	Motor low speed threshold for SFC operation
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	rpm
Default Value	0

This parameter defines the motor speed value for the commutation between the “sensorless frequency control” (SFC) at low speed and the HES sensor feedback over the threshold value. The drive torque control mode is not concerned.

When this parameter value is set at 0, the SFC operation at low speed is disabled. In this case, the speed loop is switched off when the motor is at standstill (motor shaft is free), and the HES sensor feedback is operating as soon as the motor is moving.

Sub Index	4
Description	Motor current at standstill
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	per thousand of rated current (0x6075)
Range	100 to 800
Default Value	300 (30% of rated current value)
Remark	When 0x313D, 3 is set at 0, this parameter has no effect.

This parameter defines the motor current value at standstill when the delay for the current changing (0x313D,5) is over.

Sub Index	5
Description	Delay for the current changing at standstill
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	ms
Range	0 to 16000
Default Value	4000 (4 seconds)
Remark	When 0x313D,3 is set to 0, this parameter has no effect.

This parameter defines the delay before the motor current changing (0x313D,4) when the motor is at standstill.

Sub Index	6
Description	Motor HES error threshold
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	rpm
Default Value	0
Remark	The HES error control is operating when “HES only” feedback sensor is selected. The HES error control is not operating in Torque mode. If the value of this parameter is set to 0 the HES error control is not operating.

This object defines the tolerance for the HES error control:

If $|\text{Speed Reference} - \text{Motor Speed}| > \text{Motor HES error threshold} \rightarrow$ HES counting error is released.

Sub Index	7
Description	Motor current in movement
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	per thousand of rated current (0x6075)
Range	100 to 800
Default Value	800 (80 % of rated current value)
Remark	When 0x313D,3 is set at 0, this parameter has no effect.

This parameter defines the motor current value in movement.

3.2.2.7.5 – Sensorless control

Sensorless Parameters

Index	Sub	Name	Description	Type	Attribute
0x3150		Sls_Mon	Sensorless monitoring		
	1	EmfVel	Scaled motor Emf amplitude 0x7FFF → max motor speed (0x6080)	Integer16	ro
	2	EmfErr	Scaled motor Emf error VelRef (0x30F8,1) – EmfVel (0x3150,1) 0x7FFF → max motor speed (0x6080)	Integer16	ro
0x3151		Sls_Setp	Sensorless vector control setup		
	1	Sls_Type	Sensorless Type	Integer16	rw
	2	Sls_Cfg	Sensorless Configuration	Integer16	rw
	3	Sls_NP	Motor pole pairs	Integer16	rw
	4	Sls_Te	Motor electrical time constant	Integer16	rw
	5	Sls_Rm	Motor phase-phase resistance	Integer32	rw
	6	Sls_Ke	Motor emf constant	Integer32	rw
	7	Sls_Ldq	Motor inductance variation ratio	Integer16	rw
	8	SlsSpLim	Motor low speed threshold	Integer16	rw
0x3152		EmfErWin	Motor Emf error threshold (rpm)	Integer16	rw
0x3154		Sls_Adjt	Sensorless frequency control adjust		
	1	Sls_Ired	Motor current reduction at standstill	Integer16	rw
	2	Sls_Tred	Delay for the current reduction at standstill	Integer16	rw
0x315A	0	Sls_spd	Sensorless Velocity (user velocity unit)	Integer32	ro
0x315B	0	Sls_Mod	Sensorless raw position	Integer16	ro

Sensorless vector control (SVC) setup

Index	0x3151
Name	Sensorless vector control setup
Object Code	RECORD
Number of Elements	13

Value Description

Sub Index	1
Description	Sensorless Type
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	

Bit Number	Description
0	1 Enabled 0 Disabled

Sub Index	2
Description	Sensorless Configuration
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	

Bit Number	Description
0	0 Normal direction 1 Reverse direction

Sub Index	3
Description	Motor pole pairs
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	Value of object 0x3410-1

Sub Index	4
Description	Motor electrical time constant
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	0.001 ms
Conversion	1000 x Te (ms)
Default Value	931 (0.931 ms)

Sub Index	5
Description	Motor phase-phase resistance
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	0.001 Ohms
Conversion	1000 x R (Ohms)
Default Value	5800 (0.58 Ohms)

Sub Index	6
Description	Motor emf constant
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	0.01 Vrms / Krpm
Conversion	100 x Vrms phase-phase for 1000 rpm
Default Value	2900 (29 Vrms / Krpm)

Sub Index	7
Description	Motor inductance variation ratio
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	0.1%
Conversion	1000 (Lq – Ld) / Ld
Default Value	0 (Lq = Ld)

Sub Index	8
Description	Motor low speed threshold
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	rpm
Default Value	1300 rpm

Sub Index	9 to 13
Description	Reserved
PDO Mapping	No

Index	0x3152
Name	Motor Emf error threshold
Object Code	VAR
Data Type	Unsigned16
Object Class	pv pp ip hm sq
Access	rw
PDO Mapping	Yes
Unit	rpm
Default Value	0
Remark	The Emf error control is operating only when sensorless control is selected. If the value of this parameter is set at 0, the Emf error control is not operating.

This object defines the tolerance for the scaled Emf error control:
If |Speed Reference – Scaled motor Emf| > Motor Emf error threshold → sensorless error is released

The motor Emf scaling depends on the Motor emf constant parameter (0x3151,6)
The motor Emf error value is displayed in the object 0x3150,2

Sensorless frequency control (SFC) adjust

Index	0x3154
Name	Sensorless frequency control adjust
Object Code	RECORD
Number of Elements	6

Value Description

Sub Index	1
Description	Motor current at standstill
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	per thousand of rated current (0x6075)
Range	100 to 800
Default Value	300 (30 % of rated current value)
Remark	

This parameter defines the motor current value at standstill when the delay for the current reduction (0x3154,2) is over.

Sub Index	2
Description	Delay for the current changing at standstill
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	ms
Range	0 to 16000
Default Value	4000 (4 seconds)
Remark	

This parameter defines the delay before the motor current changing (0x3154,1) when the motor is at standstill.

Sub Index	3
Description	Motor current in movement
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	per thousand of rated current (0x6075)
Range	100 to 800
Default Value	800 (80% of rated current value)
Remark	

This parameter defines the motor current value in movement.

Sub Index	4 to 6
Description	Reserved
PDO Mapping	No

3.2.2.8 - Factor and units

Factor and Units

The position unit is defined by object 0x6093

The velocity unit is defined by position unit per second.

The acceleration unit is defined by position unit per square second.

Index	Object	Name	Type	Attr.
0x608F	ARRAY	Encoder Position Resolution	Unsigned32	rw
0x6093	ARRAY	Position Factor	Unsigned32	rw
0x3089	VAR	Position Display Factor	Unsigned16	rw
0x308A	VAR	Position Unit Name	String	rw

Index	0x608F
Name	Encoder Position Resolution
Object Code	ARRAY
Number of Elements	2

Value Description

Sub Index	1
Description	Encoder Increments
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	inc
Value Range	
Default Value	0x1000

This parameter defines the encoder position resolution for one motor revolution.

Sub Index	2
Description	Motor Revolutions
Data Type	Unsigned32
Access	ro
PDO Mapping	No
Default Value	1

Position Factor

Index	0x6093
Name	Position Factor
Object Code	ARRAY
Number of Elements	2

Value Description

Sub Index	1
Description	Position Factor Numerator
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Default Value	4096

Sub Index	2
Description	Position Factor Denominator
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Default Value	4096

The Denominator defines the increments in user unit for one motor revolution.

The Numerator defines the increments in motor unit for one motor revolution. This value must be set at 4096.

$$\text{Motor_position} = \text{Numerator} / \text{Denominator} * \text{User_position}$$

Example:

1 motor revolution corresponds to a displacement of 5 mm on the load.

The desired user resolution is in μm .

Setting parameters:


Numerator = 4096

Denominator = 5000

User unit = μm

3.2.2.9 - Servo Loops

SERVO CONTROLLER STRUCTURE



Speed loop gains are the most critical to adjust because they greatly depend on the mechanical load characteristics (inertias, frictions, coupling stiffness, resonances,...).

- **Proportional speed gain (KPv):** defines the proportional gain of the controller which acts on the speed error. The higher this parameter value, the faster the speed loop response.
- **Integral speed gain (Klv):** defines the integral gain of the controller which acts on the speed error. The higher this parameter value, the better the axis stiffness.
- **Integrator low frequency limit (Klvf in Hz):** defines the low frequency value from where the controller integrator term is saturated. This parameter is used for reducing the motor heating in applications with large dry frictions due to the mechanical load.
- **Damping gain (KCv):** defines the proportional gain of the controller which acts only on the speed feedback. This parameter allows reducing the speed loop overshoot in response to a step like set point change.
- **Derivative speed gain (KDv):** defines the derivative gain of the controller which acts only on the speed feedback.
- **Derivator high frequency limit (KDvf in Hz):** defines the high frequency value from which the controller derivative term is saturated.
- **Gain scaling factor (KJv):** defines a multiplying factor for all speed regulator gains except the derivative gain KDv. This parameter is scaling the speed regulator gains in order to avoid any saturation when large values are required. This parameter also allows adjusting the servo loop stability in case of load inertia variations.

The **Current command filter** is a 3rd order, low-pass type filter, with 3 adjustable cut-off frequencies. Each cut-off frequency value can be freely adjusted according to the application, for the filtering of high frequency noise or of mechanical resonances.

The **Speed measurement filter** is a 1st order, low-pass type filter, with 3 selectable time constant values. The higher the time constant value, the lower the speed measurement noise, but also the lower the speed loop gains because of the increased speed measurement delay. The **Speed measurement filter** time constant is selected according to the motor position sensor resolution and the acceptable noise level in the speed measurement.

Position loop gains mainly influence the servo motor behavior during the displacements (following error, position overshoot, audible noise, ...).

- **Proportional position gain (KPp)**: defines the proportional gain of the controller which acts on the position error. The higher this parameter value, the better the axis stiffness and the lower the following error.

- **Position loop Error low pass filter (PosErrLF)**: defines the low pass filter which acts on the position loop error. This filter is useful for application with low resolution position sensor (HES only) in order to reduce the motor position flickering at standstill.

- **Feedforward speed 1 gain (KFp)**: defines the feedforward speed amplitude corresponding to the speed input command. This term allows reducing the following error during the motor displacement. Its value is set at the maximum (65536) after the auto-tuning procedure, if a following error as small as possible is required.

- **Feedforward speed 2 gain (KBv)**: defines the feedforward speed amplitude corresponding to the viscous frictions. This term allows reducing the viscous friction effect during the motor displacement. The gain value is equal to the damping gain value + the viscous friction compensation term. After the auto-tuning procedure, the feedforward speed 2 gain is set equal to the damping gain value, if a following error as small as possible is required. The viscous friction compensation term can be calculated by measuring the current/speed ratio at various motor speed values.

- **Feedforward acceleration gain (KA_v)**: defines the feedforward acceleration amplitude corresponding to the acceleration input command. This term allows reducing the following error during the motor acceleration and deceleration phases. Its value is calculated by the amplifier during the auto-tuning procedure, if a following error as small as possible is required.

When the **auto-tuning** procedure is executed, the motor + mechanical load specifications are identified and the appropriate gain values are calculated according to the user selected requirements (controller type, filter type, bandwidth value, ...). All gain values can then be manually modified by the user, if required.

The choice of the time interval for speed measurement (speed measurement filter) allows selecting the speed measurement resolution value according to the position sensor resolution value:

$$\text{speed resolution (rpm)} = 60000 / \text{position sensor resolution (ppr)} / \text{time interval (ms)}.$$

The higher the time interval value, the better the resolution, but also the lower the servo loop gains because of the increased speed measurement delay.

The choice of the anti-resonance filter is necessary in case of loud noise in the motor due to the motor/load coupling elasticity.

The choice of the maximum stiffness filter allows getting the maximum stiffness on the motor shaft with regard to the torque disturbances. However, this choice is only possible without any resonance due to the motor/load coupling elasticity.

The choice of the speed loop bandwidth defines the cut-off frequency value of the closed loop frequency response (Low = 50 Hz, Medium = 75 Hz, High = 100 Hz).

The choice "**minimum following error**" allows getting an accurate following of the position reference value during the whole motor displacement. In this case, all feedforward gain values are calculated.

The choice “**minimum position overshoot**” allows getting a motor positioning without any overshoot of the target position. In this case, all feedforward gain values are set at 0, and the motor position is lagging with regard to the position reference value during the whole motor displacement.

Index	Object	Name	Type	Attr.
0x60FB	RECORD	Position Loop Gain		
0x6062	VAR	Position Demand Value	Integer32	ro
0x60F4	VAR	Following Error Actual Value	Integer32	ro
0x6063	VAR	Actual position*	Integer32	ro
0x6064	VAR	Actual position	Integer32	ro
0x6065	VAR	Following Error Window	Integer32	rw
0x3065	VAR	Following Error Control	Unsigned16	rw
0x31FF	RECORD	External Feedforward		rw
0x60F9	RECORD	Speed Loop Parameters		
0x30F9	ARRAY	Speed Error Low-pass Filter	Unsigned16	rw
0x30FA	VAR	Speed measurement filter	Unsigned16	rw
0x606C	VAR	Actual Velocity	Integer32	ro
0x306C	VAR	Actual Velocity Filter	Unsigned16	rw
0x60F6	RECORD	Current Loop Parameters		
0x60B2	VAR	Current Offset	Integer16	rw
0x6078	VAR	Actual Current	Integer16	ro
0x3078	VAR	Actual Current Filter	Unsigned16	rw

Velocity Control Parameter Set

This object defines the parameters of the speed loop.

Index	0x60F9
Name	Velocity Control Parameter Set
Object Code	RECORD
Number of Elements	8

Value Description

Sub Index	1
Description	Regulator Type
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Value Range	0..65535
Default Value	0

Sub Index	2
Description	Proportional Speed Gain (K _{Pv})
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Value Range	0..65535
Default Value	

Sub Index	3
Description	Integral Speed Gain (Klv)
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	

Sub Index	4
Description	Integral Gain Filter
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Unit	0.1 Hz
Default Value	

Sub Index	5
Description	Damping Gain (KCv)
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	

Sub Index	6
Description	Derivative Gain (KDv)
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	

Sub Index	7
Description	Derivative Gain Filter
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Unit	Hz
Default Value	

Sub Index	8
Description	Gain scaling factor (KJv)
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	Yes
Value Range	0.. 65535
Default Value	

Speed Error Low-pass Filter

Index	0x30F9
Name	Speed Loop Low-pass filter Defines the cut-off frequency at -3 dB (Fev) of the first order filter that acts upon the current control. The value of this parameter is depending on the selected bandwidth.
Object Code	ARRAY
Number of Elements	3

Value Description

Sub Index	1
Description	Speed Loop Low-pass filter 1
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Unit	Hz
Value Range	20..1000 Hz 0 not active
Default Value	

Sub Index	2
Description	Speed Loop Low-pass filter 2
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Unit	Hz
Value Range	20..1000 Hz 0 not active
Default Value	

Sub Index	3
Description	Speed Loop Low-pass filter 3
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Unit	Hz
Value Range	20..1000Hz 0 not active
Default Value	

Index	0x30FA
Name	Velocity measurement filter
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Value Range	0 0.5ms 1 1ms 2 2ms

Index	0x606C
Name	Velocity Actual Value
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	User Velocity Unit

The "Velocity Actual Value" gives the value of the actual motor velocity in user unit. This signal is filtered by a low-pass filter defined by 0x306C.

Object 0x3069 gives the same Actual Velocity but in rpm unit.

Object 0x30F8-2 gives the actual velocity without the low-pass filter.

Index	0x306C
Name	Actual Velocity Filter
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Unit	0.1Hz
Value Range	
Default Value	800 (80Hz)

The filter is applied on "Velocity Actual Value" (0x606C,0)

Actual Velocity without this filtering: "Velocity Feedback" (0x30F8,2)

Index	0x306D
Name	Speed Following Error
Object Code	VAR
Data Type	Unsigned32
Object Class	pv pp ip hm sq sm se gb cm
Access	rw
PDO Mapping	Yes
Unit	inc/s
Value Range	0..0xFFFFFFFF
Default Value	0xFFFFFFFF

This object defines the tolerance for the speed error value:

$$| \text{Speed Demand} - \text{Actual Speed} | < \text{Speed Following Error}$$

If the value of the parameter is FFFF FFFFh, the speed following error control is not operating.

Position Control Parameter Set

Index	0x60FB
Name	Position loop Parameter Set
Object Code	RECORD
Number of Elements	9

Value Description

Sub Index	1
Description	Regulator Type
Data Type	Unsigned16
Object Class	pp ip hm eg
Access	rw
PDO Mapping	No
Default Value	0

Sub Index	2
Description	Position loop Proportional Gain (K _{Pp}) Defines the proportional gain that acts upon the position loop error.
Data Type	Unsigned16
Object Class	pp ip hm eg
Access	rw
PDO Mapping	No
Value Range	0..65535
Default Value	0

Sub Index	3
Description	Feedforward Speed 1 Gain (K _{Fp}) Defines the feedforward term amplitude corresponding to the speed input command (derivation of the position loop input command). This feedforward term allows to reduce the following error during the motor acceleration and deceleration phases.
Data Type	Unsigned16
Object Class	pp ip hm eg
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	0

Sub Index	4
Description	Feedforward Acceleration Gain (K _{Av}) Defines the feedforward acceleration corresponding to the acceleration input command (second derivation of the position loop input command). This feedforward term allows to reduce the following error during the motor acceleration and deceleration phases.
Data Type	Unsigned16
Object Class	pp ip hm eg
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	0

Sub Index	5
Description	Feedforward Speed 2 Gain (KBv) This gain value is equal to the damping speed gain value + Feedforward friction gain value. The feedforward friction gain allows to cancel the load viscous friction effect (load viscous friction torque is proportional to axis speed). This feedforward term allows to reduce the following error during the motor acceleration and deceleration phases.
Data Type	Unsigned16
Object Class	pp ip hm eg
Access	rw
PDO Mapping	No
Value Range	0.. 65535
Default Value	0

Sub Index	6
Description	reserved
Default Value	0

Sub Index	7
Description	reserved
Default Value	0xFFFFFFFF

Sub Index	8
Description	reserved
Default Value	0

Sub Index	9
Description	Position loop Error low pass filter (PosErrLF) Defines the low pass filter that acts upon the position loop error.
Data Type	Unsigned16
Object Class	pp ip hm pv eg
Access	rw
PDO Mapping	No
Unit	0.1 Hz
Default Value	0

Index	0x6062
Name	Position Demand Value
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	position unit
Default Value	-

This object gives the internal position value in entry of position loop.

Index	0x60F4
Name	Following Error Actual Value
Object Code	VAR
Data Type	Integer32
Object Class	pp ip hm sq sm se gb cm
Access	rw
PDO Mapping	Yes
Unit	User position unit
Default Value	-

This object gives the difference between position demand value and position actual value:
 $\text{FollowingErrorActualValue} = \text{PosDemand} - \text{PosActual}$

Index	0x6064
Name	Actual Position
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	position unit
Default Value	-

This object gives the actual axis position. If the position sensor is resolver, then the value is resolver position (0x3109,0). If the position sensor is encoder, then the value is encoder position (0x3129,0). The sensor position is defined by object 0x306A,0.

Index	0x6065
Name	Following Error Window
Object Code	VAR
Data Type	Unsigned32
Object Class	pp ip hm sq sm se gb cm
Access	rw
PDO Mapping	Yes
Unit	position unit
Value Range	0..0xFFFFFFFF
Default Value	-

This object defines the tolerance for position value:
 $|\text{PosDemand} - \text{PosActual}| < \text{FollowingErrorWindow}$

If the value of the following error window is FFFF FFFFh, the following control shall be switched off.

Index	0x3065
Name	Following Error Control This object defines the position error detection mode
Object Code	VAR
Data Type	Unsigned16
Object Class	pp ip hm sq sm se gb cm
Access	rw
PDO Mapping	No
Value Range	Position error detection mode: 0 Absolute value 1 Relative To dynamic model
Default Value	0

Index	0x3067
Description	Position Deadband window
Data Type	Unsigned32
Object Class	pp ip hm
Access	rw
Unit	User unit
PDO Mapping	No
Default Value	0 (Position Deadband window is disabled)

When the motor is stopped, if the actual position error is within the “Position Deadband Window”, the position loop is opened.

External Feedforward

Index	0x31FF
Name	External Feedforward
Object Code	RECORD
Object Class	pp, ip, hm sq, se, gb
Number of Elements	3

Value Description

Sub Index	1
Description	External Feedforward Selection
Data Type	Unsigned16
Access	rw
PDO Mapping	Yes
Default Value	0

Bit Number	Function
0	reserved
1	Select Feedforward Speed 0 Internal feedforward speed 1 External feedforward speed
2	Select Feedforward Acceleration 0 Internal feedforward acceleration 1 External feedforward acceleration
3..15	reserved

Sub Index	2
Description	External Feedforward Speed
Data Type	Integer32
Access	rw
PDO Mapping	Yes
Unit	Velocity unit: User inc / s
Default Value	0

Sub Index	3
Description	External Feedforward Acceleration
Data Type	Integer32
Access	rw
PDO Mapping	Yes
Unit	Acceleration unit: User inc / s ²
Default Value	0

3.2.2.10 - Auto-tuning / Gains calculation

Auto-tuning / Gains calculation Parameters

Index	0x3425
Name	Auto-tuning / Gains calculation parameters
Object Code	ARRAY
Number of Elements	4

Value Description

All these parameters must be set before starting the auto-tuning or gains calculation procedure by 0x3426.

Sub Index	1
Description	Auto-tuning Bandwidth
Data Type	Unsigned16
Object Class	-
Access	rw
PDO Mapping	No
Value Range	0..2
Default Value	

This parameter defines the auto-tuning bandwidth:

Value	Bandwidth
0	Low Bandwidth
1	Medium Bandwidth
2	High Bandwidth

Sub Index	2
Description	Filter type
Data Type	Unsigned16
Object Class	-
Access	rw
PDO Mapping	No
Value Range	0..2
Default Value	

This parameter defines the auto-tuning filter:

Value	Filter
0	Standard filter
1	Anti-resonance filter
2	High stiffness filter

Sub Index	3
Description	Speed Filter
Data Type	Unsigned16
Object Class	-
Access	rw
PDO Mapping	No
Value Range	0..2
Default Value	

This parameter defines the speed filter:

Value	Filter
0	auto-select by auto-tuning
1	0.5 ms
2	1 ms
3	2 ms

Sub Index	4
Description	Auto-tuning Application Requirements
Data Type	Unsigned16
Object Class	-
Access	rw
PDO Mapping	No
Value Range	0..1
Default Value	

Value	Application Requirements
0	Minimum tracking error
1	Minimum overshoot

For the Gains calculation procedure the system parameter must also be set before starting the gains calculation procedure by 0x3426:

- Motor torque constant (0x6410 sub 11).
- Motor Inertia (0x6410 sub 12).
- Load inertia reflected to the motor shaft (0x3437).

Index	0x3437
Name	Load Inertia reflected to the motor shaft
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	0.001gm ²
Remark	Used when the Gains calculation procedure is executed. See object 0x3426 with signature = 0x636C6163 (calc)

Auto-tuning / Gains calculation Procedure

Index	0x3426
Name	Start Auto-tuning / Gains calculation procedure
Object Code	
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Remark	When using a low resolution position sensor (HES only), or when the motor is operating in sensorless control, auto-tuning is not supported. Only the gains calculation procedure can be executed.

Parameters for Auto-tuning / Gains calculation (0x3425) must be previously set.
For Gains calculation procedure system parameters (0x6410 and 0x3437) must also be set.

In order to avoid running the procedure by mistake, it is only executed when a specific signature is written to this sub-index.

- The signature 'calc' (0x636C6163) concern the servo loop gains calculation procedure.
- The signature 'atun' (0x6E757461) concern the motor auto-tuning procedure.

Writing 0 to this object when auto-tuning is running will abort the procedure.

When reading, this object returns the operation status:

Read Value	Meaning
0	Procedure never executed
1	Cannot execute
2	Procedure running
3	Procedure aborted by user
4	Procedure stopped on error
>= 5	Procedure done

When running, the BUSY bit of status word (0x6041) is set.

Remark:

- The parameters calculated by the auto-tuning depend on which mode it is executed (for example, if auto-tuning is executed in Profile Velocity Mode, the position loop gain will be equal to 0).
- When using a low resolution position sensor (HES only), or when the motor is operating in sensorless control, Medium Bandwidth and Anti-resonance filter are automatically selected regardless the 0x3425 parameters selection.

3.2.2.11 - Save / Load parameters

Internal Load/Save Command

The **Xtrapuls** servo drive can store parameters in its internal flash memory:

Writing to object 0x1010 initiates the saving procedure which stores the drive parameters in its internal flash memory (inside a file called DRIVEPAR.TXT).

Writing to object 0x1011 initiates the restoring procedure which re-loads the drive parameters from its internal flash memory (from the previously saved DRIVEPAR.TXT file).

Store parameters

Index	0x1010
Name	Store parameters
Object Code	RECORD
Number of Elements	

This command saves the drive parameters in a volatile memory (ram), in a file located in an internal flash memory.

Value Description

Sub Index	1
Description	Save all parameter
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Value	writing signature: 0x65766173 save drive parameters

Signature for various operations:

Operation	Signature	Ascii
Saving of the manufacturer's parameters	0x6E616D73	"sman"
Saving of the calibration saves drive calibration parameters into flash memory.	0x6C616373	"scal"
Saving of the drive parameters saves drive parameters into flash memory (DRIVEPAR.TXT file).	0x65766173	"save"
Saving of the sequence saves sequences from sequence memory into flash memory (SEQUENCE.TXT file).	0x71657373	"sseq"

While operation is running, busy bit in status word (0x6041) is set.

If the Hiperface® encoder is selected when saving drive parameters, the encoder reference (0x312D,5 and 0x3125,6) and homing offset (0x3128,0) are also stored into the Hiperface® encoder non-volatile memory.

Restore parameters

Index	0x1011
Name	Restore parameters
Object Code	RECORD
Number of Elements	

Value Description

Sub Index	1
Description	Load all parameters
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Value	writing signature: 0x64616F6C load drive parameters

Signature for various operations:

Operation	Signature	Ascii
Loading of the manufacturer's parameters	0x6E616D6C	"lman"
Loading of the calibration parameters	0x6C61636C	"lcal"
Loading of the drive parameters (DRIVEPAR.TXT)	0x64616F6C	"load"
Loading of the USER_PAR.TXT file loads parameters from USER_PAR.TXT file into memory.	0x7273756C	"lusr"
Loading of the SEQUENCE.TXT file loads parameters from SEQUENCE.TXT file into sequence memory	0x7165736C	"lseq"
Merging of the SEQUENCE.TXT file merges parameters from SEQUENCE.TXT file into sequence memory	0x7165736D	"mseq"

While operation is running, busy bit in status word (0x6041) is set.

If the Hiperface® encoder is selected when loading drive parameters, the encoder reference (0x312D,5 and 0x3125,6) and homing offset (0x3128,0) are also loaded from the Hiperface® Encoder non volatile memory. After a reset of the Hiperface® error, these objects are also reloaded.

3.2.3 - Operation Modes

3.2.3.1 - Supported Drive Modes

Supported Drive Modes

A drive can support more than one and several distinct modes of operation. This object gives an overview of the implemented operating modes in the XtrapulsEasy device. This object is read only.

Index	0x6502
Name	Supported drive modes
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	ro
PDO Mapping	No
Value	See below

Data Description

Bit Number	Function	Class	OpCode	Servo Loops	Supported
0	Profile Position Mode	pp	1	position, speed and current loops	Yes
1	Velocity Mode	vm	2		No
2	Profile Velocity Mode	pv	3	speed and current loops	Yes
3	Profile Torque Mode	pt	4	current loop	Yes
4	Reserved				
5	Homing Mode	hm	6	position, speed and current loops	Yes
6	Interpolated Position Mode	ip	7	position, speed and current loops	Yes
7	Cyclic Synchronous Position	csp	8	position, speed and current loops	No
8	Cyclic Synchronous Velocity	csv	9	speed and current loops	No
9	Cyclic Synchronous Torque	cst	10	current loop	No
7..15	Reserved				
16	Analog Speed Mode	as	-1	speed and current loops	Yes
17	Stepper Emulation Mode	se	-2	position, speed and current loops	No
18	Sequence Mode	sq	-3	position, speed and current loops	Yes
19	Reserved				
20	Analog Torque Mode	at	-5	current loop	Yes
21	Master-Slave Gearbox Mode	gb	-6	position, speed and current loops	No
22	Master-Slave Cam Mode	cm	-7	position, speed and current loops	No

3.2.3.2 - Mode selection

Index	0x6060
Name	Mode of Operation
Object Code	VAR
Data Type	integer8
Object Class	all
Access	rw
Save	Yes
PDO Mapping	Yes

This parameter changes the operation mode of the drive.

Mode of Operation	Action
1	Profile Position Mode (PP)
3	Profile Velocity Mode (PV)
4	Profile Torque Mode (PT) Not operating in sensorless control
6	Homing Mode (HM)
7	Interpolated Position Mode (IP)
-1	Analog Speed Mode (AS)
-2	Stepper Emulation Mode (SE) Not supported by the XtrapulsEasy drive
-3	Sequence Mode (SQ)
-4	Reserved
-5	Analog Torque Mode (AT) Not operating in sensorless control
-6	Master-Slave Gearbox Mode (GB) Not supported by the XtrapulsEasy drive
-7	Master-Slave Cam Mode (CM) Not supported by the XtrapulsEasy drive


The actual mode is reflected in the operation mode display (object 0x6061).

Index	0x6061
Name	Mode of Operation Display
Object Code	VAR
Data Type	integer8
Object Class	all
Access	ro
PDO Mapping	Yes
Default Value	-

3.2.3.3 - Profile Position Mode

Profile Position Mode

In this mode, a trapezoidal trajectory generator gives the drive the possibility to execute a positioning with preset parameters as target position, profile speed and acceleration.



In profile position mode, these bits in the control word are relative to the control of the trajectory:


Bit Number	Profile Position Mode
4	new set point
5	change set immediately
6	0: absolute 1: relative

The movement will be triggered by a rising edge of bit 4 (new_set_point) of the control word. The acknowledgement of the new set point is confirmed by bit 12 (setpoint acknowledgement) of the status word. The target position will be taken as relative to the current position if bit 6 of control word = 1.


The speed profile is trapezoidal (motion profile type = 0) or S-curve (motion profile type = -1).

Change setpoint immediately

Bit change_set_immediately = 1 :



Bit change_set_immediately = 0 :



Object Dictionary Entries

Index	Object	Name	Type	Attr.
0x607A	VAR	Target Position	Integer32	rw
0x6080	VAR	Max Motor Speed	Unsigned32	rw
0x6081	VAR	Profile Velocity	Unsigned32	rw
0x6082	VAR	End Velocity	Unsigned32	rw
0x6083	VAR	Profile Acceleration	Unsigned32	rw
0x6084	VAR	Profile Deceleration	Unsigned32	rw
0x6086	VAR	Motion Profile Type	Integer16	rw
0x6067	VAR	Position Window	Unsigned32	rw
0x6068	VAR	Position Window Time	Unsigned16	rw
0x607F	VAR	Max Profile Velocity	Unsigned32	rw
0x3081	VAR	Speed Modulation Source	Unsigned32	rw

Index	0x607A
Name	Target Position
Object Code	VAR
Data Type	Integer32
Object Class	pp
Access	rw
PDO Mapping	Yes
Unit	User Position Unit
Value Range	$(-2^{31})..(2^{31}-1)$
Default Value	0

Target position is the final position where the motor will move to in profile position mode. The start position is the current position. The positioning begins with rising edge of bit 4 of the control word (new set point). Bit 6 of control word indicates if the target position is absolute (=0) or relative (=1) movement.

Index	0x6080
Name	Max Motor Speed
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	No
Unit	rpm
Value Range	100...60000
Default Value	3000

The *Max. motor speed* defines the maximum speed the drive can reach. To avoid a saturation of the servo loop, the running speed must be less than *Max. motor speed* (depends on the overshoot accepted for the servo loop response).

This parameter modifies the value of the Max Profile Velocity 0x607F.

Index	0x6081
Name	Profile Velocity
Object Code	VAR
Data Type	Unsigned32
Object Class	pp
Access	rw
PDO Mapping	Possible
Unit	User Velocity Unit
Value Range	-
Default Value	0x1000

The *Profile Velocity* is the running velocity for a positioning. If the positioning is too short, the profile velocity may not be reached.

Index	0x6082
Name	End Velocity
Object Code	VAR
Data Type	Unsigned32
Object Class	pp
Access	rw
PDO Mapping	Possible
Unit	User Velocity Unit
Value Range	-
Default Value	0


The *End Velocity* is the final velocity value when the target position is reached. When the motor has to stop at the target position, *End Velocity*=0.

Index	0x6083
Name	Profile Acceleration
Object Code	VAR
Data Type	Unsigned32
Object Class	pp
Access	rw
PDO Mapping	No
Unit	User acceleration unit
Value Range	-
Default Value	0x10000

Index	0x6084
Name	Profile Deceleration
Object Code	VAR
Data Type	Unsigned32
Object Class	pp
Access	rw
PDO Mapping	No
Unit	User acceleration unit
Value Range	-
Default Value	0x10000

Index	0x6086
Name	Motion Profile Type
Object Code	VAR
Data Type	Integer16
Object Class	pp, sm
Access	rw
PDO Mapping	No
Value Range	0 -> Trapezoidal profile -1 -> S-Curve
Default Value	0

The S-curve is defined by a polynomial. The acceleration profile is therefore parabolic.



Index	0x6067
Name	Position Window
Object Code	VAR
Data Type	Unsigned32
Object Class	pp
Access	rw
PDO Mapping	No
Unit	User Position Unit
Default Value	0

The *Position Window* defines a symmetrical range of accepted positions relatively to the target position. If the motor current position is within the position window, this target position is considered as reached (bit 10 or status word - Target Reached – is set). If the position window value is 0, the position window control is not active.

When the actual position is within the *Position Window* during the defined *Position Window Time*, the corresponding bit 10 *Target reached* in the *StatusWord* will be set at 1.

Index	0x6068
Name	Position Window Time
Object Code	VAR
Data Type	Unsigned16
Object Class	pp
Access	rw
PDO Mapping	Possible
Unit	Milliseconds
Value Range	0...32767
Default Value	0

Index	0x607F
Name	Max Profile Velocity
Object Code	VAR
Data Type	Unsigned32
Object Class	pv, pp, sm
Access	rw
PDO Mapping	Yes
Unit	User Velocity Unit
Value Range	0...(2 ³² - 1)
Default Value	0

The **Max. Profile Velocity** is the maximum speed allowed in any direction during a profiled move.

This parameter limits the input velocity reference in:

- profile position mode (0x6081),
- profile velocity mode (0x60FF),
- profile position function block and profile velocity function block in servo mode.

Position Profile Speed Modulation Input Source

Index	0x3081
Name	Position Profile Speed Modulation Input Source
Description	Index/sub-index of input data
Data Type	Unsigned32
Object Class	sm, pp, sq
Access	rw
PDO Mapping	No
Default Value	0
Value	See below

This object allows connecting any dataflow as a speed modulation of the Profile generator in Profile Position Mode or Profile Generator Function Block in Servo Mode or Sequence Mode.

The structure of the entries is the following:

MSB	LSB
Index (16-bit)	Sub-index (8-bit) 0

The modulation value is between 0 and 0x7FFF. A modulation value of 0x7FFF means 100 % of the programmed velocity.

If the input source value is negative, then the modulation value is the absolute value.

Example:

0x3081,0 = 0x30830000
 connects 0x3083 as the modulation speed for Profiles Position.

Position Profile Speed Modulation Configuration

Index	0x3082								
Name	Position Profile Speed Modulation Configuration								
Description	This object allows defining the effect of the Position Profile Speed Modulation signal.								
Data Type	Unsigned16								
Object Class	all								
Access	rw								
PDO Mapping	No								
Default Value	0								
Value	<table border="0"> <thead> <tr> <th>bit</th> <th>description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0 normal effect of the Position Profile Speed Modulation signal: 0 -> speed is limited at 0 0x7FFF -> 100 % of programmed speed.</td> </tr> <tr> <td>1</td> <td>reverse effect of the Position Profile Speed Modulation signal 0x7FFF -> speed is limited at 0 0 -> 100 % of programmed speed.</td> </tr> <tr> <td>1..15</td> <td>reserved</td> </tr> </tbody> </table>	bit	description	0	0 normal effect of the Position Profile Speed Modulation signal: 0 -> speed is limited at 0 0x7FFF -> 100 % of programmed speed.	1	reverse effect of the Position Profile Speed Modulation signal 0x7FFF -> speed is limited at 0 0 -> 100 % of programmed speed.	1..15	reserved
bit	description								
0	0 normal effect of the Position Profile Speed Modulation signal: 0 -> speed is limited at 0 0x7FFF -> 100 % of programmed speed.								
1	reverse effect of the Position Profile Speed Modulation signal 0x7FFF -> speed is limited at 0 0 -> 100 % of programmed speed.								
1..15	reserved								

Index	0x3083
Name	Position Profile Speed Modulation
Description	This object can be connected as the dataflow of the Position Profile Speed Modulation Input Source (0x3081)
Data Type	Integer16
Object Class	all
Access	rw
PDO Mapping	Yes
Default Value	0

Axis Type

Index	0x3360
Name	Axis Type
Object Code	VAR
Data Type	Unsigned8
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This parameter defines the axis type: linear or rotating.
A linear axis has its software position limit active.

Value	Function
0	rotating
1	linear

Software Position Range Limit

The Software Position Range Limit defines a Positive Position Limit and a Negative Position Limit, which act as hardware limit switches.

The Software Position Range Limit is activated when Axis Type (0x3360) is linear.

Index	0x607D
Name	Software Position Range Limit
Object Code	ARRAY
Object Class	all
Number of Elements	2

Value Description

Sub Index	1
Description	Negative Position Limit
Data Type	Integer32
Access	rw
PDO Mapping	No
Unit	User position unit
Value	


Sub Index	2
Description	Positive Position Limit
Data Type	Integer32
Access	rw
PDO Mapping	No
Unit	User position unit
Value	

3.2.3.4 - Homing Mode

When the feedback sensor does not give the absolute position, the homing mode is the right way to set up the motor to a known position. This position can be detected by using several signals such as positive or negative limit switch, home switch, index pulse or mechanical limit. The choice of the homing method depends on those signals and on the direction of the starting movement.

The drive generates the trajectory according to the homing method. This is the reason why the position loop of the drive is used.

Graphical representation of the trajectories as a function of the input signals:



Index	Object	Name	Type	Attr.
0x607C	VAR	Home Offset	Integer32	rw
0x6098	VAR	Homing Method	Integer8	rw
0x6099	ARRAY	Homing Speeds	Unsigned32	rw
0x609A	VAR	Homing Acceleration	Unsigned32	rw

Manufacturer Specific Objects:

Index	Object	Name	Type	Attr.
0x309C	VAR	Homing Current Limit	Unsigned16	rw
0x309D	VAR	End On Home Position	Unsigned16	rw
0x3218	VAR	Homing Operation Indicator	Unsigned16	rw

The homing procedure is launched on rising edge of bit 4 of the Control Word and can be interrupted when clear.

Meanings of operation mode specific bits of the Status Word:

Bit 13	Bit 12	Bit 10	Definition
0	0	0	Homing procedure in progress
0	0	1	Homing procedure interrupted or not started
0	1	0	Homing reached, but target is not reached
0	1	1	Homing procedure successfully completed
1	0	0	Homing error occurred, velocity is not 0
1	0	1	Homing error occurred, velocity is 0
1	1	X	reserved

If Bit 10 is set, this indicates that the velocity is 0.

If bit 12 is set, this indicates that the home position is known but not available.

Bit 12 is reset at 0:

- at power-up,
- if a sensor fault occurs,
- on homing error,
- when homing is starting,
- when bit 4 of the Control Word is at 0.

Bit 13 indicates a homing error:

- homing launched whereas the drive is not in "operation enabled" (except for homing method 35);
- homing launched with an unimplemented selected method.

Bit 13 is reset at 0:

- at drive power-up,
- on rising edge of bit 7 of the Control Word.

Homing Offset

The Home Offset defines the position feedback value when the motor reaches the homing position.

Index	0x607C
Name	Home Offset
Object Code	VAR
Data Type	Integer32
Object Class	hm
Access	rw
PDO Mapping	No
Unit	User position unit
Value Range	$(-2^{31})..(2^{31}-1)$
Default Value	0

Homing Method

The *Homing Method* defines various ways of the drive to search the homing position.

Index	0x6098
Name	Homing Method
Object Code	VAR
Data Type	Integer8
Object Class	hm
Access	rw
PDO Mapping	No
Default Value	23h

Value Description


Method supported: 1..14, 17..30, 33..35.

Methods specific: -1, -2, -3, -4.


Method	Search for Switch	Search for Index Pulse	Remarks
1	Negative Limit Switch	Exterior	
2	Positive Limit Switch	Exterior	
3	Positive Home Switch	Exterior	
4	Positive Home Switch	Interior	
5	Negative Home Switch	Exterior	
6	Negative Home Switch	Interior	
7	Home Switch, Negative Side	Exterior	Positive Initial Move. Reverse direction on Positive Limit Switch.
8	Home Switch, Negative Side	Interior	Positive Initial Move. Reverse direction on Positive Limit Switch.
9	Home Switch, Positive Side	Interior	Positive Initial Move. Reverse direction on Positive Limit Switch.
10	Home Switch, Positive Side	Exterior	Positive Initial Move. Reverse direction on Positive Limit Switch.
11	Home Switch, Positive Side	Exterior	Negative Initial Move. Reverse direction on Negative Limit Switch.
12	Home Switch, Positive Side	Interior	Negative Initial Move. Reverse direction on Negative Limit Switch.
13	Home Switch, Negative Side	Interior	Negative Initial Move. Reverse direction on Negative Limit Switch.
14	Home Switch, Negative Side	Exterior	Negative Initial Move. Reverse direction on Negative Limit Switch.
17	Negative Limit Switch	-	
18	Positive Limit Switch	-	
19	Positive Home Switch	-	
20	Positive Home Switch	-	
21	Negative Home Switch	-	
22	Negative Home Switch	-	
23	Home Switch, Negative Side	-	
24	Home Switch, Negative Side	-	
25	Home Switch, Positive Side	-	
26	Home Switch, Positive Side	-	
27	Home Switch, Positive Side	-	
28	Home Switch, Positive Side	-	
29	Home Switch, Negative Side	-	
30	Home Switch, Negative Side	-	
33		First Index Pulse	Negative Initial Move.
34		First Index Pulse	Positive Initial Move.
35		-	Homing On Current Position
-1	Mechanical Limit, Negative Move	First Index Pulse	
-2	Mechanical Limit, Positive Move	First Index Pulse	
-3	Mechanical Limit, Negative Move	-	
-4	Mechanical Limit, Positive Move	-	

According to the table above, each homing method can be detailed using a diagram representing all of the possible trajectories.

The homing Method 8 is taken as an example:



For simplifying diagrams, the trajectory of the switch side search is not explicitly drawn. However, an arrow indicates the direction used to search a switch side. Hence, trajectory 1 of homing method 8 is explained in the following diagram:



The following explanation describes only trajectory 1 of homing method 8 taken above as an example. Using homing method 8, the initial direction of the movement is positive, except if the home switch is active at the motion start. So, the negative side of the home switch is first searched in the positive direction with the Home Switch Speed. When the activation of the home switch is detected, the drive reverses to look for the home switch deactivation. As the home switch has been found, the speed is the slowest home speed, namely the Index Pulse Speed. Once the deactivation of the home switch has been found, the drive reverses to position to look for the Index Pulse. At this stage, depending on the position sensor, the home position will directly be reached, for example a resolver. For sensors like incremental encoders, a search of Index Pulse is achieved in the positive direction and then the drive reverses to position on the captured Index Pulse position.

Homing Speeds

Homing Speeds defines the motor speed when searching the homing position.

Index	0x6099
Name	Homing Speeds
Object Code	ARRAY
Number of Elements	2
Data Type	Unsigned32

Value Description

Sub Index	1
Description	Speed during search of switch
Object Class	hm
Access	rw
PDO Mapping	No
Unit	User velocity unit
Default Value	00000019h

Sub Index	2
Description	Speed during search of zero
Object Class	hm
Access	rw
PDO Mapping	No
Unit	User velocity unit
Default Value	0000000Ah

Homing Acceleration

Index	0x609A
Name	Homing Acceleration
Object Code	VAR
Data Type	Unsigned32
Object Class	hm
Access	rw
PDO Mapping	No
Unit	User acceleration unit
Default Value	00010000h

Homing Current Limit


The "Homing current limit" defines the limit of current during the homing on the mechanical limit. The value is defined as a percent of the drive maximum current (defined by object 6510h sub-index 1).

Index	0x309C
Name	Homing Current Limit
Object Code	VAR
Data Type	Unsigned16
Object Class	hm
Access	rw
PDO Mapping	No
Unit	%
Conversion	0 to 0x3FFF -> 0% to 100 %
Default Value	0x0400


Functional Description

The "Homing Current Limit" parameter defines the limit of current in the motor during the homing procedure. When the mechanical limit is reached, the current in the motor increases up to this limit and the motor speed is 0. This position will be taken as the homing position. An offset value (object 607Ch) can be used to preset the homing position value.

Methods -1 and -2 define the homing on the mechanical limit with index pulse.



Methods -3 and -4 define the homing on the mechanical limit.



End on Home Position

This parameter allows the drive not reversing at the end of the homing. If set at 1, it makes a move towards the home position when the homing is over. If cleared, the home position is found but not moved to.

Index	0x309D
Name	End on Home Position
Object Code	VAR
Data Type	Unsigned16
Object Class	hm
Access	rw
PDO Mapping	No
Default Value	1

Homing Operation Indicator

Index	0x3218
Name	Homing Operation Indicator
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

This object allows keeping the result of a homing operation:

- it is cleared when drive is switched on
- it is set if the position sensor is absolute multi-turn.
- it is set after a successful homing.
- it is cleared if the position sensor is lost (by any fault related to this sensor).
- if a special homing function is implemented in the master, the master needs to set this object after that special homing is complete.

3.2.3.5 - Interpolated Position Mode


Interpolated Position Mode

The interpolated position mode is used to control several axes in coordination. The trajectory must be generated by the host controller and the elementary set point is sent at a fixed cycle time (same as communication cycle time) to all axes.

The cycle time synchronization of all axes is ensured by the SYNC message. The setpoint data flow must be sent in real-time.

The elementary set point could be only position if linear interpolation is chosen. The PV interpolation mode requires position and velocity for each set point. The P3 cubic interpolation mode requires only position set point because the interpolator is using the three last position set points. However, the interpolation error is inherent when the acceleration is changing with the P3 cubic interpolation mode.

Both cubic interpolation modes require high position resolution when operating at low speed values. At very low speed, the linear interpolation mode is giving best results.



The CAN bus Interpolator is running in any mode but the result of the interpolator (0x30C1) is applied to the position loop only in Interpolated Position Mode.

When using the linear interpolation, the feedforward acceleration term (KAv) must be cleared (see interpolation and servo loop). Only a PV or P3 interpolation can fully support a feedforward acceleration term.

Index	Object	Name	Type	Attr.
0x60C0	VAR	Interpolation Submode Select	Integer16	rw
0x60C1	RECORD	Interpolation Data Record		rw
0x30C1	VAR	Interpolated Data Output	Integer32	rw


Interpolation Submode Select

Index	0x60C0
Name	Interpolation Submode Select
Object Code	VAR
Data Type	Integer16
Object Class	ip
Access	rw
PDO Mapping	No
Value Range	see below
Default Value	0

Interpolation Submode Select	Description
0	Linear interpolation
-1	PV interpolation
-2	P3 interpolation

When in linear interpolation mode, only the first parameter of the interpolation data record is used. The data must be the position reference.

When in PV interpolation mode, the first parameter of the interpolation data record must contain the position reference and the second parameter of the interpolation data record contains the velocity reference.



Note: The velocity reference for each set-point must be the instantaneous velocity at this point (not the average velocity).

Interpolation data record

Index	0x60C1
Name	Interpolation data record
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	First parameter of ip function
Data Type	Integer32
Object Class	ip
Access	rw
PDO Mapping	Possible

This sub-index contains the position reference in IP mode.

Sub Index	2
Description	Second parameter of ip function
Data Type	Integer32
Object Class	ip
Access	rw
PDO Mapping	Possible

This sub-index contains the speed reference in IP mode if the interpolation submode select (0x60C0) is -1 (interpolation PV). Otherwise it is not used.

Absolute 16-bit Position Reference for IP mode

Index	0x3350
Name	Absolute 16-bit Position Reference
Object Code	VAR
Data Type	Unsigned8
Object Class	ip
Access	rw
PDO Mapping	No
Value Range	0..1
Default Value	0


The position reference in interpolated position mode can be defined as 16-bits only. This is to reduce the bus traffic.

When in 16-bit mode (object 3350h = 1), the position reference in object 60C1-1 via PDO is set at 16 bits and the drive calculates the upper word. At the beginning, it is necessary to set the upper word with object 60C1-1 via SDO (Integer32). The mapping of RPDO must be changed to object 60C1 sub-index 1 with 16-bit length.

3.2.3.6 - Profile Velocity Mode

Profile Velocity Mode

The profile velocity mode authorizes the drive to operate with a velocity reference. Only speed loop and current loop are closed in this mode.



Index	Object	Name	Type	Attr.
0x606B	VAR	Velocity Demand Value	Integer32	ro
0x606C	VAR	Velocity Actual Value	Integer32	ro
0x306C	VAR	Actual Velocity Filter	Unsigned16	rw
0x3069	VAR	Velocity Actual Value (rpm)	Integer32	ro
0x60FF	VAR	Target Velocity	Integer32	rw
0x6083	VAR	Profile Acceleration	Unsigned32	rw
0x6084	VAR	Profile Deceleration	Unsigned32	rw
0x606D	VAR	Velocity Window	Unsigned16	rw
0x606E	VAR	Velocity Window Time	Unsigned16	rw
0x606F	VAR	Velocity Threshold	Unsigned16	rw
0x6070	VAR	Velocity Threshold Time	Unsigned16	rw
0x30FF	VAR	Target Velocity Source	Unsigned16	rw

Index	0x6083
Name	Profile Acceleration
Object Code	VAR
Data Type	Unsigned32
Object Class	pp
Access	rw
PDO Mapping	No
Unit	User acceleration unit
Value Range	-
Default Value	0x10000

Index	0x6084
Name	Profile Deceleration
Object Code	VAR
Data Type	Unsigned32
Object Class	pp
Access	rw
PDO Mapping	No
Unit	User acceleration unit
Value Range	-
Default Value	0x10000

The **Velocity Window** defines a symmetrical range of accepted velocity relatively to the target velocity. If the motor current velocity is within the velocity window, this target velocity is considered as reached (bit 10 of status word - Target Reached – is set). If the velocity window value is 0, the velocity window control is not active.

Index	0x606D
Name	Velocity Window
Object Code	VAR
Data Type	Unsigned32
Object Class	pv
Access	rw
PDO Mapping	No
Unit	Velocity Unit
Default Value	0

When the actual velocity is within the **Velocity Window** during the defined **Velocity Window Time**, the corresponding bit 10 Target reached in the StatusWord will be set at 1.

Index	0x606E
Name	Velocity Window Time
Object Code	VAR
Data Type	Unsigned16
Object Class	pv
Access	rw
PDO Mapping	Possible
Unit	ms
Value Range	0...32767
Default Value	0

The **Velocity Threshold** defines a symmetrical range of accepted velocity relatively to the 0. If the motor current velocity is within the velocity threshold, this 0 velocity is considered as reached (bit 12 of status word - Velocity = 0 – is set). If the velocity threshold value is 0, the velocity threshold control is not active.

Index	0x606F
Name	Velocity Threshold
Object Code	VAR
Data Type	Unsigned32
Object Class	pv
Access	rw
PDO Mapping	No
Unit	Velocity Unit
Default Value	0

When the actual velocity is within the *Velocity Threshold* during the defined *Velocity Threshold Time*, the corresponding bit 12 *Velocity=0* in the *StatusWord* will be set at 1.

Index	0x6070
Name	Velocity Threshold Time
Object Code	VAR
Data Type	Unsigned16
Object Class	pv
Access	rw
PDO Mapping	Possible
Unit	ms
Value Range	0...32767
Default Value	0

Profile Velocity Mode Input Source

Index	0x30FF
Name	Profile Velocity Mode Input Source for Target Velocity
Description	Index/sub-index of input data
Data Type	Unsigned32
Class	pv
Access	rw
PDO Mapping	No
Value	See below
Default Value	0x60FF0000

This object allows connecting any 32-bit dataflow as target velocity for the Profile Velocity Mode.

The structure of the entries is the following:

MSB			LSB
Index (16-bit)	Sub-index (8-bit)	0	

Example:

0x30FF,0 = 0x30F10200

connects the analog input as the target velocity for Profile Velocity Mode.

3.2.3.7 - Profile Torque Mode

Profile Torque Mode

In this mode, the drive operates only with current loops and there is no speed or position control.

Object Dictionary Entries

Index	Object	Name	Type	Attr.
0x6071	VAR	Target Torque	Integer16	rw
0x3071	VAR	Target Torque Input Source	Unsigned32	rw
0x6087	VAR	Torque Slope	Unsigned32	rw
0x6088	VAR	Torque Profile Type	Integer16	rw
0x60B2	VAR	Offset Torque	Integer16	rw
0x6074	VAR	Torque Demand Value	Integer16	ro
0x6077	VAR	Torque Actual Value	Integer16	ro
0x6078	VAR	Current Actual Value	Integer16	ro
0x6079	VAR	DC Voltage	Integer16	ro

Target Torque is the input value for the current loop in profile torque mode. The value is given per thousand of the rated current (0x6075).

Index	0x6071
Name	Target Torque
Object Code	VAR
Data Type	Integer16
Object Class	pt
Access	rw
PDO Mapping	Possible
Unit	per thousand of rated current (0x6075)
Value Range	-
Default Value	0

Profile Torque Mode Input Source

Index	0x3071
Name	Profile Torque Mode Input Source for Target Torque
Description	Index/sub-index of input data
Data Type	Unsigned32
Class	pt
Access	rw
PDO Mapping	No
Value	See below
Default Value	0x60710000

This object allows connecting any 16-bit dataflow as a target torque for the Profile Torque Mode.

The structure of the entries is the following:

MSB			LSB
Index (16-bit)	Sub-index (8-bit)	0	

Example:

0x3071,0 = 0x30F10100

connects analog input 1 as the target torque for Profile Torque Mode.

This parameter defines the torque slope when the target torque is changed.

Index	0x6087
Name	Torque Slope
Object Code	VAR
Data Type	Unsigned32
Object Class	pt
Access	rw
PDO Mapping	No
Unit	per thousand of rated current per second
Value Range	-
Default Value	0x10000

"DC Voltage" gives the value of the DC voltage in the drive. This signal is filtered by a low-pass filter (0x3408-2)

Index	0x6079
Name	DC Voltage
Object Code	VAR
Data Type	Integer32
Object Class	all
Access	ro
PDO Mapping	Yes
Unit	mV
Value Range	-
Default Value	-

3.2.3.8 - Sequence Mode

The purpose of the sequencer mode is to allow basic moves.

A basic move is called "sequence" and a list of sequences can be pre-programmed and stored in the drive.

Each sequence is identified with a number (sequence number).


The maximum number of sequences for a given drive is shown in object 0x3612

The different sequence types are the following:

- Positioning sequence
- Homing sequence
- Speed sequence
- Torque sequence
- Gearing sequence

NOTE: depending on model and/or firmware version, not all sequence types above are supported. The sequence types supported are shown in object 0x360F

Various sequences can be sequentially linked together to build a complex move.



Sequence Number: allows the selection of the sequence to be executed. The "Sequence Number" can be connected to physical logic inputs or set via the fieldbus to select the sequence.

Start Condition: A Logic bit pattern can be defined as a condition for a sequence to be started. The "Start Condition" can be connected to physical logic inputs or to a variable via the fieldbus.

Start: A trigger signal (rising edge of start bit) allows starting the sequence which number is set by a sequence number and if the start condition is fulfilled. If the start condition is not ok, the movement will not be executed until the start condition is valid. A sequence is started with bit 4 of control word (0x6040) and stopped with bit 5 of control word.

End Condition: In some sequences, if an "End Condition" is defined, the sequence will be over when the "End Condition" is valid. The "End Condition" is defined by bit patterns (bits equal to 0, bits equal to 1...), and can be connected to physical logic inputs or to a variable via the fieldbus.

Control Word (0x6040):

Bit	Action
4	^ start sequence
5	1 stop sequence
6	reserved

Status Word (0x6041):

Bit	Action
10	Target Reached
12	POS
13	SEQ

Sequence Chaining

The sequence chaining is controlled by the "SeqNext", "SeqCount", "SeqLink" and "StartCond" parameters.

Sequence Parameters

The parameters of all sequences are stored in a RAM memory (sequence memory). These sequence parameters can be set:

- by parameter values defined in a sequence file named SEQUENCE.TXT (see Sequence File format).
- by direct access to the sequence parameters via appropriate objects.

Sequence Files

Loading a sequence file:

- all sequence parameters in the sequence memory will be erased by sequences defined in SEQUENCE.TXT
- if a sequence is not defined in SEQUENCE.TXT, then the sequence will be cleared.
- the SEQUENCE.TXT file will be loaded into the sequence memory when the 24 V supply is applied
- the SEQUENCE.TXT file will be loaded into the sequence memory when writing into object 0x1011 with signature = 0x7165736C (lseq)

Merging a sequence file:

- only sequences defined in SEQUENCE.TXT will be loaded into the sequence memory; other sequences in the memory are not modified.
- the SEQUENCE.TXT file can be merged in sequence memory when writing into object 0x1011 with signature = 0x7165736D (mseq).

Object Definition

Sequence Control

These objects allow controlling the execution of a sequence.

Index	Object	Name	Type	Attr.
0x3601	ARRAY	Sequence Inputs		rw
0x3602	ARRAY	Sequence Outputs		rw
0x3603	VAR	Minimum Sequence Pulse	Unsigned16	rw
0x3604	RECORD	Output Pulse Configuration		rw
0x3605	VAR	Sequence phase	Unsigned16	rw
0x360B	VAR	Sequence Capture Position	integer32	rw
0x360F	VAR	Supported Sequence Type	Unsigned16	ro
0x3612	VAR	Maximum Sequences Supported	Unsigned16	ro

Sequence Parameters

These objects allow the direct access to any parameter of any sequence.


The selected sequence number is defined by object 0x3610, and all sequence parameters are accessed by object 0x3611.

Index	Object	Name	Type	Attr.
0x3610	VAR	Sequence Parameters Number	integer16	rw
0x3611	RECORD	Sequence Parameters		rw


3.2.3.8.1 - Positioning Sequence

The main parameters of a positioning sequence are:

- The position to be reached (absolute or relative)
- The motion speed
- The acceleration time
- The deceleration Time
- The delay time at the end of the motion



Example of 2 positioning sequences without stopping (the deceleration ramp of the first sequence is 0).



Sequence 1:
 SeqType = POS
 Speed = 150000
 AccelTime = 400
 DecelTime = 0
 NextSeq = 2

Sequence 2:
 SeqType = POS
 Speed = 250000
 AccelTime = 300
 DecelTime = 400

Supported keywords and parameters for a positioning sequence

Keyword	Direct parameter entry	Description
SeqType	0x3611-1	value = POS for SEQUENCE.TXT file or value = 1 for direct parameter object
NextSeq	0x3611-2	see sequence parameters
SeqCount	0x3611-3	see sequence parameters
SeqLink	0x3611-4	see sequence parameters
Trigger	0x3611-5	see sequence parameters
Output	0x3611-6	see sequence parameters
	0x3611-7	
	0x3611-8	
StartCond	0x3611-9	see sequence parameters
	0x3611-10	
Tempo	0x3611-23	see sequence parameters
Speed	0x3611-15	defines the speed setpoint of the sequence in velocity unit
Speed2	0x3611-16	defines the speed setpoint at the end of the sequence in velocity unit
Accel	0x3611-17	defines the acceleration time in user unit per square second
Decel	0x3611-18	defines the deceleration time in user unit per square second
Position	0x3611-13	defines the position setpoint in user unit
EndCond	0x3611-11	see sequence parameters
	0x3611-12	

3.2.3.8.2 - Homing Sequence

The Home sequence allows performing a homing procedure.

The main parameters of a home sequence are:

- Home Offset
- Home method
- Speeds
- Acceleration
- Current limit (Torque Limit) for method -1, -2, -3 and -4.


The Home sequence runs like in Homing Mode.

Supported keywords and parameters for a home sequence

Keyword	Direct parameter entry	Description
SeqType	0x3611-1	value = HOME for SEQUENCE.TXT file or value = 2 for direct parameter object
NextSeq	0x3611-2	see sequence parameters
SeqCount	0x3611-3	see sequence parameters
SeqLink	0x3611-4	see sequence parameters
Trigger	0x3611-5	see sequence parameters
Output	0x3611-6	see sequence parameters
	0x3611-7	
	0x3611-8	
StartCond	0x3611-9	see sequence parameters
	0x3611-10	
Method	0x3611-22	defines various ways of the drive to search the homing position
Home offset	0x3611-13	defines the position value when the motor reaches the homing position
Speed	0x3611-15	defines the speed during search of switch (velocity unit)
Speed2	0x3611-16	defines the speed during search of zero (velocity unit)
Accel	0x3611-19	defines the acceleration time in acceleration unit
Current Limit	0x3611-25	defines the current limit in per thousand of the rated current for a homing on mechanical limit
EndCond	0x3611-11	see sequence parameters
	0x3611-12	

3.2.3.8.3 - Speed Sequence

The speed sequence allows moving the axis with a profile speed as follows:




The main parameters of a speed sequence are:

- Speed setpoint
- Acceleration Time
- Deceleration Time
- Running Time

If the Running Time is 65535 (maximum of 16-bit) then the running phase will be executed forever. An "End Condition" can be used to exit this sequence.

If the deceleration Time is 0, then the sequence will end up after the running phase. This allows combining several sequences for a special profile.

Example of combined sequences:



Sequence 1:
 SeqType = SPEED
 Speed = 150000
 AccelTime = 400
 RunTime = 0
 DecelTime = 0
 NextSeq = 2

Sequence 2:
 SeqType = SPEED
 Speed = 250000
 AccelTime = 400
 RunTime = 0
 DecelTime = 0
 NextSeq = 3

Sequence 3:
 SeqType = SPEED
 Speed = 140000
 RunTime = 0
 AccelTime = 400
 DecelTime = 150


The speed setpoint of the Speed Sequence is also limited by the value of the Speed Modulation (0x3081). If the speed modulation is defined, then the sequence speed will be reduced by the speed modulation value.

Supported keyword and parameters for a speed sequence

Keyword	Direct parameter entry	Description
SeqType	0x3611-1	value = SPEED for SEQUENCE.TXT file or value = 3 for direct parameter object
NextSeq	0x3611-2	see sequence parameters
SeqCount	0x3611-3	see sequence parameters
SeqLink	0x3611-4	see sequence parameters
Trigger	0x3611-5	see sequence parameters
Output	0x3611-6	see sequence parameters
	0x3611-7	
	0x3611-8	
StartCond	0x3611-9	see sequence parameters
	0x3611-10	
Tempo	0x3611-23	see sequence parameters
Speed	0x3611-15	defines the speed setpoint of this sequence in velocity unit
AccelTime	0x3611-19	defines the acceleration time in ms.
DecelTime	0x3611-20	defines the deceleration time in ms.
RunTime	0x3611-24	defines the running time in ms. A value of 65535 corresponds to an infinite running time.
EndCond	0x3611-11	see sequence parameters
	0x3611-12	

3.2.3.8.4 - Torque Sequence

The torque sequence allows moving the axis with a profile speed and a current limit.



The main parameters of a torque sequence are:

- Speed setpoint
- Acceleration
- Running Time
- Current limit (Torque Limit)

In the torque control sequence, the motor is running at the speed setpoint value until the current rises up to the limit value. The motor running direction depends on the sign of the speed setpoint. When the current limitation is reached, the amplifier is holding this current during the time interval defined by the Running Time parameter. If the Running Time = 65535, the torque holding time is infinite. In this case, the sequence can be left by an end condition.

At the end of the Running Time, the current position will be captured in object 0x360B.

Notes:

When Torque Sequence is executed, the position following error is disabled.

The Torque Sequence speed is also limited by the value of the Speed Modulation (0x3081). If the speed modulation is defined, then the sequence speed will be reduced by the speed modulation value.

Torque sequence is not operating in sensorless control.

Supported keywords and parameters for a torque sequence

Keyword	Direct parameter entry	Description
SeqType	0x3611-1	Value = TORQUE for SEQUENCE.TXT file or Value = 4 for direct parameter object
NextSeq	0x3611-2	See sequence parameters
SeqCount	0x3611-3	See sequence parameters
SeqLink	0x3611-4	See sequence parameters
Trigger	0x3611-5	See sequence parameters
Output	0x3611-6	See sequence parameters
	0x3611-7	
	0x3611-8	
StartCond	0x3611-9	See sequence parameters
	0x3611-10	
Speed	0x3611-15	Defines the speed setpoint of this sequence in velocity unit
Accel	0x3611-19	Defines the acceleration time in acceleration unit
RunTime	0x3611-24	Defines the running time in ms. A value of 65535 corresponds a infinite running time.
Torque	0x3611-25	Defines the current limit in per thousand of the rated current
EndCond	0x3611-11	See sequence parameters
	0x3611-12	

3.2.3.8.5 - Sequence Chaining

The sequence chaining is controlled by 4 parameters:

- SeqCount,
- SeqNext,
- SeqLink,
- and StartCond.

"SeqCount" defines how many times this sequence will be executed. Then the sequencer will link to SeqNext if the counter is not 0 or link to SeqLink if the counter has expired. There must be only one SeqCount at a time.

"SeqNext" defines the sequence to be executed after the current one.

When a sequence is started:

If "StartCond" is defined:

- If "start condition" is valid, then the sequence will be executed and then link "SeqNext"
- If "Start condition" is not valid, then the sequence is not executed but jump to "SeqLink"

If "StartCond" is not defined:

the sequence will be executed and then link "SeqNext".

COUNTER LOOP

The sequence linkage is controlled by the "SeqNext", "SeqCount" and "SeqLink" parameters.

Application example:

Sequence 1:

SeqCount = 0
SeqNext = 2
SeqLink = -1

Sequence 2:


SeqCount = 2
SeqNext = 3
SeqLink = 1

Sequence 3:

SeqCount = 0
SeqNext = -1
SeqLink = -1

Note: SeqNext = -1 or SeqLink = -1 corresponds to an empty field in the Gem Drive Studio software.

If the execution is starting at sequence 1, the program will be the following:



CONDITIONAL JUMP

The conditional jump is controlled by using the "StartCond" and the "SeqNext", "SeqCount" and "SeqLink" parameters.

Application example:

```


Sequence 1:
    SeqNext = 2
    SeqCount = 0
    SeqLink = -1

Sequence 2:
    SeqNext = 3
    SeqCount = 0
    SeqLink = 4
    Start Cond = "1....."


Sequence 3:
    SeqNext = -1
    SeqCount = 0
    SeqLink = -1

Sequence 4:
    SeqNext = -1
    SeqCount = 0
    SeqLink = -1
    
```

If the execution is starting at sequence 1 and logic input 8 is activated, the program will be the following:



If the execution is starting at sequence 1 and logic input 8 is deactivated, the program will be the following:



3.2.3.8.6 - Sequence Parameters

Sequence Parameters

Supported keyword and parameters for all sequences

Keyword	Direct parameter entry	Description
SeqNb	0x3610	Selects the sequence number (0..127)
SeqType	0x3611-1	This parameter defines the sequence type: POS (1) HOME (2) SPEED (3) TORQUE (4) GEAR (5) in brackets is the value for direct parameter in object 0x3611-1
NextSeq	0x3611-2	Defines the next sequence to be executed after this one if there is no condition or counter
SeqCount	0x3611-3	Defines how many times the sequence must be executed. This counter is decremented each time a sequence is over.
SeqLink	0x3611-4	Defines the number of the sequence to be executed when the SeqCount is not 0
Trigger	0x3611-5	Defines the output triggering event
Output	0x3611-6 0x3611-7 0x3611-8	Defines the output bit which will be reset Defines the output bit which will be set Defines the output bit which will be toggled
StartCond	0x3611-9 0x3611-10	Defines the condition bit which starts the sequence when equal to 0 Defines the condition bit which starts the sequence when equal to 1
Tempo	0x3611-23	Defines the delay time in ms at the end of the positioning
EndCond	0x3611-11 0x3611-12	Defines the condition bit which stops the sequence when equal to 0 Defines the condition bit which stops the sequence when equal to 1

Sequence Inputs

Index	0x3601
Name	Sequence Inputs
Object Code	RECORD
Number of Elements	3

Value Description

Sub Index	1
Description	Sequence Number Input
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	Yes
Default Value	0

This object defines the sequence that will be executed when START is rising up.

Sub Index	2
Description	Executed Sequence Number
Data Type	Integer16
Object Class	sq
Access	ro
PDO Mapping	Yes
Default Value	-

This object indicates the currently running sequence.
A value of -1 means that no sequence is running.

Sub Index	3
Description	Conditional Input
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	Yes
Default Value	0

This object defines the bits pattern which is used for start condition or end condition.

Sequence Outputs

Index	0x3602
Name	Sequence Outputs
Object Code	RECORD
Number of Elements	4

Value Description


Sub Index	1
Description	Programmable Logic Outputs
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	Yes
Default Value	

Sub Index	2
Description	Programmable Logic Outputs Polarity
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Default Value	0

Value	Description
0	For a positive polarity
1	For a negative polarity

Sub Index	3
Description	Dedicated Logic Outputs
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	Yes
Default Value	

Bit	Designation	Description
0	POS	This signal is activated when the motor reaches the position and remains enabled until the next motor movement
1	SEQ	This signal indicates that a sequence is currently executed
2	SPEED	This signal indicates that the speed set point is reached during a movement
3	READY	This signal is activated when the drive is OK



Sub Index	4
Description	Dedicated Logic Outputs Polarity
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Default Value	0

Value	Description
0	For a positive polarity
1	For a negative polarity

Minimum Sequence Pulse

This function is useful for the detection of a sequence with a short duration.

Index	0x3603
Name	Minimum Sequence Pulse
Object Code	VAR
Data Type	Unsigned16
Object Class	Sq
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0 this function is not activated 1...65535 this function defines the minimum duration of the SEQ output
Default Value	0

Sequence Outputs

Index	0x3604
Name	Output Pulse Configuration
Object Code	RECORD
Number of Elements	2

Value Description

Sub Index	1
Description	Output Pulse
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	0 the bit number is configured as Output 1 the bit number is configured as Output Pulse
Default Value	0

Sub Index	2
Description	Output Pulse Duration
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Unit	ms
Value Range	1...16000
Default Value	0

This parameter defines the duration of the output activation.


Sequence Phase

This object monitors the state inside a sequence.

Index	0x3605
Name	Sequence Phase
Object Code	VAR
Data Type	Unsigned16
Object Class	sq
Access	ro
PDO Mapping	Yes

Data Description

Bit Number	Function
0	begin
1	cruise
2	decel
3	hold
4	inpos
5	end



Sequence Captured Position

This object gives the value of the position captured by the torque sequence.

Index	0x360B
Name	Sequence Captured Position
Object Code	VAR
Data Type	Integer32
Object Class	sq
Access	ro
Unit	Position Unit
PDO Mapping	Yes

Supported Sequence Types

Various sequence types can be implemented in a given firmware and drive model. This object shows supported sequence types. This object is read only.

Index	0x360F
Name	Supported sequence types
Object Code	VAR
Data Type	Unsigned16
Object Class	sq
Access	ro
PDO Mapping	No
Value	See below

Data Description

Bit Number	Function
0	Positioning sequence supported
1	Homing sequence supported
2	Velocity sequence supported
3	Torque sequence supported
4	Gearbox sequence supported
5	Cam sequence supported

Maximum Sequences supported

This object gives the maximum sequences supported by a given device.
The sequence number is between 0 and maximum sequences supported - 1

Index	0x3612
Name	Maximum sequence supported
Object Code	VAR
Data Type	Unsigned16
Object Class	sq
Access	ro
PDO Mapping	No
Value	See below

Sequence Parameters Number

Index	0x3610
Name	Sequence Parameters Number
Object Code	VAR
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	No
Default Value	0

This parameter holds the sequence number for direct reading/writing into sequence parameters by object 0x3611.

Sequence Parameters

Index	0x3611
Name	Sequence Parameters
Object Code	RECORD
Number of Elements	26

This object allows reading/writing all parameters of a sequence which number is given in object 0x3610.

Value Description

Sub Index	1
Description	Sequence Type
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	No
Default Value	

This parameter allows reading/writing the type of a sequence. Check object 0x360F for supported sequence types.

The value is the sequence type:

Value	Function
0	Not defined
1	Positioning sequence
2	Homing sequence
3	Speed sequence
4	Torque sequence
5	Gear sequence (if device supports)
6	Cam sequence (if device supports)


Sub Index	2
Description	Next sequence
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	-1..127 -1 means there is no other sequence
Default Value	

Sub Index	3
Description	Sequence Counter
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	

Sub Index	4
Description	Sequence Link
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	-1..127
Default Value	

Sub Index	5
Description	Output Trigger
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	

Bit Number	Function	Description
0	BEGIN	
1	CRUISE	
2	DECEL	
3	HOLD	
4	INPOS	The output is triggered according to the parameter Position Window (see 0x6067)
5	END	The output is triggered after Temporization at the end of the positioning



Sub Index	6
Description	Output Bits = 0
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	0

Sub Index	7
Description	Output Bits = 1
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	0

Sub Index	8
Description	Output Bits Toggle
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	0

Sub Index	9
Description	Start Condition Bits = 0
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	0

Sub Index	10
Description	Start Condition Bits = 1
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	0

Sub Index	11
Description	End Condition Bits = 0
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	0

Sub Index	12
Description	End Condition Bits = 1
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Value Range	
Default Value	0

Sub Index	13
Description	Position
Data Type	Integer32
Object Class	sq
Access	rw
PDO Mapping	No
Unit	Position Unit
Value Range	

For a homing sequence, this parameter defines the home offset value.

Sub Index	14
Description	Position 2 (reserved for future use)
Data Type	Integer32
Object Class	sq
Access	rw
PDO Mapping	No
Unit	Position Unit
Value Range	

Sub Index	15
Description	Speed
Data Type	Integer32
Object Class	sq
Access	rw
PDO Mapping	No
Unit	Speed Unit
Value Range	
Default Value	0

Sub Index	16
Description	Speed 2 / Position 3 (reserved for future use)
Data Type	Integer32
Object Class	sq
Access	rw
PDO Mapping	No
Unit	Speed Unit / Position Unit
Value Range	
Default Value	0

Sub Index	17
Description	Acceleration
Data Type	Unsigned32
Object Class	sq
Access	rw
PDO Mapping	No
Unit	Acceleration Unit
Value Range	
Default Value	0

Sub Index	18
Description	Deceleration
Data Type	Unsigned32
Object Class	sq
Access	rw
PDO Mapping	No
Unit	Acceleration Unit
Value Range	
Default Value	0

Sub Index	19
Description	Acceleration Time
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Unit	ms
Value Range	1..65535
Default Value	0

Sub Index	20
Description	Deceleration Time
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0..65535
Default Value	0

Sub Index	21
Description	Configuration
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Default Value	0

For a position sequence, this parameter defines the positioning type:

Value	Function
0	Absolute positioning
1	Relative positioning

For a homing sequence, this parameter defines the "return" configuration:

Value	Function
0	No return
1	Return to homing position

Sub Index	22
Description	Configuration 2
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	No
Default Value	0

For a homing sequence, this parameter defines the homing method.

Sub Index	23
Description	Temporization
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0...16000
Default Value	0

Sub Index	24
Description	Running Time
Data Type	Unsigned16
Object Class	sq
Access	rw
PDO Mapping	No
Unit	ms
Value Range	
Default Value	0

For a speed sequence or a torque sequence, if the Running Time is 65535 (maximum of 16-bit), then the running phase will be executed forever. An "End Condition" can be used to exit this sequence.

Sub Index	25
Description	Analog In
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	No
Unit	16-bit scaled value
Value Range	
Default Value	0

For a torque sequence, this parameter defines the torque value.
 For a homing sequence, this parameter defines the home current limit value.

Sub Index	26
Description	Analog In 2 (reserved for futur use)
Data Type	Integer16
Object Class	sq
Access	rw
PDO Mapping	No
Unit	16-bit scaled value
Value Range	
Default Value	0

3.2.3.8.7 - Sequence File Format

Description

1. Sequence files are text files.
 Characters are not case sensitive.
2. The parameter syntax is:
 Key_word = value
 There must be only one key word per line.
3. The parameter value can be:
 - a number: decimal or hexadecimal (preceded by 0x)
 - a constant (text)
4. The character ; indicates the begin of a comment to the end of the line.
5. A sequence begins with keyword **SeqNb**
6. The parameters of a sequence are declared one after the other. Except for **SeqNb**, the parameter order has no importance.
7. There is no indication for the end of a sequence. A new sequence with SeqNb indicates the end of the current sequence.
8. Incoherent parameters or values out of the limits will generate an error.
9. In a sequence, parameters which are not declared will have a default value.
 The default value can be changed by means of the **Default** keyword.
10. The sequencer can load sequence files in two ways:
 - LOAD: load declared sequences from the sequence file into memory. Sequences that are not declared will be cleared.
 - MERGE: load declared sequences from the sequence file into memory. Sequences that are not declared in the file will be kept.

Sequence file example:

```

; define some default values
Default
Accel=100000
Decel=100000

; sequence 1: positioning
SeqNb=1
SeqType=pos
Pos=0x001000
PosType=ABS ; absolute positioning
Speed=100000
Output="..001000"
Trigger=begin ; activate outputs at the beginning of the sequence
Tempo=1000
SeqNext=3

; sequence 3: run at high speed during 10 s
SeqNb=3
SeqType=speed
AccelTime=200000
DecelTime=200000
Speed=500000
RunTime=10000
    
```

Sequence Keyword

Supported sequence types:

- Positioning sequence
- Homing sequence
- Speed sequence
- Torque sequence

General Parameters

General parameters are for all sequence types.

Key word	Signification/Constance
SeqType	Sequence Type POS, SPEED, HOME, TORQUE, GEAR
SeqNext	Next sequence
SeqCount	Sequence Counter
SeqLink	Conditional Jump
Output	Output
Trigger	Output trigger BEGIN, CRUISE, DECEL, HOLD, END
StartCond	Start condition inputs
EndCond	End condition inputs

Positioning Sequence

Key word	Signification
PosType	Positioning type: ABS / REL
Pos	Positioning value
Speed	Move Speed
Speed2	End Speed
Accel	Acceleration
Decel	Deceleration
Tempo	Temporization at the end of positioning

Homing Sequence

Key word	Signification
HomeOfs	Position Offset
Speed	Speed during search for switch
Speed2	Speed during search for Zero
Accel	Acceleration
Decel	Deceleration
Method	Homing method
Torque	Torque limit for mechanical limit homing

Speed Sequence

Key word	Signification
Speed	Move Speed
AccelTime	Acceleration Time
DecelTime	Deceleration Time
RunTime	Move Time

Torque Sequence

Key word	Signification
Speed	Move Speed
Accel	Acceleration
Decel	Deceleration
RunTime	Torque limit Time
Torque	Torque limit

3.2.3.9 - Analog Speed Mode

Analog Speed Mode

In this mode, the Xtrapuls drive operates as a variable speed drive.

The speed reference is the analog input 1.

The maximum speed defined by 0x6080 is reached with 10 V input.

The acceleration time from 0 to maximum speed and the deceleration time from maximum speed to 0 are defined in ms by object 0x604F.

The deceleration time is also defined in ms by object 0x304F. This allows setting a deceleration time different from the acceleration time.

Operation Mode number: -1 (0x6060)

If HALT bit in control word (0x6040) is set, the speed reference is reset at 0.

Index	0x604F
Name	Velocity Ramp
Object Code	VAR
Data Type	Unsigned32
Object Class	as
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0 - 0x3FFF80
Default Value	0

This object defines the acceleration time from 0 to maximum motor speed defined in 0x6080, and the deceleration time from maximum motor speed to 0.

Index	0x304F
Name	Velocity Ramp 2
Object Code	VAR
Data Type	Unsigned32
Object Class	as
Access	rw
PDO Mapping	No
Unit	ms
Value Range	0 - 0x3FFF80
Default Value	0

This object defines the deceleration time from maximum motor speed to 0.

3.2.3.10 - Analog Torque Mode

Analog Torque Mode

In this mode, the Xtrapuls drive operates in current loop with current reference from analog input 1.

The Analog Input value is given by:

$$\text{Analog_Input_1} = (\text{ADC} - \text{AnalogIn1Offset}) * \text{AnalogIn1Gain} / 256$$

ADC value = 0x7FF0 for 10 V

AnalogIn1Offset is the offset of the analog input and is defined by object 0x30F1,3

AnalogIn1Gain is defined by object 0x30F1,4

The current reference is set with Analog_Input_1. A value of 0x7FFF corresponds to drive size (0x6510,1)

If HALT bit in control word (0x6040) is set, then the current reference is reset at 0.

The object 0x3077,0 allows defining a window in which the status bit Target_Reached is set.

Analog torque operation mode selection code: -5 (0x6060)

Index	0x3077
Name	Torque Threshold
Object Code	VAR
Data Type	Integer16
Object Class	at
Access	rw
PDO Mapping	No
Unit	0x7FFF -> drive current rating
Default Value	0

3.2.4 - Application Feature

3.2.4.1 - Digital Input/Output configuration

Digital Inputs / Outputs

The Xtrapuls drive allows:

- connecting any physical logic input to any bit in any variable,
- connecting any bit in any variable to any physical logic output.

The available logic input functions are:

- Negative Limit Switch
- Positive Limit Switch
- Homing Switch
- Inhibit

Index	Object	Name	Type	Attr.
0x60FD	VAR	Digital Inputs	Unsigned32	ro
0x3050	ARRAY	Digital Inputs Configuration	Unsigned32	rw
0x3051	VAR	Digital Inputs Polarity	Unsigned16	rw
0x60FE	ARRAY	Digital Outputs	Unsigned32	rw
0x3054	ARRAY	Digital Outputs Configuration	Unsigned32	rw
0x3055	VAR	Digital Outputs Polarity	Unsigned16	rw
0x3058	ARRAY	Digital User Inputs/Outputs	Unsigned16	rw
0x3043	ARRAY	Enable Configuration	Unsigned16	rw

Example: ENABLE / INHIBIT input with physical input IN4.

- Drive can move only when 24 V is applied on IN4 (logic 1),
- When 24 V is lost on IN4 (logic 0), drive must stop.

So, IN4 input must be connected to the "Inhibit" function with 0x3050. When the "Inhibit" function is activated with logic level 1, the input polarity of IN4 must be reversed by object 0x3051.

0x3050,4 = 0x60FD0003 and 0x3051,0 bit 3 is set.



CAUTION !

This configuration is not suitable for the drive STO function operation.

Digital Inputs

Index	0x60FD
Name	Digital Inputs
Object Code	VAR
Data Type	Unsigned32
Object Class	all
Access	rw
PDO Mapping	Possible
Default Value	No

bit	Function
0	Logic Input Negative Limit Switch Function: 0 running 1 stopped in negative direction with stop on current limit
1	Logic Input Positive Limit Switch Function: 0 running 1 stopped in positive direction with stop on current limit
2	Logic Input HOME 0 - 1 Home switch activated
3	Logic Input INHIBIT 0 - 1 drive is disabled
4..11	Reserved
12	Logic Input RESET ↑ fault reset
13	Logic Input ENABLE 0 drive is disabled ↑ drive is enabled
14	Logic Input Motor Phasing ↑ start motor phasing
15	1 QuickStop
16	Physical input IN1
17	Physical input IN2
18	Physical input IN3
19	Physical input IN4
20..29	Reserved
30	Encoder Virtual Top Z (defined by 0x3127)
31	Resolver Virtual Top Z (defined by 0x3107)

Digital Inputs Configuration

Index	0x3050
Name	Digital Inputs Configuration
Object Code	ARRAY
Number of Elements	10

The digital Inputs configuration allows affecting any digital input to one bit in a variable indicated by index and sub-index.

Value Description

Sub Index	1-10
Description	Digital Inputs Destination defines the destination object for the corresponding digital input.
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x00000000

The structure of the entries is the following:

MSB	LSB
Index (16-bit)	Sub-index (8-bit) Bit number n (0-15)

The state of the physical input will be copied into bit n of the object indicated by index and sub-index.

Digital Inputs Polarity

Index	0x3051
Name	Digital Inputs Polarity
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	Possible
Default Value	No

bit	Function
0	input IN1
1	input IN2
2	input IN3
3	input IN4
4-15	Reserved

Digital Outputs

Index	0x60FE
Name	Digital Output
Object Code	ARRAY
Number of Elements	2

Value Description

Sub Index	1
Description	Digital Output
Data Type	Unsigned32
Access	rw
PDO Mapping	Possible
Default Value	0

bit	Function
0	Motor Brake
1..15	Reserved
16	Physical Output OUT1
17	Physical Output OUT2
18..31	Reserved

Sub Index	2
Description	Digital Output Bitmask
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0

If the Digital Output Bitmask corresponding to "Motor Brake" (bit 0) is set, the sub 1 allows the manual control of the motor brake. Otherwise, the motor brake is automatically controlled when the drive is enabled/disabled with a delay.

Digital Outputs Configuration

Index	0x3054
Name	Digital Outputs Configuration
Object Code	ARRAY
Number of Elements	6

The digital outputs configuration allows affecting one bit of any variable indicated by the index and sub-index to a physical output.

Value Description

Sub Index	1-6
Description	Digital Output Source defines the source for digital output.
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Default Value	0x00000000

The structure of the entries is the following:

MSB	LSB
Index (16-bit)	Sub-index (8-bit) Bit number n (0-31)

The state of bit n of the object index and sub-index will be copied to the physical output.

Digital Outputs Polarity

Index	0x3055
Name	Digital Outputs Polarity
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	Possible
Default Value	No

bit	Function
0	Output OUT1
1	Output OUT2
2-15	Reserved

Digital Inputs/Outputs 16-bit format

Index	0x3058
Name	Digital IO 16bits
Object Code	ARRAY
Object Class	all
Number of Elements	2

Value Description

Sub Index	1
Description	Digital Inputs 16b status of digital inputs depending on the polarity (0x3051) setup.
Data Type	Unsigned16
Access	ro
PDO Mapping	Possible
Default Value	No

Corresponds to the 16 MSB of 0x60FD,0

Sub Index	2
Description	Digital Outputs 16b
Data Type	Unsigned16
Access	rw
PDO Mapping	Possible
Default Value	0

Corresponds to the 16 MSB of 0x60FE,1

Sub Index	3
Description	Physical Digital Inputs 16b status of hardware digital inputs.
Data Type	Unsigned16
Access	ro
PDO Mapping	Possible
Default Value	No

bit	Function
0	Hardware physical input IN1
1	Hardware physical input IN2
2	Hardware physical input IN3
3	Hardware physical input IN4
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	Encoder Virtual Top Z (defined by 0x3127)
15	Resolver Virtual Top Z (defined by 0x3107)

3.2.4.2 - Analog Input

XtrapulsEasy servo drives have 1 analog input:

Index	Object	Name	Type	Attr.
0x30F1	RECORD	Analog Input 1		rw

Analog Input

Index	0x30F1
Name	Analog Input
Object Code	RECORD
Number of Elements	7

Value Description

Sub Index	1
Description	Analog Input 16-bit Value Conversion data from ADC. The sampling rate is 16 kHz The result is left aligned.
Data Type	Integer16
Access	ro
PDO Mapping	Yes
Value Range	No
Default Value	No

Sub Index	2
Description	Analog Input 32-bit Value
Data Type	Integer32
Access	ro
PDO Mapping	Yes
Value Range	No
Default Value	No

$\text{Analog_Input_32bit_Value} = (\text{Analog_Input_16bit_Value} - \text{Offset}) * \text{Gain} / 256$
The Gain value is signed.

Example: using analog input as speed reference.

The speed reference is 32-bits, so the 32-bit value will be used.

Let's say that the maximum speed is 30000 rpm and the unit is inc/s with 4096 inc per motor revolution.

Maximum speed: 30000 rpm -> 500 rev/s -> 2048000 inc/s

The maximum 16-bit analog input is 32767

Gain = 2048000 / 32767 * 256 = 16000

Sub Index	3
Description	Offset
Data Type	Integer16
Access	rw
PDO Mapping	Yes
Value Range	-
Default Value	0

Sub Index	4
Description	Gain
Data Type	Integer16
Access	rw
PDO Mapping	Yes
Value Range	-
Default Value	256

Sub Index	5
Description	Filter
Data Type	Unsigned16
Access	rw
PDO Mapping	Yes
Unit	Hz
Value Range	5-20000
Default Value	100


The filter is applied on Analog Input 16-bit Value.

Sub Index	6
Description	Analog In Level 0
Data Type	Integer16
Access	rw
PDO Mapping	No
Value Range	
Default Value	

This parameter defines level 0 for position capture with analog input (see diagram below).


Sub Index	7
Description	Analog In Level 1
Data Type	Integer16
Access	rw
PDO Mapping	No
Value Range	
Default Value	

This parameter defines level 1 for position capture with analog input (see diagram below).




3.2.4.3 - Capture

Capture/Touch probe Function



The purpose of the capture function is to latch a data signal (generally position value from a sensor) on a trigger input signal (generally a logic input).




Xtrapuls capture features:

- The data signal can be a resolver position value or an encoder position value,
- The trigger input signal can be any of the physical logic inputs, any of the analog inputs or the encoder marker Z,
- The capture can be triggered on rising edge, falling edge or both.
- The trigger input signal can be filtered by a time filter,
- The data signal can be filtered by a space filter.


Capture Time Filter

This parameter defines the time interval threshold of the capture time filter. After the rising or falling edge of the input signal, the input signal level must be stable for a time interval value greater than or equal to the time interval threshold defined by object 0x337n-4 in order to get the position capture validated as described below.



Capture Space Filter

This parameter defines the value in distance threshold of the capture position filter. If the position gap between rising and falling edges is less than the threshold, then the signal is the following:



Objects definition

Index	Object	Name	Type	Attr.
0x3370	VAR	Capture Status	Unsigned16	ro
0x337F	VAR	Capture Status for TPDO	Unsigned16	ro
0x3371	RECORD	Capture 1		rw

The capture 1 can also be accessed by CANopen DSP-402 interface (Touch Probe):

Index	Object	Name	Type	Attr.
0x60B8	VAR	Touch Probe Function	Unsigned16	rw
0x60B9	VAR	Touch Probe Status	Unsigned16	ro
0x60BA	VAR	Touch Probe Pos1 Positive Value	Integer32	ro
0x60BB	VAR	Touch Probe Pos1 Negative Value	Integer32	ro
0x60D0	ARRAY	Touch Probe Source		rw

Capture objects

Capture Status

Index	0x3370
Description	Capture Status
Data Type	Unsigned16
Access	ro
PDO Mapping	Possible
Value	-
Default value	-

Bit Number	Function
0	Capture 1 enabled
1	Capture Input 1 image
2	Change state: a capture on rising edge of input 1 occurred
3	Change state: a capture on falling edge of input 1 occurred
4-15	Reserved

The Capture Status is clear when writing to Capture configuration (0x337n-1)

Capture Status for PDO

Index	0x337F
Description	Capture Status for PDO
Data Type	Unsigned16
Access	ro
PDO Mapping	Possible
Value	-
Default value	-

Bit Number	Function
0	Capture 1 enabled
1	Capture Input 1 image
2	A capture on rising edge of input 1 occurred
3	A capture on falling edge of input 1 occurred
4-15	Reserved

Capture indicators (bit 2, 3) are cleared when this object is sent by a PDO.

Capture Parameters

Index	0x3371 for capture 1
Name	Capture Parameters
Object Code	RECORD
Number of Elements	8

Value Description

Sub Index	1
Description	Capture 1 Config
Data Type	Unsigned16
Access	rw
PDO Mapping	No

Bit Number	Function
0	Capture on rising edge
1	Capture on falling edge
4	0 Continue capture 1 Single-shot capture
15	Enable Capture

Sub Index	2
Description	Capture 1 source
Data Type	Unsigned32
Access	rw
PDO Mapping	No

This parameter allows connecting a 32-bit dataflow as input of the capture data signal.

Possible source signals:

Index,sub	Signal
0x6064,0	Position feedback
0x3109,0	Resolver position (if resolver is supported)
0x3129,0	Encoder Position (if encoder is supported)
0x3189,0	Encoder 2 Position (if encoder 2 is supported)

The structure of the entries is the following:

MSB		LSB	
Index (16-bit)	Sub-index (8-bit)	0	

Example:

Capture 1 data is connected to resolver position:
0x3371,2 = 0x31090000

Sub Index	3
Description	Capture 1 Input
Data Type	Unsigned16
Access	rw
PDO Mapping	No

This parameter allows defining a logic input as capture trigger signal.

Value	Function
0	IN1
1	IN2
2	IN3
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	Analog In 1
13	Analog In 2
14	Encoder Top Z
15	Resolver Zero

IN1 .. IN3 are physical inputs.

The capture triggered by the analog input is defined by analog levels (0x30F1).

Sub Index	4
Description	Capture Time Filter
Data Type	Unsigned16
Access	rw
PDO Mapping	No
Unit	µs

Sub Index	5
Description	Capture Position Filter
Data Type	Unsigned32
Access	rw
PDO Mapping	No
Unit	Position unit

Sub Index	6
Description	Capture Position
Data Type	Integer32
Access	ro
PDO Mapping	Yes
Unit	Position unit

Sub Index	7
Description	Rising Edge Capture Position
Data Type	Integer32
Access	ro
PDO Mapping	Yes
Unit	Position unit

Sub Index	8
Description	Falling Edge Capture Position
Data Type	Integer32
Access	ro
PDO Mapping	Yes
Unit	Position unit

Touch Probe Objects

Touch Probe Function

Index	0x60B8
Description	Touch Probe Function
Data Type	Unsigned16
Access	rw
PDO Mapping	Possible
Value	-
Default value	-

Bit Number	Function
0	Enable Touch Probe 1
1	0 Trigger First Event 1 Continuous
3, 2	00 Trigger with Touch Probe 1 Input 01 Trigger with TopZ 10 Touch Probe Source defined by object 0x60D0,1 11 reserved
4	Enable sampling at positive edge of touch probe 1
5	Enable sampling at negative edge of touch probe 1
6, 15	Reserved

Touch Probe Status

Index	0x60B9
Description	Touch Probe Status
Data Type	Unsigned16
Access	ro
PDO Mapping	Possible
Value	-
Default value	-

Bit Number	Function
0	Touch Probe 1 Enabled
1	Touch Probe 1 Positive Edge Position Stored
2	Touch Probe 1 Negative Edge Position Stored
3..15	reserved

Touch Probe Pos1 Pos Value

Index	0x60BA
Description	Touch Probe Pos1 Pos Value
Object Code	VAR
Data Type	Integer32
Object class	All
Access	ro
PDO Mapping	Possible
Unit	User Position Unit
Default value	-

Touch Probe Pos1 Neg Value

Index	0x60BB
Description	Touch Probe Pos1 Neg Value
Object Code	VAR
Data Type	Integer32
Object class	All
Access	ro
PDO Mapping	Possible
Unit	User Position Unit
Default value	-

Touch Probe Source

Index	0x60D0
Name	Touch Probe Source
Object Code	ARRAY
Number of Elements	1

Value Description

Value	Touch Probe Source
-15	Resolver TopZ
-14	Encoder TopZ
-13	Analog In 2
-12	Analog In 1
-5	
1	IN1
2	IN2
3	IN3
4	
6	TopZ

Sub Index	1
Description	Touch Probe 1 Source
Data Type	Integer16
Access	rw
PDO Mapping	No
Value	See table above
Default Value	3

3.2.4.4 - Modulo function

Index	0x307B
Name	Modulo configuration
Object Code	VAR
Data Type	Unsigned16
Object Class	all
Access	rw
PDO Mapping	No
Default Value	0

The motor position can be limited by the position limit function (modulo function).


Minimum Position Limit <= Motor Position < Maximum Position Limit

Bit Number	Function
0	Modulo Function 0 disable 1 enable
2	Forward (always in positive direction)
3	Backward (always in negative direction)
4	CLEAR input function 0 disable 1 enable

- "Forward" and "Backward" cannot be set at the same time.
- "Modulo Enable/Disable" (bit 0) and CLEAR input function (bit 4) cannot be changed when drive is enabled.

Modulo Function with forward:

The forward bit forces the motor to move always in positive direction.



CLEAR input function:

The CLEAR input function allows using the HOME input (0x60FD) to reset the position value.

CLEAR input function and modulo function must not be activated at the same time.

The motor position can be limited by the position limit function or modulo function.

The modulo function is enabled / disabled by object 0x307B.

$$\text{Minimum Position Limit} \leq \text{Motor Position} < \text{Maximum Position Limit}$$

The Position Limit values are defined by object 0x607B. These position values can only be changed when the modulo function is disabled.

Index	0x607B
Name	Position Limit
Object Code	ARRAY
Object Class	all
Number of Elements	2

Value Description

Sub Index	1
Description	Minimum Position Limit
Data Type	Integer32
Access	rw
PDO Mapping	No
Unit	User position unit
Value	

Sub Index	2
Description	Maximum Position Limit
Data Type	Integer32
Access	rw
PDO Mapping	No
Unit	User position unit
Value	

3.2.5 - Maintenance**3.2.5.1 - Files****Xtrapuls drive Files**

The **Xtrapuls** drive can store data files in its internal Flash memory:

Name	Format	Description
DRIVEPAR.TXT	text object file	Drive parameters are saved in these files. The user can save drive parameters by means of the Gem Drive Studio software or via the communication bus by means of object 0x1010 (CAN bus, RS-232...)
USER_PAR.TXT	text object file	This file can keep extra parameters by the user. The parameters are set manually and the USER_PAR.TXT file must be sent to the Xtrapuls drive.
SEQUENCE.TXT	text sequence file	Sequence files for Positioner Mode

Object File**Object file format**

The object file (i.e. CANopen object) is a plain text file allowing the definition of an object list in the drive, which values must be defined.

The syntax is:

```
index,sub=object_value
```

All digital values can be in hexa (preceded by 0x) or decimal.

Only one allocation per line is allowed.

A comment line begins with a ;

All lines that do not begin with a figure will be ignored.

Example:

```
0x3549,10=0x12
```

means the allocation of value 0x12 to object index 0x3549 sub-index 10

```
13641,0xA=18
```

gives the same result.

Notes

- The drive parameter file (DRIVEPAR.TXT) has also got this format.
- The USER_PAR.TXT file is not mandatory. It allows, for example, defining an initial configuration of the drive directly by the user.

3.2.5.2 - Firmware update

Update File

An Update File contains a file header and one or several data blocks.

```
File_Header
Binary_Block_1
Binary_Block_2
...
Binary_Block_n
```

File_Header (32 bytes):

```
00000000 File_code 'IDUF' (0x46554449)
00000004 File_crc32: from byte 4 to the end of file
00000008 Protect Data length (bytes): file_length - 8
0000000C Device Sectors
00000010 Update_Code
00000012 Number of Binary Blocks
00000014 Number of Block Type
00000016 Version
00000018 Device Address
0000001C reserved
00000020 First Binary Block
```

Binary_Block_k: Block_Header + Block_Data

Block header (16 bytes):

```
00000000 Block_crc32: from byte 4 to the end of block
00000004 Block_type: 1-algo, 2-security, 3-code
00000006 Block_Cmd
00000008 Block_addr: Device memory address
0000000C Block_length: length of block data (bytes)
00000010 Block data...
```

Update Interface

General Commands

Index	0x5F30
Name	Update
Object Code	RECORD
Number of Elements	5

Value Description

Sub Index	1
Description	Update_Code
Data Type	Unsigned16
Access	rw
Value	Write: Select firmware_Code (> 0) Read back: same code = Update_Code supported, 0 if not supported

Sub Index	2
Description	Update_Mode
Data Type	Unsigned16
Access	rw
Value	Write signature: 0x00000001 Change to update mode, Update_Code must be <> 0 depend on Update_Code, the execution time of this instruction may be very long: for example: update firmware -> switch from firmware mode to bootmanager mode

Update Init

Index	0x5F31
Name	Update Init
Object Code	RECORD
Number of Elements	5

Sub Index	1
Description	Number of Binary Blocks
Data Type	Unsigned16
Access	rw
Value	

Sub Index	2
Description	Number of Block Types
Data Type	Unsigned16
Access	rw
Value	

Sub Index	3
Description	Sectors
Data Type	Unsigned32
Access	rw
Value	Each bit = 1 sectors support up to 32 sectors

Sub Index	4
Description	Erase Command
Data Type	Unsigned32
Access	rw
Value	Signature = 0x00000001 the execution time of this instruction is very long

Block process

Index	0x5F32
Name	Block process
Object Code	RECORD
Number of Elements	5

Value Description

Sub Index	1
Description	Block_Type
Data Type	Unsigned16
Access	rw
Value	defines the Block_Type of data bock

Sub Index	2
Description	buffer_Size (read-only)
Data Type	Unsigned32
Access	ro
Value	gives the buffer size (bytes) for current block (depends on block_type)

Sub Index	3
Description	Current_sector (read-only)
Data Type	Unsigned32
Access	ro
Value	

Sub Index	4
Description	Current_address (read-only)
Data Type	Unsigned32
Access	ro
Value	

Sub Index	5
Description	Buffer (segmented)
Data Type	Unsigned32
Access	rw
Value	transfer data to/from buffer: binary_block (block_header + block_data)

Programming sequence

Initialization:

Update Code: write 0x5F30,1 = update_code
 Change to program mode: write 0x5F30,2 = 1
 Verify program mode: read 0x5F30,2 = 1

Erase:

Number of Blocks: write 0x5F31,1 = n_blocks
 Number of Block_type: write 0x5F31,2 = n_types
 Sectors Mask: write 0x5F31,3 = sectors_mask
 Erase command: write 0x5F31,4 = 1
 Verify erase command: read 0x5F31,4 = 0

Programming: repeat (n blocks)

Write Block_type: write 0x5F32,1 = block_type
 Write Block (header & data): write seg 0x5F32,5
 Program Block command: write 0x5F32,6 = 1
 Verify program command: read 0x5F32,6 = 0

3.3 - OBJECT LIST

Parameters in bold are saved into the parameter file.

Index	Sub	Name	Description
-------	-----	------	-------------

Communication

0x1005		Sync_ID	Sync CoblD
0x1006		Period	Communication Cycle Period
0x100C		Guard_T	NodeGuarding Guard Time
0x100D		LifeTime	NodeGuarding Life time factor
0x1014		Emcy_ID	Emcy CoblD
0x1016		HeartBt	Consumer Heartbeat Time
0x1017		HBprod	Producer Heartbeat Time
0x1018		Identity	CANopen Identity object
0x1200		SrvSDO	Server SDO parameter
0x1201		SrvSDO2	Server SDO 2 parameter
0x1280		CliSDO1	Client SDO 1 parameter
0x1281		CliSDO2	Client SDO 2 parameter
0x1400		RPDO1par	RPDO1 parameter
0x1401		RPDO2par	RPDO2 parameter
0x1402		RPDO3par	RPDO3 parameter
0x1403		RPDO4par	RPDO4 parameter
0x1600		RPDO1map	RPDO1 mapping
0x1601		RPDO2map	RPDO2 mapping
0x1602		RPDO3map	RPDO3 mapping
0x1603		RPDO4map	RPDO4 mapping
0x1800		TPDO1par	TPDO1 parameter
0x1801		TPDO2par	TPDO2 parameter
0x1802		TPDO3par	TPDO3 parameter
0x1803		TPDO4par	TPDO4 parameter
0x1A00		TPDO1map	TPDO1 mapping
0x1A01		TPDO2map	TPDO2 mapping
0x1A02		TPDO3map	TPDO3 mapping
0x1A03		TPDO4map	TPDO4 mapping

0x2000		NMTmastr	NMT Start/Stop
0x2001		NMTstate	NMT state
0x2004		AxisName	Axis Name
0x2006		SyncCtrl	Can Synchronisation parameter
	1	SCphase	
	2	SCthresh	
	3	SCadjust	
	4	SCerror	
	5	SCfilter	
0x200A		DevAddr	DeviceID
	1	Deviceld	
0x2010	0	NMTboot	Boot-up configuration
0x205D	0	NMTcfg	NMT configuration
0x205E	0	NMTerror	NMT error behaviour
0x205F	0	EMCYmsg	EMCY message behaviour

0x2300		SerialP	RS-232 parameters
	1	SP_baud	
	2	SP_data	
	3	SP_par	
	4	SP_stop	
0x2301	0	SP_pro	RS-232 protocol select
0x2310		Can_Baud	Can Baudrate

General

0x1000		DevType	Device Type
0x1008		DevName	Manufacturer Device Name
0x1009		Hardware	Manufacturer Hardware Version
0x100A		Software	Manufacturer Software Version

0x5F80		Version	Version
	1	ver_sw	Software Version
	2	ver_hw	Hardware Version
	3	ver_pld	PLD Version
	4	ver_psoc	Power Controller Version
	5	ver_dico	Dictionary Version
	6	ver_bman	Bootmanager Version
	7	ver_plug	Plugin Version

0x1010		StorePar	Store parameters
0x1011		LoadPar	Restore parameters

0x6510	0	DrvData	Drive Data
	1	DrvMax	Drive Max. Current
	2	DrvRated	Drive Rated Current
	3	DrvVolt	Drive Voltage
	4	OpVolt	Operating Voltage
	5	LowVolt	Low Voltage Threshold
0x6502	0	DrvModes	Supported drive modes
0x6504	0	ManName	Manufacturer Name

0x3079	0	DCwarn	Undervoltage Warning Threshold
--------	---	--------	--------------------------------

0x33B0	0	BkRes	Braking resistor duty cycle limit
--------	---	-------	-----------------------------------

0x3328	0	Tpwrmod	IGBT module temperature value
--------	---	---------	-------------------------------

Device Control

0x6040	0	ControlW	Control Word
0x6041	0	StatusW	Status Word
0x605A	0	QStopOC	Quick Stop option code
0x605B	0	ShutDnOC	Shutdown option code
0x605C	0	DisOpOC	Disable Operation option code
0x305A	0	InhOpOC	Inhibit option code
0x6060	0	ModeOp	Mode of Operation
0x6061	0	ModeOpDp	Mode of Operation Display
0x3041	0	DevState	Device state monitoring
	1	DC_State	Device Control State
	2	DC_Servo	Servo On / Servo Off
0x3440	0	devCtrl	Device Control
0x3441	0	devStat	Device Status
0x3300		StopDec	Stop 1 Ramp
	1	StopDec1	
	2	StopDec2	
0x3301		StopI	Stop 3 current limit
	1	StopI1	
	2	StopI2	
0x3302		StopTime	Stop Time Limit
	1	StopTm1	
	2	StopTm2	Stop 2 Time out
0x6085	0	QS_dec	Quick Stop Ramp
0x3304	0	DrvTime	Amplifier Reaction Time
0x3305	0	BrkTime	Motor Brake Reaction Time

Factor Group

0x608F		PosResol	Encoder Position Resolution
0x6093		Pos1Fact	Position Factor
0x6089	0	Pos1Nota	
0x608A	0	Pos1Dim	
0x3089	0	Pos1Disp	Position Display Factor
0x308A	0	Pos1Unit	Position Unit Name

Motor

0x6410			Motor Data
	1	MotorMan	
	2	MotorNm	
	3	MotorCod	
	4	McatDate	
	5	MmodDate	
	6	Mtype	
	7	Mmaxspd	
	8	Mrtdspd	
	9	Mstalll	
	10	Mpeakl	
	11	M_Kt	
	12	M_J	
	13	Minduct	
	14	Mpolepr	
	15	MPhase	
	16	Moffset	
	17	MTtype	
	18	MTthres1	
	19	MTthres2	
0x6072		MaxTq	Max Torque
0x6073		MaxI	Motor Max current
0x6075		MotRtdI	Motor Rated Current
0x6076		MotRtdTq	Motor Rated Torque

0x3410		MotorPar	Motor Parameters
	1	PolePair	Current Number of motor pole pairs
	2	MotPhase	Current Motor Phase
	3	RotorOfs	Current Motor Offset
0x340F	0	Induct	Current Motor Inductance
0x3323	0	MT_res	Motor temperature probe monitoring
0x3324		MT_cfg	Motor temperature probe config
	1	MT_probe	Motor temperature type (NTC/PTC)
	2	MT_warn	Motor temperature warning threshold
	3	MT_error	Motor temperature error threshold

Sensors

0x306A	0	Pos_FB	Position Feedback Sensor Select
0x3070	0	Motor_FB	Motor Feedback Sensor Select

Resolver Input

0x3100		Resolver	Resolver monitoring
	1	Res_Sin	
	2	Res_Cos	
	3	Res_Amp2	
	4	Res_Mod	65536 for one motor revolution
	5	Res_Amp	
0x3101	0	Res_Setp	Resolver Setup
	1	Res_Type	Enable/Setup Resolver Input
	2	Res_Cfg	
	3	Res_Zsh	
	4	Res_Zsz	
	5	Res_NP	
	6	ResRatio	
0x3102	0	Res_Err	Resolver Error control
	1	Res_Thrs	
	2	Res_Lim	
	3	Res_AmpF	
	4	Res_Rdc	
0x3104		Res_Cal	Resolver Calibration Procedure
0x3105		Res_CalV	Resolver Calibration parameters
0x3107	0	Res_TopZ	Resolver Virtual Top Z
0x3108	0	Res_ofs	Resolver Offset (user position unit)
0x3109	0	Res_pos	Resolver Position (user position unit)
0x310A	0	Res_vel	Resolver Velocity (user velocity unit)
0x310C	0	Res_raw	Resolver raw position

Encoder Input

0x3120		Encoder1	Encoder
	1	Enc1Sin	
	2	Enc1Cos	
	3	Enc1Amp2	
	4	Enc1Mod	65536 for one motor revolution
	5	Enc1Amp	
0x3121		Enc1Setp	Encoder Setup
	1	Enc1Type	
	2	Enc1Cfg	
	3	Enc1Zsh	
	4	Enc1Zsz	
	5	Enc1res	
	6	Enc1turn	
	7	Enc1Zlen	
0x3122		Enc1Err	Encoder Error Control
	1	Enc1Cnt	
	2	Enc1Thrs	
	3	Enc1Lim	
0x3124		Enc1CalP	Encoder Calibration
0x3127	0	Enc1TopZ	Encoder Virtual Top Z
0x3128	0	Enc1ofs	Encoder Offset (user position unit)
0x3129	0	Enc1pos	Encoder Position (user position unit)
0x312A	0	Enc1vel	Encoder Velocity (user velocity unit)
0x312B	0	Enc1Ref	
	1	Enc1RefP	
0x312C	0	Enc1raw	Encoder1 Raw Position
0x313E	0	Enc1HesC	

Servo Loops

Current Loop

0x3400		Imon	Motor Current Monitoring
0x3402		Iofs	Motor Current offset measurement
0x3408		Vdcmon	DC Voltage monitoring
	1	Vdc	DC Voltage value (V)
	2	VdcFilt	Filter for DC voltage measurement (Hz)
0x30DA		IlimSrc	Dynamic Current Limit Input Source
0x30D1	0	Ilimit	Current Limitation
0x30D2	0	IlimCfg	Dynamic Current Limit Configuration
0x30D4	0	Iq	Iq Current monitor
0x30D5	0	Id	Id Current monitor

0x3411	0	CalcIip	Current Loop Calculation
0x3412	0	CalcIlim	Current Limitation Calculation
0x60F6		Tq_CTRL	Current Loop Parameters
	1	IregType	
	2	KPq_I	
	3	KIq_I	
	4	KPd_I	
	5	KId_I	
0x30F5		TqLpmon	Current Loop Monitoring
	1	IdRef	
	2	IqRef	
	3	Idmon	
	4	Iqmon	
	5	VdRef	
	6	VqRef	
	7	PosElec	
0x6079	0	DCvolt	DC Voltage
0x30F4		IdrvLim	Current limit parameters

0x3413		APstart	Auto-phasing
--------	--	---------	--------------

0x3414		MCstart	Motor phasing
--------	--	---------	---------------

Speed Loop

0x60F9		Vel_CTRL	Speed Loop Parameters
	1	VregType	
	2	KPv	
	3	KIv	
	4	KIvf	
	5	KCv	
	6	KDv	
	7	KDvf	
	8	KJv	
0x30F9		VFilter	Speed Error Low-pass Filter
	1	SpErrLF1	
	2	SpErrLF2	
	3	SpErrLF3	
0x30FA	0	TVelMes	Speed measurement filter
0x30F8		VelLpmon	Speed Loop Monitoring
	1	VelRef	Demand speed (0x7FFF -> Maximum motor speed)
	2	VelFb	Motor speed (0x7FFF -> Maximum motor speed)
	3	VelErr	Speed loop error (0x7FFF -> Maximum motor speed)
	4	Idc	Current command (0x7FFF -> Drive max current (0x6510))
	5	IcomF	Speed loop current command in limitation indicator

Position Control

0x307B	0	PosRgEna	Modulo configuration
0x607B		PosRange	Position Limit
	1	PosRgMin	
	2	PosRgMax	
0x60FB		Pos_CTRL	Position Control Parameters Set
	1	PregType	
	2	KPp	
	3	KFp	
	4	KAv	
	5	KBv	
0x30FC		PosLpmon	Pos Loop monitoring
	1	PosRef	
	2	PosFB	
	3	Vref	
0x6062		PosDem	Position Demand Value (user position unit)
0x60B0		PosOfs	Position Offset (user position unit)
0x6063		IntPos	Position Actual Value (user position unit)
0x6064		ActPos	Actual position (user position unit)
0x6065		PosErWin	Following Error Window (user position unit)
0x3065		FWctrl	Following Error Error control
0x60F4		PosErr	Following Error Actual Value

External Feedforward

0x31FF		FForward	External Feedforward
--------	--	----------	----------------------

Auto-tuning

0x3425	0	Autotune	Auto-tuning parameters
	1	ATbwidth	
	2	ATtype	
	3	ATselect	
	4	ATappl	
0x3426	0	ATstart	Auto-tuning
0x3427	0	KsDig	

Error Control

0x3022	0	Error	Error monitoring
	1	Error1	
	2	Error2	
	3	Error3	
0x3023	0	ErrCode	
	1	ErrState	
	2	LastErr	
	3	PrevErr	
0x3024	0	Warning	Warning
0x3025	0	Err_Ctrl	Error control (mask)
	1	ErrMask1	
	2	ErrMask2	
	3	Stop1Mk1	
	4	Stop1Mk2	
	5	Stop3Mk1	
	6	Stop3Mk2	

0x3404	0	lprotect	I ² t monitoring/parameter
	1	I2tMode	
	2	I2t	
	3	Imotor	

Profile Position Mode

0x607A	0	TargePos	Target Position
0x6080	0	MaxSpeed	Maximum motor speed
0x6081	0	ProfiVel	Profile Velocity
0x6082	0	PPendVel	End Velocity
0x6083	0	ProfiAcc	Profile Acceleration
0x6084	0	ProfiDec	Profile Deceleration
0x6086	0	ProfType	Motion Profile Type
0x6067	0	PosWindo	Position Window
0x6068	0	PosWinTi	Position Window Time
0x607D	0	PosLimit	Software Position Limit
	1	MinPosLm	Minimum position Limit
	2	MaxPosLm	Maximum position Limit
0x607F		MaxPPvel	Max Profile Velocity
0x3360	0	AxeType	Axis Type
0x3081	0	SpModSrc	Position Profile Speed Modulation Input Source
0x3082	0	SpModCfg	Position Profile Speed Modulation Configuration
0x3083	0	SpMod	Position Profile Speed Modulation

Homing Mode

0x607C		HomeOfs	Home Offset
0x6098		HomeMeth	Homing Method
0x6099		HomeSpds	Homing Speeds
	1	HomeSpd1	Speed during search of switch
	2	HomeSpd2	Speed during search of zero
0x609A		HomeAcc	Homing Acceleration
0x309C		HCurLim	Home Current Limit
0x309D		HEndHome	End On Home Position

Interpolated Position Mode

0x60C0		IPmode	Interpolated SubMode Select
0x60C1		IPrecord	Interpolated Data Record
0x30C1		IPoutput	Interpolation output
0x3350		IPformat	Absolute 16-bit Position Reference

Profile Velocity Mode

0x60B1	0	VelOfs	Offset Velocity
0x30B1	0	VelOfsSc	Offset Velocity input source
0x60FF	0	TargetV	Target Velocity
0x606B	0	VelDem	Velocity Demand Value
0x606C	0	VelAct	Velocity Actual Value
0x306C	0	VelFilt	Velocity measurement filter
0x3069	0	Velocity	Velocity Actual Value (rpm)
0x606D	0	VelWin	Velocity Window
0x606E	0	VelWinTm	Velocity Window Time
0x606F	0	VelThr	Velocity Threshold
0x6070	0	VelThrTm	Velocity Threshold Time
0x30FF	0	VellnObj	Target Velocity Input Object

Profile Torque Mode

0x6071	0	TqTarget	Target Torque
0x3071	0	TqSrc	Target Torque input source
0x6087	0	TqSlope	Torque Slope
0x6088	0	TqProfil	Torque profile type
0x60B2	0	TqOffset	Offset Torque
0x30B2	0	TqOfsSrc	Offset Torque input source
0x30B3	0	TqOfs2	Torque Offset 2
0x6074	0	TqDemand	Torque Demand Value
0x6077	0	TqValue	Torque Actual Value
0x6078	0	CurrAct	Current Actual Value
0x6079	0	DCvolt	DC Voltage
0x3078	0	CurrFilt	Current measurement filter

Sequence Mode

Sequence Control

0x3601		SQin	Sequence Inputs
	1	SQnb	Sequence Number Input
	2	SQrun	Executed Sequence Number
	3	SQcond	Conditional Inputs
	4	SQinp	Sequence Inputs
0x3602		SQoutp	Sequence Outputs
	1	SQout	Programmable Logic Outputs
	2	SQoutpol	Programmable Logic Outputs Polarity
	3	SQsta	Dedicated Logic Outputs
	4	SQstapol	Dedicated Logic Outputs Polarity
0x3603	0	SQSpulse	Minimum Sequence Pulse
0x3604		SQoutcfg	Output Pulse Configuration
	1	SQOpulse	Output Pulse
	2	SQOtime	Output Pulse Duration
0x3605	0	SQphase	Sequence phase
0x360B	0	SQpcapt	Sequence position capture
0x360C	0	SQconfig	Sequence Configuration
0x360F	0	SQavail	Supported Sequence Type

Sequence Parameters

0x3610	0	SQParNb	Sequence Parameters Number
0x3611	0	SQPar	Sequence Parameters
	1	SQPtype	Sequence Type
	2	SQPnext	Next sequence
	3	SQPcnt	Sequence Counter
	4	SQPlink	Sequence Link
	5	SQPtrig	Output Trigger
	6	SQPout0	Output Bits = 0
	7	SQPout1	Output Bits = 1
	8	SQPoutT	Output Bits Toggle
	9	SQPst0	Start Condition Bits = 0
	10	SQPst1	Start Condition Bits = 1
	11	SQPstop0	End Condition Bits = 0
	12	SQPstop1	End Condition Bits = 1
	13	SQPpos	Position
	14	SQPpos2	Position 2 (reserved for future use)
	15	SQPvel	Speed
	16	SQPext	Speed 2 / Position 3 (reserved for future use)
	17	SQPaccel	Acceleration
	18	SQPdecel	Deceleration
	19	SQPtacc	Acceleration Time
	20	SQPtdec	Deceleration Time
	21	SQPcfg	Configuration
	22	SQPcfg2	Configuration 2
	23	SQPtempo	Temporization
	24	SQPrtime	Running Time
	25	SQPana	Analog In
	26	SQPana2	Analog In 2 (reserved for future use)
0x3612	0	SQmaxNb	Number of maximum sequences

Analog Speed Mode

0x604F	0	Vramp	
0x304F	0	Vramp2	

Application FE

Digital Inputs/Outputs

0x60FD	0	Dinput	Digital Inputs
0x3050		DInpCfg	Digital Inputs Configuration
	n	Inp?Cfg	
0x3051	0	InpPol	Digital Inputs Polarity
0x60FE		Doutput	Digital Outputs
	1	Dout	
	2	DoutBMSk	
0x3054		DOutpCfg	Digital Outputs Configuration
	n	Outp?Cfg	
0x3055	0	OutpPol	Digital Outputs Polarity
0x3058		Dio16	Digital User Inputs/Outputs
		Dinp16	Digital Inputs 16b
		Doutp16	Digital Outputs 16b
		Dinp16hw	Physical Digital Inputs 16b
0x3043		enable	Enable Configuration
		ena_cfg	

Analog Input

0x30F1		AnalogI1	Analog Input 1
	1	Analn1	
	2	AI1s32	
	3	AI1_ofs	
	4	AI1_gain	
	5	AI1_filt	
	6	AI1_lv0	
	7	AI1_lv1	
	8	AI1_proc	
	9	AI1_db	

Oscilloscope

0x5800	0	Osc_Func	Oscillo function support
0x5804		Osc_Buf	Oscillo Buffer configuration
0x5805	0	OscBufDI	Oscillo Buffer delay
0x5810		OscChCfg	Oscillo Channel config
0x5811		OscChan	Oscillo Channel definitions
0x5812		OscUnit	Oscillo Channel Unit
0x5820		OscTgSrc	Oscillo Trigger configuration
0x5822		OscTrig	Oscillo Trigger 1
0x5828	0	OscTgCtl	Oscillo Trigger Control
0x5829	0	OscTgSta	Oscillo Trigger Status
0x5840		OscTxCfg	Oscillo Buffer transfer configuration
0x5841	0	OscTx	Oscillo Buffer transfer

Firmware Update

0x5F30		UpdtDrv	Update Firmware
0x5F31		UpdtInit	Update init
0x5F32		UpdtProc	Update process

Kontakt

Stegmaier-Haupt GmbH
Industrieelektronik-Servoantriebstechnik
 Untere Röte 5
 D-69231 Rauenberg
 Tel.: 06222-61021
 Fax: 06222-64988
 Email: info@stegmaier-haupt.de
 Http: [//www.stegmaier-haupt.de](http://www.stegmaier-haupt.de)